

# DUXOT

## INSTRUCTION MANUAL

Vol. 1.20 EN



# Alfius

## POWER RESERVE AUTOMATIC WATCH



This timepiece is equipped with a self-winding Mechanical Automatic movement.

**It does not need a battery.**

It is powered by the motions of the user's own wrist during the wear of the watch. You may also choose to wind the watch manually.

For more details on operating this timepiece please refer to the enclosed booklet or visit :

**DUXOTWATCHES.COM**



1

**BEFORE YOU USE THIS WATCH, IT IS RECOMMENDED THAT YOU MANUALLY WIND THE MAINSPRING TO START IT MOVING.**

THIS WATCH IS AN AUTOMATIC WATCH EQUIPPED WITH A MANUAL WINDING MECHANISM.

### WINDING THE MAINSPRING



1. When it is in position [0], turn the crown clockwise to wind. Wind 15-20 times and it will start to move naturally after shaking slightly.


2

- \* This watch **MUST** be worn for at least 8 (Eight) hours each day to ensure it is fully wound. An automatic watch will only wind when the watch is on your wrist and your arm moves. Winding the watch by the crown will put power on the spring but not enough to allow the watch to function fully. If your watch stops overnight or loses time it means it is not being fully wound.

3

### HOW TO SET THE TIME

1. Pull the crown out to position [1]-**(1st click)**.
2. Turn the crown clockwise to set the correct time.
3. Push the crown in.



- \* Take a.m./p.m. into consideration when setting the hour and minute hands to the desired time.

### POWER RESERVE INDICATION

The power reserve hand indicates the power stored inside your timepiece.

Not wearing the timepiece for several consecutive days could exhaust the power reserve. If your watch stops, it is recommended that you manually wind the movement by rotating the crown clockwise to achieve the necessary power reserve.

4

5

## WATER RESISTANCE

Note that the water resistance chart serves only as a guide (please refer to the water resistance chart on the next page). Actual water resistance may vary depending on a number of factors including water temperature, water salinity, and use under water.

The water resistance of your timepiece may eventually be compromised over time with general wear and tear and use of your timepiece under adverse conditions.

Always remember to employ the screw down crown if available to maintain the water resistance of your timepiece. Warranty may be voided if the screw down crown has not been properly employed.

Note that you should **never** wear your watch in a jacuzzi or steam room where steam may enter the case despite the water tight seals used to protect your watch. This may cause condensation inside your watch which may effect and damage the inner workings of your watch.

WATER RESISTANCE CHART	30M/ 3ATM	50M/ 5ATM	100M/ 10ATM	150M/ 15ATM	200M/ 20ATM
<b>SPLASH/ SHOWERING</b>	☑	☑	☑	☑	☑
<b>SWIMMING/ BATHING</b>	☒	☑	☑	☑	☑
<b>BRIEF SWIMMING/ WATER SPORTS</b>	☒	☒	☑	☑	☑
<b>PROLONGED SWIMMING/ FREE DIVING</b>	☒	☒	☒	☑	☑
<b>SCUBA DIVING</b>	☒	☒	☒	☒	☒
<b>PROFESSIONAL DEEP SEA DIVING</b>	☒	☒	☒	☒	☒