









# Harlow LED Floating Vanity

Installation instructions



Hardware				Tools ( not includes )	
NO.		Draw	QTY		
A	White rubber plug(Ø6mm)		2		
B	Screws(Ø4 x 68mm)		2		
C	Stainless steel cover		2		
D	Leveling bracket		2		
E	Green rubber plug		6		
F	Screw		6		

Depending on the sinks selected, the total height will vary from 33-1/2"(850mm) to 35-1/4"(895mm). If an alternate height desired, adjust the rough-in and backing material heights using the dimensions provided.




## STEP 1

- Draw a punched position on the wall with a pencil.


Tip:

1. The suggestion height of the cabinet is 32-11/16" (830mm) - not including the basin.
2. The suggestion height of the upper hole is 30-11/16" (780mm).
3. The suggestion distance between the upper hole to the lower hole is 10 1/16" (255mm).




## STEP 2

- Drill the holes with suitable drill-bits base on different condition of the wall.





## STEP 3

- Use a hammer to knock the white expansion rubber plug into the upper hole, and knock the green rubber plug into the three lower hole, align the hole in the wall and lock the leveling bracket to the wall with screws.





## STEP 4

- Hang the accessories behind the cabinet on the leveling bracket.(As the picture shows).





## STEP 5

- Fix the cabinet to the wall with screw B and cover it with a stainless steel lid C.



## STEP 6

- Install sink top with silicone and finish.



# IMPORTANT SAFETY INSTRUCTIONS

When using an electrical furnishing, basic precautions should always be followed, including the following:

**⚠ WARNING:** To reduce the risk of burns, fire, electric shock or injury to persons. Use this furnishing only for its intended use as described in these instructions. Do not use attachments not recommended by the manufacturer. Never drop or insert any object into any opening. Do not use outdoors.

**⚠ WARNING:** Risk of electric shock. Connect this furnishing to a properly grounded circuit only. See grounding instructions.

## ELECTRIC CONNECTIONS

**ALL WIRING SHOULD BE DONE BY A QUALIFIED LICENCED ELECTRICIAN.**


**⚠ WARNING:** Shut off power before wiring the cabinet.  
Requires 120 VAC 20 Amp GFI protected Circuit.

### GROUNDING INSTRUCTIONS:

**⚠ CAUTION:** This product must be connected to a grounded metal permanent wiring system or an equipment-grounding conductor must be run with the circuit conductors and connected to the equipment grounding terminal or lead on the product.


**⚠ WARNING:** An Electrical option cabinet must be wired to a 20 Amp GFI (Ground Fault Interrupter) protected circuit when used in bathrooms and all other locations required by the National Electric Code.

The electric wire comes through the access hole on the top of the cabinet. exact location of access hole varies depending on the product models. Please refer to the actual product for the exact location.



Make connection with Junction box

Neutral to white.  
Line to black.



★ junction box is not included ★

