

Ripstop[®] ByTheRoll

Synthetic Underquilt Kit



Step 1: Cut your fabric and insulation to 46 x 79" for a full length or for 46 x 53" for 3/4 length.




Step 2. Cut 2 pieces of 1.5" grosgrain to 43" long. Heat seal the edges.



Step 3: Cut 1/2" grosgrain to 4 pieces 8" long, heat seal the edges. Use Lineloc 3's, and sandwich 2 tieouts around the 1.5" grosgrain.



Correct order for stacking




Step 4: Lay down your first piece of fabric (correct side up) and align the grosgrain with tieouts along the bottom.




Step 5: Add second layer on top (Correct side DOWN)



Step 6: Pin along the perimeter




Step 7: Sew perimeter, leaving a 10" gap on the top.



Step 8: Lay insulation on top. Pin and Sew.

Leave the same 10" gap as before.



Step 9: Reach in between the layers of fabric, grabbing the far end of the quilt, and turn it inside out.



Step 10: Sew the 10" opening closed.



Step 11: Use the other piece of 43" long 1.5" Grosgrain to bind the edge. Leave a space for shock cord.



Close up



Step 12: Sew the remaining timeouts onto the ends of the quilt.



Step 13: Run shock cord through the end channels. Use cord locks to tighten the ends of the quilt.



Step 14: Run shock cord through the Lineloc 3's. Attach to suspension with microbiners.



