

Instructional Guide:

How To Raise and Lower Fusion Pool Table

Height Notes:

➤ Lower Mode (Dining): 29.5" with Dining Tops

➤ Higher Mode (Pool Table): 32"

Important Notes:

- Unless by a trained professional, never attempt to move the table (even slightly), from its original installed location. The table is leveled, and the legs are set in its original position. Moving the table will run the risk of damage and void all warranties.
- 1. Raising from Dining (low), to Pool (high): Always one side at a time (never at the same time). Start at either the head or the foot of the table (short ends). Using two hands, slowly lift the table upwards, until you hear the 'click', as well as feel the table lock into the leg mechanisms, that holds the table at the higher height. Repeat on the other side.
- 2. Lowering from Pool (high) to Dining (low): Always one side at a time (never at the same time). Start at either the head or the foot of the table (short ends). Using two hands, slowly lift the table upwards, until you cannot lift any higher (essentially, hit the "ceiling"). Once you lift the end as high as the table reaches, this will unhook the leg mechanism in the higher position and allow the table to gently lower back to the Dining (low) height.

For all immediate questions and information:

info@blattbilliards.com

212-675-8855

Blatt Billiards, 330 West 38th Street, New York, NY 10018