



Chrysler Sebring Convertible & Sedan 2001-2005 Dodge Stratus Sedan 2001-2006



PART NUMBER: DG-54-01-G3

PLEASE READ COMPLETE INSTRUCTIONS BEFORE INSTALLING THIS VSM G3

All instructions assume a drivers seat vantage point. Caution is advised when removing and reassembling wood or plastic parts of a dash. Applying unnecessary force or pressure may cause a piece to crack or break.

**When properly installed, the metal between the ball and 2 small holes is all that is exposed.
(Some exceptions apply).**

TOOLS REQUIRED: #2 Phillips screwdriver, hook tool, 5/64" drill bit and drill, marking pen.

PARTS INCLUDED: VSM G3, A Plate, J Stem, three (3) #8 x 1/2" screws

LOCATION: Right of radio

STEP 1. Begin by removing the trim bezel around the radio and climate control module. The bezel is held in place with six (6) clips, one (1) each in the following locations: lower left and right, middle left and right, and upper left and right. Insert a hook tool in the lower right corner and gently pull outward to release a clip. Work the hook tool up the right side and then the left, gently pulling outward until all the clips are released. Pull the bezel forward and slide it slightly to the left, exposing a trim screw. (See photo #1). The climate control is integrated in the bezel, so it will also come forward. Do not disconnect any wiring.

STEP 2. Remove the Phillips screw shown in Photo #1. Next, remove the trim bezel strip located directly to the right of the trim screw. Insert a hook tool behind the left end of the trim bezel strip and pull outward. Working to the right with a hook tool, release the four (4) trim bezel clips. Set the trim piece aside.

STEP 3. Place the VSM G3 under the trim bezel clip as shown in Photo #1. Hold it snugly against the dash pad and mark the location of the three (3) holes. Set the VSM G3 aside. Drill three (3) pilot holes at the marked locations using a 5/64" drill bit and drill. These holes should be about 1/2" deep. Align the VSM G3 over the pilot holes, insert three (3) #8 x 1/2" screws and tighten.

Step 4. Re-assemble the dash in reverse order. You have successfully installed your VSM G3!

Note: See the Assembly Instructions for G3 Components for additional information.



Pro.Fit International, Inc.® may not be held liable for any damage to a vehicle before, during or after the installation or removal of this VSM G3™. Pro.Fit International may not be held liable for any personal injury resulting from accident or improper installation. Pro.Fit International, Inc.® 1335 Eagandale Court, Eagan, MN 55121, Ph: 651.688.3588 or 800.388.0073 Fx: 651.688.9876

Installation Difficulty
● ○ ○ ○ ○
Simple Advanced

© Pro.Fit International, Eagan, MN 2008

View Instruction & Updates
Online at
www.pro-fit-intl.com



Mercedes R 350 2008

PART NUMBER: DG-54-01-G3



PLEASE READ COMPLETE INSTRUCTIONS BEFORE INSTALLING THIS VSM G3

All instructions assume a drivers seat vantage point. Caution is advised when removing and reassembling wood or plastic parts of a dash. Applying unnecessary force or pressure may cause a piece to crack or break.

**When properly installed, the metal between the ball and 2 small holes is all that is exposed.
(Some exceptions apply).**

TOOLS REQUIRED: Dash Trim Removal Tool (DTRT), 5/64" bit and drill, Phillips Screw driver, marking pen

PARTS INCLUDED: VSM G3, A Plate, J Stem, three (3) #8 x 1/2" screws

LOCATION: Right of radio

STEP 1. Place the DTRT in the space between the dash molding and the trim piece that runs the length of the dash on the passenger side of the vehicle. Photo #1. Use the DTRT in a gentle twisting motion in order to release a series of four (4) retainer clips securing this trim piece to the dash. Once the retainer clips have been removed place the trim piece off to the side.




STEP 2. Place the VSM G3 in position exactly as pictured in Photo #2. Use the VSM G3 as a guide and mark the locations of the pilot holes with a marking pen. Carefully drill out the marked locations with a 5/64" bit and drill. DO NOT drill more than 1/4" deep. Place the VSM G3 over the pilot holes and tighten it to the dash molding with the three (3) provided #8 x 1/2" screws and a Phillips screw driver.



STEP 3. Once the VSM G3 is flush to the dash molding and secure, secure the trim piece back into position. You have successfully installed your VSM G3!



Pro.Fit International, Inc.® may not be held liable for any damage to a vehicle before, during or after the installation or removal of this VSM G3™. Pro.Fit International may not be held liable for any personal injury resulting from accident or improper installation. Pro.Fit International, Inc.® 1335 Eagandale Court, Eagan, MN 55121, Ph: 651.688.3588 or 800.388.0073 Fx: 651.688.9876



© Pro.Fit International, Eagan, MN 2008

View Instruction & Updates
Online at
www.pro-fit-intl.com