



Hyundai Sonata 2009-2010

IF-71-03-G3



PLEASE READ COMPLETE INSTRUCTIONS BEFORE INSTALLING THIS VSM G3

All instructions assume a drivers seat vantage point. Caution is advised when removing and reassembling wood or plastic parts of a dash. Applying unnecessary force or pressure may cause a piece to crack or break.

**When properly installed, the metal between the ball and 2 small holes is all that is exposed.
(Some exceptions apply).**

TOOLS REQUIRED: Dash Trim Removal Tool (DTRT), Phillips Screw driver, 5/64" bit and drill, marking pen

PARTS INCLUDED: VSM G3, A Plate, J Stem, two (2) #8 x 1/2" screws

LOCATION: Right of Air Vent

STEP 1. Apply the emergency brake and place the vehicle in neutral. Insert the DTRT in the space between the shifter bezel and the floor console. Use a gentle twisting motion around the shifter bezel in order to release a series of retainer clips. Once the shifter bezel has been released, simply slide it carefully back and away from the cubby hole.

STEP 2. There is a plastic trim piece located on each side of the cubby hole that is held in place by three (3) retainer clips. Insert the DTRT in between the dash molding and these trim pieces and use a gentle twisting motion to release the retainer clips. Do not disconnect the wiring; simply allow these trim pieces to hang off to the side.

STEP 3. Remove two Phillips screws located directly underneath the climate control. See Photo #2. These screws not only secure the bottom of the radio/climate control bezel, but also secure a small plastic bezel located between the climate control and the cubby hole. After the screws have been removed, remove this small plastic bezel very carefully as it is a delicate piece.

STEP 4. Insert the DTRT between the radio/climate control bezel and the dash molding. Use a gentle twisting motion around the radio, climate control, and air vents releasing 6 retainer clips. Disconnect all wiring harnesses connecting the bezel and carefully place it aside. Remove the four (4) screws surrounding the radio, pull it carefully straight out and wrap it in a protective cloth. Do not disconnect the radio; simply allow it to hang out of the way.

STEP 5. Place the VSM G3 in position exactly as shown in Photo #3. Once the VSM G3 is flush and in position, mark the pilot holes with a marking pen. Use a 5/64" bit and drill to drill out the pilot holes. Be careful not to drill more than 1/4" deep. Place the VSM G3 over the pilot holes and tighten the VSM G3 evenly and flush to the dash molding with the two (2) provided #8 x 1/2" screws.

STEP 6. Once the VSM G3 is secure and in position, place the dash back together in the reverse order in which it was dismantled. You have successfully installed your VSM G3.

Note: See the Assembly Instructions for G3 Components for additional information.



Pro.Fit International, Inc.® may not be held liable for any damage to a vehicle before, during or after the installation or removal of this VSM G3™. Pro.Fit International may not be held liable for any personal injury resulting from accident or improper installation. Pro.Fit International, Inc.® 1335 Eagandale Court, Eagan, MN 55121, Ph: 651.688.3588 or 800.388.0073 Fx: 651.688.9876

Installation Difficulty

● ● ● ○ ○
Simple Advanced

© Pro.Fit International, Eagan, MN 2008

View Instruction & Updates
Online at
www.pro-fit-intl.com