



Volvo S80 2008-2011
Volvo XC70 2008-2011
Volvo v70 2008-2010
MV-25-03-G3



PLEASE READ COMPLETE INSTRUCTIONS BEFORE INSTALLING THIS VSM G3

All instructions assume a drivers seat vantage point. Caution is advised when removing and reassembling wood or plastic parts of a dash. Applying unnecessary force or pressure may cause a piece to crack or break.

TOOLS REQUIRED: Dash Trim Removal Tool (DTRT), Hook Tool, T20 Torx driver, 5/64" bit and drill, marking pen, Phillips screw driver

PARTS INCLUDED: VSM G3, A Plate, J Stem, three (3) #8 x 1/2" screws

LOCATION: Right of Radio

Step 1: Use a hook tool and DTRT together to carefully remove the emergency flasher (**Photo #1**) from between the two center air vents. Place the DTRT and hook tool between the dash molding and the small plastic bezel surrounding the emergency flasher and release the top of this small bezel first. Once this bezel has been removed, locate the T20 Torx screw located directly behind the button, remove it and carefully set it aside.


Step 2: Open the passenger door in order to reveal a small plastic bezel covering the passenger side of dash. Remove this side cover using the DTRT in a gentle twisting motion in order to release two (2) retainer clips, tilt and slide the side cover out. Use the T20 Torx driver to carefully remove the screw that is immediately exposed when the side cover is removed.

Step 3: Insert the hook tool and DTRT in the space between the air vent assembly and the dash molding starting on the left side of the air vent bezel. Use the hook tool in a manner to create enough space for the DTRT. Once the DTRT is in place, use a gentle twisting motion in order to release a series of two (2) clips securing the left side of the air vent bezel. Continue to release a total of eight (8) retainer clips working from left to right and remove the entire air vent assembly.

Step 4: Place the VSM G3 flush and in place just as pictured (**Photo #3**). Use the VSM G3 as a guide and mark the locations of the pilot holes. Use 5/64" bit and drill to drill out the locations of the pilot holes. DO NOT DRILL MORE THAN 1/4" DEEP! Place the VSM G3 over the pilot holes as pictured. Secure the VSM G3 to the dash molding with the three (3) provided #8X1/2" screws and a Phillips screw driver. Be careful not to over tighten.

Step 5: Once the VSM G3 is flush and secured, place the dash back together in the reverse order in which it was disassembled. You have successfully installed your VSM G3!

Note: See the Assembly Instructions for G3 Components for additional information.



Pro.Fit International, Inc.® may not be held liable for any damage to a vehicle before, during or after the installation or removal of this VSM-G3. Pro.Fit International may not be held liable for any personal injury resulting from accident or improper installation.

Pro.Fit International, Inc.® 314 West 86th Street, Bloomington, MN 55420, Ph: 952.641.4700 or 800.388.0073 Fx: 952.641.4701

Installation Difficulty
● ○ ○ ○ ○
Simple Advanced

© Pro.Fit International, Bloomington, MN 2009-2012

View Instruction & Updates
Online at
www.pro-fit-intl.com