



Honda Accord 2003-2007 (Vehicles built for US Market Only)

PART NUMBER: MV-50-03-G3



PLEASE READ COMPLETE INSTRUCTIONS BEFORE INSTALLING THIS VSM G3

All instructions assume a drivers seat vantage point. Caution is advised when removing and reassembling wood or plastic parts of a dash. Applying unnecessary force or pressure may cause a piece to crack or break.


**When properly installed, the metal between the ball and 2 small holes is all that is exposed.
(Some exceptions apply).**

TOOLS REQUIRED: #2 Phillips screwdriver, drill and 5/64" bit, Dash Trim Removal Tool (DTRT), marking pen


PARTS INCLUDED: VSM G3, A Plate, J Stem, two (2) #8 x 1/2" screws

LOCATION: Right of radio


STEP 1. Begin by setting the emergency brake and putting the gear shift into neutral. Using the DTRT, remove the bezel surrounding the gear shift lever. Starting in the lower left corner of the bezel, using a gentle twisting motion, work the tool around the bezel, releasing six (6) clips. Lift bezel over shifter and set aside. Remove the two (2) screws in front of the shifter.



STEP 2. Open the tray cover to the left of the power outlet. Use DTRT to lift the tray out, releasing two (2) clips on the bottom. Remove the two (2) screws that are under the tray. Use the DTRT to lift the front of the power outlet assembly, releasing three (3) clips. Set outlet aside. Remove the two (2) screws from the bottom corners of the bin above the power outlet. Close the door and pull the box out. Remove the two (2) hex-head screws from the bottom of the radio. (Photo #1).



STEP 3. Insert the DTRT behind the lower right corner of the air vent and release the clip. (Photo # 3). Work the tool to the left to release two (2) more clips. Pivot the bottom edge of the vent upward until the top comes free. Set the vent on top of the dash. Remove the three (3) Phillips screws from the top of the radio. Use the DTRT to release three (3) clips at the bottom of the radio. They are located directly below the large, round knobs. Pull the radio out of the dash and let hang down. DO NOT disconnect any wires to the radio.




STEP 4. Place the VSM G3 against the dash pad to the right of the radio. The top edge of the G3 should be approximately 1/4" above a small ridge. (Photo #2). Using the holes of the G3 as a guide, mark the location of two (2) holes and drill two (2) pilot holes. Align the G3 over the pilot holes, insert two (2) #8 x 1/2" screws and tighten.

STEP 5. Assemble the dash in reverse order, remembering to reattach wiring to bezel. This completes the installation of your VSM G3.

Note: See the Assembly Instructions for G3 Components for additional information.

Pro.Fit International, Inc.® may not be held liable for any damage to a vehicle before, during or after the installation or removal of this VSM G3™. Pro.Fit International may not be held liable for any personal injury resulting from accident or improper installation. Pro.Fit International, Inc.® 1335 Eagandale Court, Eagan, MN 55121, Ph: 651.688.3588 or 800.388.0073 Fx: 651.688.9876



© Pro.Fit International, Eagan, MN 2008

View Instruction & Updates
Online at
www.pro-fit-intl.com