

Safety

Safety Instructions



- Unplug this product from the wall outlet before cleaning. Do not use this product near water or moisture. Do not spill liquids on the product. Clean only with a dry cloth.
- Place the unit on a solid surface.
- Do not put it in a closed bookcase or a cabinet that may keep air from flowing through its ventilation openings.
- Do not install near any heat sources, such as radiators, heat registers, stoves or other appliances that produce heat.
- Protect the power cord from being walked on or pinched, particularly at plugs and the point where they exit from the product.
- During Lightning storms, unplug the product from the power source or if unused for long periods of time. This will prevent lightning and power-line surge damage to the product.
- Do not attempt to service this product yourself. Opening or removing covers may expose you to dangerous voltages or other hazards. Please

contact the manufacturer to be referred to an authorized service center near you.

- Do not overload wall outlets, extension cords, or integral power circuits as this can result in a risk of fire or electric shock.
- Never push any object through the product openings, as this can result in fire, electric shock or damage.
- Use proper power sources. Plug the product into a proper power source, as described in the operating instructions or as marked on the product.

Quick start

1. On your Argon NanoDAC unit connect L/R stereo OUTPUT to your TV/Monitor or audio equipment using a RCA cable.
2. On your Argon NanoDAC unit connect the optical INPUT cable to your audio equipment, such as DVD player, etc.
 - a. *Notice: Before connecting the Optical cable, remember to remove the small plastic protection covers at each end of the Optical cable.*
3. Plug the power supply into the Argon NanoDAC unit and connect the adaptor to wall outlet.