

Stealthbox®

INSTALLATION GUIDE
for the
SB-GM-HUMRH3/10W1v3
SKU# 94196
2006 - 2010 Hummer H3



Thank you for choosing a JL Audio Stealthbox® for your automotive sound system. With proper installation, your new vehicle-specific enclosed subwoofer system will deliver years of listening pleasure.

We strongly recommend that you have your new Stealthbox® installed by your authorized JL Audio dealer. The installation professionals employed by your dealer have the necessary tools and experience to disassemble and reassemble your vehicle properly. Also, keep in mind that your warranty coverage extends to 2 year if your system is installed or approved by your authorized JL Audio dealer. If you prefer to perform your own installation, please read this installation guide completely before beginning the process.

JL AUDIO®
Ahead of the Curve™

! IMPORTANT

If you choose to perform the installation yourself, it is absolutely vital that the Stealthbox® be properly mounted to the vehicle according to these instructions. Failure to mount the enclosure properly presents two problems:

- 1) The sub-bass performance will suffer due to the movement of the enclosure caused by the force exerted by the woofer(s).
- 2) A loose enclosure presents a serious safety hazard in the event of a collision or sudden deceleration.

INSTALLATION DIFFICULTY:

3 OUT OF 5



STEP 1

Remove any contents from the rear cargo area and lower the rear seats forward.



STEP 2

The driver's side rear plastic inner fender needs to be removed. Using a 10mm socket and ratchet, remove the 5 bolts. Using a Phillip® head screw driver, remove the 2 screws.



STEP 3

Pop out the 5 plastic pop-rivets. The plastic inner fender will drop down.



STEP 4
From the cargo entrance, remove the weather stripping. Start at the lower middle. Pull off just past the driver side paneling.



STEP 5
At the driver's side rear door, remove the door sill.



STEP 6
With a Phillip® screw driver, remove the screw that is located under the cover panel.

With a T-50 Torx bit and ratchet, remove the seat belt loop.



STEP 7
Remove the top panel.




STEP 8
Remove the lower panel.



STEP 9
With a 10mm socket and ratchet, remove the four bolts that hold the factory woofer system into place.

Unplug the amplifier and remove the woofer system out of vehicle.



STEP 10
After the factory woofer system has been removed, look down into the cavity. There is a rubber matting that lays on top of the wheel well. Cut the front half of this matting out.

Place the wax square to the proper measurements, 3" from the side wall and 5-1/4-inch from the front wall.



STEP 11
Thread in the supplied socket cup set screw into the threaded insert, located on the bottom of the Stealthbox®. Leaving 1/2-inch exposed.



STEP 12

Position the Stealthbox® into place and press firmly down. This is to make an impression onto the wax square. Remove the Stealthbox®.

With a 1/2" drill bit or Step Bit/Unibit® and drill. Drill at the impression on the wax square, through the floor to the outside.

Remove the wax square.

(Disregard the woofer grille)



STEP 13

Using a factory bolt that was removed in STEP 9. Mount the supplied L-bracket to the upper right threaded mounting hole. One of the same holes that was used to mount the factory woofer system to the vehicle.

The L-bracket needs be mounted with the protruding angle to the top.




STEP 14

Loosen the socket cup set screw to expose 1-inch. Place the Stealthbox® into place, carefully guiding the socket cup set screw through the drilled hole.

Using a supplied bolt and washer, secure the L-bracket to the top of the enclosure.

(Disregard the woofer grille)



STEP 15

From the outside driver's side rear wheel well; place the supplied fender washer, flat washer, lock washer and then hex nut onto the protruding socket cup set screw. Secure tightly with a 14mm socket, long extension and ratchet.

Note: For added protection it is recommended that you apply a bead of silicone between the vehicle and the fender washer. After the bolt assembly is tightly secured, it is also recommended that vehicle undercoating material is applied to the exposed assembly.




STEP 16

Run speaker wire from the amplifier location to the Stealthbox® and attach to the terminal.

Check woofer for proper operation.

(Disregard the woofer grille)



STEP 17

Apply the supplied double sided tape to the supplied foam bar. Apply the foam bar to the back side of the lower cargo panel that was removed in STEP 8. The foam needs to be placed below the factory grille opening.

Secure this lower panel back into place.



STEP 18

Secure the upper panel back into place.



STEP 19

With a Phillip® screw driver, remount the screw that removed in STEP 6. Apply factory cover. With a T-50 Torx bit and ratchet, secure the seat belt loop. Apply factory cover.



STEP 20
Secure the driver's side rear door sill.



STEP 21
From the cargo entrance, reapply the weather stripping.



STEP 22
Secure the driver's side rear plastic inner fender.
Using a 10mm socket and ratchet, secure the 5 bolts.
Using a Phillip® head screw driver, secure the 2 screws
Pop in the 5 plastic pop-rivets.



CONGRATULATIONS
You have completed the installation for this model!

Please refer to the Power Recommendation section for an amplifier recommendation and basic set-up help.

INCLUDED HARDWARE


- | | |
|--|---|
| (1) 13/8-inch - 16 x 2-1/4-inch Socket Cup Screw | (1) 3/8-inch - 16 x 1-1/4-inch Hex Bolt |
| (1) 3/8-inch x 1-1/4-inch Fender Washer | (1) L-Bracket |
| (2) 3/8-inch x 3/4-inch USS Flat Washer | (1) Foam Bar |
| (2) 3/8-inch Lock Washer | (1) Double Sided Tape |
| (1) 3-inch x 3-inch Wax Square | |

SPECIFICATIONS

Enclosure Type: Acoustic Suspension (sealed)
Driver Type: 10W1v3-2
Nominal Impedance: 2 ohms
Continuous Power Handling: 300 Watts

POWER RECOMMENDATION

JL Audio recommends using a high quality amplifier such as the JL Audio XD300/1v2.
The diagram below shows the recommended crossover settings for the XD300/1v2 when being used to power your Stealthbox®.



The JL Audio XD300/1v2 is a very versatile audio component. Please consult the owner's manual for even more detailed information about installing and tuning this amplifier.

MID/HIGH FREQUENCY DRIVER FITMENT

A variety of JL Audio coaxial and component systems will fit in the factory speaker locations of you vehicle.

Front Speaker Size / Location: 6.5-inch / Front Doors
Fits JL Audio Models: TR650-CXi, C2-650, C2-650x, C3-650, C5-650, & ZR650-CSi

Rear Speaker Size / Location: 6.5-inch / Rear Doors
Fits JL Audio Models: TR650-CXi, C5-650X, & C5-650



JL AUDIO®
Ahead of the Curve™

(954) 443-1100

www.jlaudio.com

All specifications are subject to change without notice. "JL Audio" and the JL Audio logo, "Stealthbox" and the Stealthbox logo are registered trademarks of JL Audio, Inc. "Ahead of the Curve" and its respective logo is a trademark of JL Audio, Inc.
JLA-SKU# 011215 - 09.20.2016 • Printed in USA • ©2016 JL Audio, Inc.
For more detailed information please visit us online at www.jlaudio.com.

