


User Manual



General Information:

Detailed instruction is provided in this manual (the function , safety usage and notices of the charger).

1

Product Overview:

- ▶ The charger could freely charge 1-8 AA/AAA Ni-MH/Ni-CD rechargeable batteries.
- ▶ The charger adopts technology of independent IC control, it could charge the rechargeable battery independently.
- ▶ Equipped 2 USB Port, could simultaneously charge 5V USB e-nable devices like popular smartphones, tablets, camera, mp3, mp4 and so on.

Charger Specification:

- ▶ Input: 100-240V AC 50/60Hz 0.3A Max
- ▶ Output: AA: DC 1.2V 1000mA
AAA: DC 1.2V 500mA
- ▶ USB Output: DC 5V 2A
- ▶ Battery charging rate: ≥85%

Environment Condition:

- ▶ Storage environment: -10 C -50 C; Storage humidity: 45%-85%
- ▶ Using environment: 0 C-35 C; Using humidity: 35%-95%
- ▶ Working temperature of charger and batteries:
- ▶ Surface temperature of charger: 35°C to 55°C
- ▶ Surface temperature of batteries: 25°C to 45°C

Safety Standard:

- ▶ Meet the safety standard of GB/T 191-2000

2

Using Instruction:

- ▶ Connect the power cable firstly before charging.
- ▶ Place the battery into charger carefully, make sure the +/- pole of the battery is match for the +/- pole of the charger.
- ▶ The charger could charge 1-8 AA/AAA Ni-MH Ni-CD rechargeable batteries.
- ▶ The charger has 2 USB port , could freely charge the most popular smartphones and tablets also.
- ▶ The charger's light is red when charging, if charged fully, the charger will automatically turn to trickle charging mode and the light will turn to green.

Notice:

- ▶ The charger could charge 1-8 pieces of AA/AAA Ni-MH/Ni-CD battery, please do not charge other type battery.
- ▶ If the indicator light does not turn on while charging, please checking firstly if the battery is normal and if the installation is correct.
- ▶ New battery will reach the best performance after 2-3 times charge and discharge.
- ▶ Charge the battery to fully if the battery is long time storage and usage firstly.
- ▶ It is normal phenomenon that the battery is warmer than room temperature when charging. The temperature will automatically decrease to normal after fully charged.
- ▶ Using the charger within the temperature between 0°C and 35°C. Cutting off the power supply when you no need to charge the b-

3

attery and take out the battery after fully charged.

- ▶ Children should not use this charger without adult's supervision.

Important Safety Instructions:

- ▶ The charger can only charge for AA/AAA Ni-MH Ni-CD rechargeable battery suitable for audio, Information and technology equipment, it may cause explosion battery broken or leakage, personal injure and damage to property if charging other type of battery.
- ▶ It may cause electric shock hazard if using the charger incorrectly.
- ▶ The charger is using for indoor only, keep it away from moist and heat.
- ▶ Put it into safety place where the children could not reach to.
- ▶ Do not disassemble or reassembly the charger for safety reason.

Size & Weight

Size	19*9.5*2.9 cm (Length*Width*Height)
Weight	193g ±10g

4

FCC Statement

- ▶ This device complies with Part 15 of the FCC Rules.
- ▶ Operation is subject to the following two conditions:
(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.
- ▶ Warning: Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.
- ▶ Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

Warranty

- ▶ We provide 30 days worry-free money back and one year limited warranty.
- ▶ Any problem, please feel free to contact us: service@ebmail.com

5