


Product of

STILLMORE LLC

Proudly Made in the USA 



The ONLY patented tool to cut soft-leg water diverters and sweeps

INSTRUCTIONS:

1. Remove water diverter from bottom of door.
2. Place diverter on the side edge of door for stability while cutting. (Fig. 1)
3. Insert a single edge razor blade at an angle (Fig. 2) into the cutting vent to accommodate your desired cut-off point (less is better to start).
Bottom blade vent is 1/8", each additional vents adds 1/16".
4. Place the raceway (open edge) of the tool onto the diverter leg to be trimmed. (Fig. 3)
5. Keep your thumb firmly on the back edge of the razor blade, slide the tool in a downward motion in the direction of the blade to make your cut. (Fig. 4)
6. Place water diverter back on the bottom of door and swing door – if door still drags, repeat steps 2 & 5. Repeat this process until desired sweep height has been achieved for a perfect seal.

PRO TIPS:

- The SWEEP\$AVER™ was built as a straight-line plane. Use this feature to stay square with the door.
- After each cut use a pick to clear the raceway of any debris.
- Razor should be changed out every two cuts per each end of the blade.

Have a question? View FAQs at STILLMORELLC.com






Fig. 1



Vent Fig. 2



Raceway Fig. 3




Fig. 4

Check out our YouTube channel, STILLMORE LLC for additional tips and extensive tutorial!



STILLMORE LLC offers a lifetime warranty against manufacturer defects. Please register your tool at www.STILLMORELLC.com/pages/product-warranty-registration. STILLMORE LLC is not liable for any incidentals or consequential damages. User expressly assumes the risk and knowledge that single edge razor blades are inherently dangerous if not properly used and if not used accordingly to the instructions set forth herein.