

## IMPORTANT!

### Please Read Instructions Thoroughly Before Using Your RV Cover

**CAUTION:** Do not attempt to put the cover on during strong winds. Do not install with seams facing out. Walk very carefully when on the RV roof to avoid tripping or causing damage. Installation will be easier and safer with a helper. This is highly recommended.

## Prepare for Installation

1. Remove or fold down stationary antennas before installing the cover.
2. Install the gutter spout guards if needed.
3. Place a protective barrier on sharp edges on the RV that could tear the cover.
  - Examples of areas to cover include awning locks, radio antennas, satellite antennas, rain gutters, ladders, etc.
  - Items to use as a protective barrier include towels, foam pads, etc.
4. Both ends of the cover, front and rear are NOT the same and have been labeled to indicate FRONT and REAR.

## Installing Your RV Cover

1. Unfold the cover on the ground in a clean, dry area.
2. Turn the cover inside out and roll it up starting with the rear. Make sure you have the FRONT tag showing at the end of the roll.
3. Climb the ladder while holding onto the FRONT of the RV cover. Request your helper to unroll the cover as you pull it up.
4. After reaching the top of the RV, turn and carefully pull the cover up onto the roof.
5. Carefully pull the front of the cover as you walk to the front of the RV.
6. Toss the front of the cover towards the ground, draping the cover over the RV front.
7. Push the sides of the cover over both sides of the RV, working back to the ladder. (See Fig. 1)
8. As you step down the ladder, install the ladder cover and carefully pull the RV cover down over the rear of the RV.
9. Moving around the sides of the RV, center and adjust the cover. (See Fig. 2)
10. Pull the elastic corners on the bottom edge of the cover down and under the RV.
11. Buckle each strap at the front and rear of the cover and adjust to tighten. Use a ladder as necessary to secure straps.
12. Place a small rock in the throw bag (bag included).
13. Connect the throw bag to a underbelly strap buckle at the bottom of the cover.
14. Toss throw bag with underbelly strap attached under the RV to the other side.
15. Disconnect the throw bag and snap together the mating buckles. (See Fig. 3)
16. Cinch the strap by pulling strap end.
17. Repeat until all the cover underbelly straps are attached.

Fig. 1




Fig. 2





Fig. 3



# Removing Your RV Cover

1. Release the buckles and straps from the underbelly, front, and rear of the RV.
2. Pull elastic bottom corners of the cover loose from the RV.
3. Push the cover up away from the ladder and start climbing up the ladder.
4. Push the rear of the cover in front of you as you go up the ladder.
5. Walk to the front of the RV while grasping the rear of the cover. WATCH YOUR STEP as you move forward!
6. Release the cover from the front of the RV until it all gathers on the ground.
7. Roll or fold the cover up to your preference, so it is easy for you to store or put back in the storage bag.

## Limited Warranty Policy

If there is a problem with your new cover, please do not take it back to the place of purchase. Please call 1-800-334-2004 for warranty assistance.

### WARRANTY REGISTRATION

Obligation of Purchaser. To obtain the benefits of this Warranty, the Purchaser must complete the following steps: (a) fill out online Warranty Registration within 10 days of purchase at [www.camco.net/warranties](http://www.camco.net/warranties); (b) promptly present the defective Product together with the proof of purchase to Camco located at 121 Landmark Drive, Greensboro, NC 27409 and (c) pay all handling, transportation, and shipping charges incurred for the return of the defective Product. Any defective Product returned to Camco shall become the property of Camco.

#### A. One Time Replacement

Any Camco RV Cover which becomes unusable due to a defect in material or workmanship within the allotted months of purchase will be replaced only to the original consumer/purchaser by the manufacturer (Camco Manufacturing). There will be no charge (except for shipping and handling) for this one time replacement.

Note: This is a one-time only replacement policy. If the product has already been replaced once by the manufacturer at no charge, all other warranty replacements will be offered at a prorated cost per the Pro-Rata schedule. Please see Pro-Rata chart for specific information on the replacement schedule for your type of cover.

Detailing/Washing charges, loss of time, inconvenience, or ANY CONSEQUENTIAL DAMAGES do not apply!

#### B. Pro-Rata Schedule

	TIME OWNED	CONSUMER REPLACEMENT COST
RV COVERS	0-12 months	No Cost - Complete Replacement
	13-24 months	50% of Manufacturer's Suggested Retail Price

#### C. Exclusions

Free replacement and Pro-Rata periods do not apply in the following cases:

1. If the cover has been damaged due to a failure to follow directions, neglect or abuse.
2. If the cover fails because of fire, explosion, wreckage, collision, high winds, storm conditions, other forms of extreme weather, acts of God and/or vandalism.
3. If tie downs other than those recommended by the manufacturer are utilized.

4. If no proof of purchase (or copy thereof) can be produced.
5. If the cover was used in an application for which it was not designed.
6. If the cover was not installed per the manufacturer's instructions.
7. If the cover has been altered in any way by a person or commercial entity other than an approved representative of the manufacturer.

#### D. Liability

Camco Manufacturing assumes no liability in the use of their covers. Please check your owner's manual for recommendations on use of covers.

This warranty gives you specific legal rights, and you may also have other rights, which vary from state to state. This is a full statement of warranty terms. No other expressed warranties are made. There are no implied warranties extending beyond the term of the express written warranty stated within. Some states may limit or augment your rights and the warranty time limits stated.

#### How to obtain warranty performance:

1. Call a Camco Manufacturing Warranty Service Representative for a preliminary determination of product performance failure.
2. If cover is determined to be defective, a return number will be issued. This return number must accompany all correspondence regarding the return of the product.
3. Camco Manufacturing must receive the following items before a replacement will be issued.
  - Proof of purchase.
  - Product Identification tag.
  - A photograph or digital picture of the damaged area that contains the defect.
  - Payment for any pro-rata adjustment.
  - Payment for shipping and handling fees.

**CAMCO**

TOP QUALITY PRODUCTS  
121 LANDMARK DRIVE GREENSBORO, NC 27409  
1-800-334-2004 / WWW.CAMCO.NET