


CRAWL SPACE: (BETWEEN JOISTS)

- HELPS PREVENT GROUND MOISTURE FROM CAUSING DRY-ROT
- REDUCES HEAT LOSS TO THE SURROUNDING ENVIRONMENT
- EXCELLENT VAPOR AND RADON BARRIER
- QUICK AND EASY TO INSTALL

INSTALLATION METHOD

1. Using 16" or 24" wide EcoFoil® insulation with staple tabs, staple the material between the joists, 2"-4" below the subfloor.



SUGGESTED PRODUCTS FOR THIS APPLICATION:	
EcoFoil® Insulation Product	EF2222 Series (Available in Various Dimensions)
EcoFoil® Tape	EF15073 (Reflective)

- a) Check local building codes for compliance before installation. This installation sheet is intended solely to illustrate the proper location and placement of EcoFoil® Reflective Insulation products in specific constructions applications. They are not intended to illustrate proper construction methods (which is ultimately the responsibility of the builder or contractor). The installation instructions are only recommendations relating to the location and placement of EcoFoil® Reflective Insulation products and EcoFoil® makes no claims that these construction systems are universally accurate.
- b) All warranties are void if EcoFoil® Reflective Insulation products are used in exterior applications, or in non-enclosed systems or buildings.
- c) Exercise caution when using EcoFoil® Reflective Insulation products near and around electrical wiring and devices.








CRAWL SPACE: (UNDER JOISTS)

- HELPS PREVENT GROUND MOISTURE FROM CAUSING DRY-ROT
- REDUCES HEAT LOSS TO THE SURROUNDING ENVIRONMENT
- EXCELLENT VAPOR AND RADON BARRIER
- QUICK AND EASY TO INSTALL

INSTALLATION METHOD

- 1. Staple one end of EcoFoil* insulation to the Ring Box joist.
- 2. Run the insulation product along the underside of the joists, stapling the product every 4"-6".
- 3. Seal all seams with EcoFoil® tape.



SUGGESTED PRODUCTS FOR THIS APPLICATION:	
EcoFoil® Insulation Product	Solid EFM4800, EF2210, EF2510, EF2220, EF2520 (Available in Various Dimensions)
EcoFoil® Tape	EF15073 (Reflective) or EF15853 (White Poly)

- a) Check local building codes for compliance before installation. This installation sheet is intended solely to illustrate the proper location and placement of EcoFoil® Reflective Insulation products in specific constructions applications. They are not intended to illustrate proper construction methods (which is ultimately the responsibility of the builder or contractor). The installation instructions are only recommendations relating to the location and placement of EcoFoil® Reflective Insulation products and EcoFoil® makes no claims that these construction systems are universally accurate.
- b) All warranties are void if EcoFoil® Reflective Insulation products are used in exterior applications, or in non-enclosed systems or buildings.
- c) Exercise caution when using EcoFoil® Reflective Insulation products near and around electrical wiring and devices.



