

POST FRAME BUILDING ROOF (NEW) (Draped Method)

- IDEAL INSULATION FOR POST FRAME BUILDING APPLICATIONS
- QUICK AND EASY TO INSTALL
- REDUCES HEAT LOSS AND HEAT GAIN ALL YEAR ROUND
- WILL BLOCK UP TO 96% OF RADIANT HEAT TRANSFER

INSTALLATION METHOD

1. Staple the EcoFoil® Insulation to the first truss with at least 5/16" staples.
2. Unroll the product across the trusses, allowing the insulation to sag between the purlins creating a 3/4" air space.
3. Run subsequent EcoFoil® Insulation and butt it up to the previous installed layer
4. Apply EcoFoil® tape to the seams.
5. Attach metal roofing as usual.



SUGGESTED PRODUCTS FOR THIS APPLICATION:

EcoFoil® Insulation Product	EF2210, EF2510, EF2220, EF2520 (Available in Various Dimensions)
EcoFoil® Tape	EF15073 (Reflective), EF15853 (White Poly)

- a) Check local building codes for compliance before installation. This installation sheet is intended solely to illustrate the proper location and placement of EcoFoil® Reflective Insulation products in specific constructions applications. They are not intended to illustrate proper construction methods (which is ultimately the responsibility of the builder or contractor). The installation instructions are only recommendations relating to the location and placement of EcoFoil® Reflective Insulation products and EcoFoil® makes no claims that these construction systems are universally accurate.
- b) All warranties are void if EcoFoil® Reflective Insulation products are used in exterior applications, or in non-enclosed systems or buildings.
- c) Exercise caution when using EcoFoil® Reflective Insulation products near and around electrical wiring and devices.




POST FRAME BUILDING ROOF (NEW) (Furring Method)

- IDEAL INSULATION FOR POST FRAME BUILDING APPLICATIONS
- QUICK AND EASY TO INSTALL
- REDUCES HEAT LOSS AND HEAT GAIN ALL YEAR ROUND
- WILL BLOCK UP TO 96% OF RADIANT HEAT TRANSFER

INSTALLATION METHOD

1. Staple the EcoFoil® Insulation to the first truss with at least 5/16" staples.
2. Unroll the product across the trusses, pull tight and staple.
3. Run subsequent EcoFoil® Insulation and butt it up to the previous installed layer.
4. Apply EcoFoil® tape to the seams.
5. Install purlins over the EcoFoil® insulation. Nail or screw to the trusses through the product.
6. Attach metal roofing as usual.



SUGGESTED PRODUCTS FOR THIS APPLICATION:

EcoFoil® Insulation Product	EF2210, EF2510, EF2220, EF2520
EcoFoil® Tape	EF15073 (Reflective), EF15853 (White Poly)

- a) Check local building codes for compliance before installation. This installation sheet is intended solely to illustrate the proper location and placement of EcoFoil® Reflective Insulation products in specific constructions applications. They are not intended to illustrate proper construction methods (which is ultimately the responsibility of the builder or contractor). The installation instructions are only recommendations relating to the location and placement of EcoFoil® Reflective Insulation products and EcoFoil® makes no claims that these construction systems are universally accurate.
- b) All warranties are void if EcoFoil® Reflective Insulation products are used in exterior applications, or in non-enclosed systems or buildings.
- c) Exercise caution when using EcoFoil® Reflective Insulation products near and around electrical wiring and devices.

