




Skoda Rapid HB Skoda Rapid Spaceback Seat Toledo HB 2013-



- Fitting instructions electric wiring kit tow bar with 13-P socket up to DIN/ISO Norm 11446.
- We would expressly point out that assembly not carried out properly by a competent installer will resultin cancellation of any right to damage compensation, in particular those arising by virtue of the product liability act.
- Contents of these kits and their fitting manuals are subject to alteration without notice, please ensure that these instructions are read and fully understood before commencing installation.


• Do not overload circuits; the maximum loads per connection are detailed in this manual.

- Attention! Before Installation, please read this manual carefully and inform your customer to consult the vehicle owners manual to check for any vehicle modifications required before towing.
- In the event of functional problems, troubleshooting must be limited to about 0.5 hours, contact the technical support:


t.skinner@ecs-electronics.com / 07440 202 052.




Part list





© ECS Electronics B.V. Pag 2 SK-018-D1U / 070116TT







© ECS Electronics B.V. Pag 3 SK-018-D1U / 070116TT







© ECS Electronics B.V. Pag. 4 SK-018-D1U / 070116TT







© ECS Electronics B.V. Pag. 5 SK-018-D1U / 070116TT







© ECS Electronics B.V. Pag. 6 SK-018-D1U / 070116TT













© ECS Electronics B.V. Pag. 7 SK-018-D1U / 070116TT




© ECS Electronics B.V. Pag. 8 SK-018-D1U / 070116TT











© ECS Electronics B.V. Pag. 9 SK-018-D1U / 070116TT















































© ECS Electronics B.V. Pag. 14 SK-018-D1U / 070116TT







© ECS Electronics B.V. Pag. 15 SK-018-D1U / 070116TT

A VAG SERVICE TESTER MUST BE USED TO CODE THE VEHICLE'S GATEWAY WITH THE ADDITIONAL FUNCTION FOR THE TOWING HITCH AT THE DEALER.

27


WARNING! IT MUST BE ENSURED THAT ALL THE REQUIREMENTS OF THE VEHICLE MANUFACTURER FOR CHANGES TO AND RETRO-FITTING ON THE VEHICLE AND/OR COOLING SYSTEM FOR THE OPERATION WITH A TRAILER ARE CARRIED OUT.


SUBJECT TO CHANGE.

28

TEST ALL THE CIRCUITS WITH A TEST DEVICE WITH THE CORRECT POWER LOAD FOR EACH FUNCTION. A TEST DEVICE WITH LED'S CANNOT BE USED FOR

THIS PURPOSE.






31

REINSTALL TRIM.







INFO

SOCKET CONNECTION

	N/ISO	\(\frac{1}{2} \)	⇔ ()≢	<u></u> 1-8	4	-\ৈ	STOP	-\ৈ	Reverse 0	30+	15 P	≟10		≟ 9
	1446	1/L	2	3/31	4/R	5/58-R	6/54	7/58-L	8	9	10	11	12	13
Р	max	21W	2x21W		21W	52W	3x21W	52W	2x21W	180W/15Amp	180W/15Amp			
Co	olour	Black/ White	Blue	Brown	Black/ Green	Grey/ Red	Black/ Red	Grey/ Black	Black	Red	Yellow	Brown		Brown









