



Step 1: Twist the 1st band into a figure 8 on the loom.

Step 2: Add two more bands so there are 3 bands on the loom (the 2nd and 3rd band placed normally).

Step 3: Using the hook, remove the bottom band and pass over so it is resting on top of the bands stretched between 2 pins. Repeat with other side.

Step 4: When placing the next band, take a pony bead and pass the band through before hooking over the pins, allowing the bead to settle between the pins.

Step 5: Loop the bottom band over from the top 2 like previous.

Step 6: Place another band across the 2 pins and repeat the band loop process.

Step 7: Continue in a beaded band then empty band pattern until desired length is reached before finishing with a s-clip.