
## MODEL SPECIFICATIONS

## MODEL SPECIFICATIONS TABLE

Table 1	24"	30"	36"
Main burner Quantity N/P orifice drill size	2 1.82mm / 1.16mm	3 #50 / 1.16mm	3 #49 / #56
Backburner ▲ N/P orifice drill size	#53 / #64	#53 / #64	#52 / #62
Insulating liner model # (not included)*	24-IL-B	30-IL-B	36-IL-B
A Countertop to unit bottom cut-out*	8 1/2"	8 1/2"	8 1/2"
B Side to side non-combustible cut-out*	24 1/2"	30 5/8"	36 7/8"
C Front to back non-combustible cut-out*†	19 1/2"	19 1/2"	19 1/2"
D Control panel width non-combustible cut-out‡	25 1/ <sub>2</sub> "	31 <sup>5</sup> / <sub>8</sub> "	37 7/8"

## ▲ If equipped

<sup>‡</sup> Only applicable for non-combustible enclosures that have countertops with an overhang (see illustration and section below).



## The control panel is designed to sit flush against the enclosure front wall. If the **non-combustible enclosure** countertop extends beyond the front wall, creating a countertop overhang, it must be cut flush with the front wall for the width of the control panel or a gap will be created exposing the forward portions of the left and right side grill fire walls. See illustrations above.

**Important:** FOR YOUR SAFETY, you must provide openings in the island enclosure for drainage, replacement air, and cross-ventilation of any storage area exposed to possible leakage from gas connections, the unit, or propane bottles. See the ENCLOSURE REQUIREMENTS section for details.

<sup>\*</sup> **Note:** If installing this grill in a combustible enclosure, the correct AOG insulating liner must be used. Consult liner instructions for counter cut-out dimensions and installation.

<sup>†</sup> Includes any substrate at front wall of enclosure (in the area the rear of the control panel is to sit flush against). <u>See SUBSTRATE section on next page.</u>