
## **MODEL SPECIFICATIONS (cont.)**

	19-7B Series
A Countertop to unit bottom cutout*	11 <sup>1</sup> / <sub>2</sub> "
<b>B</b> Side to side non-combustible <b>cutout</b> *	19"
C Front to back non-combustible cutout*	18 <sup>3</sup> / <sub>4</sub> "
D Control panel width non-combustible c	utout‡ 20 1/4"
*Note: If installing this unit in a combustible instructions for counter cutout dimensional dimensionada dimensionada dimensionada dimensionada dimens	e enclosure, the correct insulating liner must be used. Consult liner isions and installation.
† Includes any substrate at front wall of enclo See SUBSTRATE section on next page.	osure (in the area the rear of the control panel is to sit flush against).
‡ Only applicable for <u>non-combustible enclosur</u> below).	res that have countertops with an overhang (see illustration and section
Table	3 - Cutout Dimensions
Note: It is highly recommended to build the enclosure with an offset counter height for the power burner installation. See the RECOMMENDED OFFSET INSTALL section on the following page for details.	



## **COUNTERTOP OVERHANG**

The control panel is designed to sit flush against the enclosure front wall. If the enclosure countertop extends beyond the front wall, creating a countertop overhang, it must be cut flush with the front wall for the width of the control panel or a gap will be created exposing the forward portions of the left and right side fire walls of the unit. See illustrations above.

## **ENCLOSURE VENTILATION**

FOR YOUR SAFETY, you must provide openings in the enclosure for replacement air and ventilation (in case of possible leakage from gas connections or propane cylinders). <u>Failure to do so may result in a fire or explosion causing property damage, bodily injury, or death.</u> See the ENCLOSURE / VENTILATION REQUIREMENTS section for details.