

Smart Watch

Operation Instructions





Thank you for choosing our product. Please read the instructions carefully before use.

Start to Use


1. Turn On

- Automatic turn-on after charging



Note: The Watch must be charged and activated before the first use. Please use the original power adapter to charge the watch.

- Turn on by pressing and holding DOWN button.



2. Download and Install Cubitt app



You can directly scan the QR code to download Cubitt app or search "Cubitt app" in the APP store to download and install.

Note: Conditions required by hardware platform system are as below.



iOS 9.0 and above



Android 4.4 and above



Bluetooth 4.2

3. Please connect to mobile phone correctly.



Correct operation: Pair the Watch via the Cubitt App on your phone.




Wrong operation: Pair the Watch directly via Bluetooth in phone Settings.




4. Bind the Watch

Drop down on APP home to show binding request. Select product model, and tap “Confirm Binding” to complete binding.



Operation Instructions




1. Key Instructions

UP button	Press	In screen locked state : Unlock screen
		Sibling interface: circularly flip
		Pop-up interface: confirm
		During stopwatch/timer working: pause/continue
		During sports paused: continue sport
	Press and hold	During sports: pause sports
Other interfaces: quickly launch sports		
DOWN button	Press	In screen locked state : Unlock screen
		During sports paused: stop sports
		Pop-up interface: Cancel/Close
		During stopwatch working: count
		During timer working: stop timekeeping and quit
	Other interfaces: return to previous interface/dial	
Press and hold	Turn on/Turn off	


2. Operation on Screen

Screen	Tap	Select to enter the next interface/select current item.
	Tap and hold	Tap and hold in the main dial interface to enter dial switching interface.
	Slide left /right	Switch interfaces left and right.
	Slide up /down	Switch interfaces up and down.

3. Operation of Gestures



Raise to turn on backlight.



Hang to turn off backlight.

Note: ON/OFF of this function can be set up through mobile APP.

Introductions to Sports Functions

1. Activate Sports




Enter Sports list interface, slide up or down to select sports item, and tap icon to start sports.

2. Start Sports




When Sports is activated, the Watch will show sports countdown. Sports starts after the countdown.

3. Operations during Sports



In screen locked state



In screen unlocked state

4. Reminders during Sports

Heart rate reminder

During sports, the Watch will continuously detect current heart rate. If current heart rate exceeds the maximum heart rate, the Watch will remind to reduce sports intensity or stop sports through vibration and interface alarm.


Set your safe heart rate reminder through More>Heart rate zone>User defined Max. heart rate in the mobile APP.

5. Pause or Stop Sports

Pause sports:

In the unlocked state, press and hold UP button to pause sports. Tap Continue icon to resume sports.

In the paused state, slide up to view current sports data.



Stop sports

In the paused state, select STOP to stop sports.

After sports, the Watch will keep details of the sports. View in sports records.

Instructions to Other Functions

1. Health Data



Enter Health Data interface to view the accumulated steps, calories and distances when wearing the Watch that day.

2. Notifications

Turn on smart reminder

When it is in use, you need to turn on “Smart Reminder” on the APP end, select and turn on notification types to be reminded, and this function requires keeping the connection between the Watch and mobile phone.

View message


When receiving message, the Watch will vibrate to remind. If the message is not immediately viewed after being received, slide down to view the message.

Delete message

The Watch can save the most recent 12 notifications. Beyond the limit, the earliest notice will be automatically deleted once a new notice is received. When the notification content exceeds one screen, it will be displayed continuously on the second screen.

- On the message list view interface, slide left single message box to show Delete icon, and tap Delete icon to delete the message.

- Slide down to the top of message list, and tap Clear icon to clear all messages.



3. Heart Rate



The Watch supports heart rate detection. Slide to Heart Rate Detection interface, hold for two seconds, the Watch will automatically detect heart rate. Please stand still during the detection, so that the Watch can output more accurate heart rate data.

Note: To improve the accuracy of heart rate detection, please wear the Watch correctly and keep the wearing parts clean.

4. Weather



Weather function allows you keep track of the weather in your city. Because weather data is obtained through mobile phone network, it is required to maintain the connection between the Watch and the phone to timely update weather data.

5. More Functions

Stopwatch

It is available to record multiple times.

Timer

It is available to set count-down. Remind through vibration after count-down is over.

Alarm clock

Set alarm clocks in mobile APP.

When it is the set time, the Watch will remind through vibration.



In case of no operation after 20s, the alarm clock will automatically stop. After 5 minutes, the alarm clock will remind again. Press UP/DOWN button to pause the alarm, and after 5 minutes the alarm clock will remind again.

Call reminder





Call Reminder can be set in mobile APP. When it is in use, turn on Call Reminder function in mobile APP, and keep the connection between the Watch and the phone. When there is an incoming call, the Watch will remind through vibration. Close the call pop-up by pressing UP/DOWN button.

6. Control Center


DND mode

Slide up once on dial interface, and enter control center interface. Tap DND icon  to lighten the icon . DND mode is on. Tap DND icon again to dim the icon. DND mode is off.

Brightness adjustment

Slide up once on dial interface, and enter control center interface. Brightness level is defaulted as Level 2 . Tap the brightness icon to switch it to Level 3 . Tap the icon again to switch it to Level 1 . Tap the icon again to switch it to Level 2 . Conduct repeatedly in order.

System settings

Slide up once on dial interface, and enter control center interface, and tap System Setting icon  to enter system settings.

In system settings, you can enter:

- Dial settings: tap and enter this function to switch dials among different styles.
- Pressing and holding UP button settings: tap and enter this function to set sports style entered by pressing and holding UP button.
- Factory data reset settings: tap to enter factory data reset procedure.
- Firmware information: tap and enter to view firmware information and Bluetooth address.

Product Specifications

Product model	CT3	Screen model	1.3"TFT-LCD (round)
Battery capacity	260mAh	Working voltage	3.8V
Charging time	≤2 hours, 25 °C constant temperature	Battery duration	7 days (Battery life depends on how you use it.)
Waterproofing grade	5ATM	Bluetooth version	BLE4.2
Working temperature	-10 °C-45 °C	Product weight	56.1g
Product frequency	2402-2480MHz	Max. transmission power consumption	0 dBm

Waterproofing: Use of the Watch at the time of hand washing, raining and swimming in shallow water is supported, but use under hot shower, diving, underwater diving, surfing etc. is unsupported.

Care Instructions



Replace watch strap



Please use a soft brush or clean soft cloth to clean the Watch.

- Please stop using the Watch and disconnect all connections with other equipment before cleaning and maintenance.
- Please keep the Watch and its accessories dry. Do not dry them with external heating equipment such as microwave oven or hair dryer.
- Do not place the Watch and its accessories in an area where the temperature is too high or too low, which may cause malfunction, fire or explosion.
- Avoid strong shock or vibration to prevent damage to the Watch and its accessories or failure.
- Please do not disassemble or modify the Watch and its accessories without permission. In case of failure, please contact after-sales service.



FAQ

- **Mobile phone cannot be connected to the Watch.**

1. It is recommended to update Cubitt app to the latest version.
2. It is recommended to quit all APPs, reactivate the phone Bluetooth and re-connect.
3. Confirm that system of the phone is Android 4.4 or iOS 9.0 and above.


- **The Watch has no message or call reminders.**

1. It is required to turn on smart reminder function and call reminder function in APP and synchronize to the Watch.
2. The Watch should be paired with mobile phone through Bluetooth.
3. It is required to keep Watch Bluetooth under normal connection.

●Bluetooth disconnects frequently.

1. Relatively long distance between the Watch and the phone may cause Bluetooth disconnection, and the effect of Bluetooth connection over 7 meters will be obviously weak.
2. Shielding between the Watch and the phone will affect the connection, and human body and metal jewelry will interfere Bluetooth connection signal.
3. Please confirm that Bluetooth function of the phone is normal.

●More detailed FAQs can be obtained through help and feedback in the APP.

Operating steps: Cubitt app >  > FAQ

Safety and Product Information Notes



Battery warning

Do not disassemble, bore or damage the battery. Do not disassemble the built-in batteries of non-replaceable battery devices. Do not use sharp objects to remove the battery.

Health Warning

If you are wearing a pacemaker or other implanted electronic devices, please consult your doctor before using the heart rate monitoring strap.

The watch's optical heart rate sensor glows green and flashes. If you suffer from epilepsy or are sensitive to blinking light sources, please consult your physician if you can wear this product.

The device tracks your daily activities through sensors. These data are intended to tell you about your daily activities, such as steps, sleep, distance, heart rate and calories, but may not be completely accurate.

The device, accessories, heart rate sensors and other relevant data are designed for entertainment and fitness, not for medical purposes. They are not applicable to the diagnosis, monitoring, treatment or prevention of any diseases or symptoms. The heart rate data is for reference only. We are not responsible for any consequences caused by any data deviation.

Cycling Warning

If you are wearing a pacemaker or other implanted electronic devices, please consult your doctor before using the heart rate monitoring strap.

Notes:

- Device data should be synchronized once every seven days to avoid data loss.
- The device has no waterproof effect on seawater, acidic and alkaline solution, chemical reagent and other corrosive liquids. The damage or defect caused by misuse or improper use is beyond the warranty scope.
- The device supports the use under cold shower or swimming excluding diving.

- In daily use, the device should be avoided from wearing too tight. Please keep the parts where the device touches the skin dry.
- During heart rate detection, please keep your arm stand still.



The device meets the EU ROHS criterion. Please refer to IEC 62321, EU ROHS Directive 2011/65/EU and revised directive.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) this device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

CAUTION

RISK OF EXPLOSION IF BATTERY IS REPLACED

BY AN INCORRECT TYPE

DISPOSE OF USED BATTERIES ACCORDING
TO THE INSTRUCTIONS



Old electrical appliances must not be disposed of together with the residual waste, but have to be disposed of separately. The disposal at the communal collecting point via private persons is for free. The owner of old appliances is responsible to bring the appliances to these collecting points or to similar collection points. With this little personal effort, you contribute to recycle valuable raw materials and the treatment of toxic substances.



Scan here to download
Cubitt App

