


# CHRONOMASTER


## MANUAL WINDING

INSTRUCTION MANUAL

# CHRONOMASTER MANUAL Watch parts



# CHRONOMASTER MANUAL Crown Position



**1** Manual winding

**2** Setting the time

# CHRONOMASTER MANUAL Manual winding



## 1 Manual winding

Turn the crown clockwise. As you're winding your watch, you will feel a slight resistance which increases as the tension mounts.

Depending on the size of the watch, 20 to 30 forward turns should lead to resistance

★ *Purely manually wound movements require winding at regular intervals, normally on a daily basis, to keep operating. Take care to stop winding this type of movement at the first sign of resistance as damage may result from over winding.*

# CHRONOMASTER MANUAL Setting the time



1. **1** Crown out to the **2** position
2. Turn the crown to set hour and minute hands
3. Push back to **1** position

# CHRONOMASTER MANUAL Using the chronograph



**THIS MODEL CHRONOGRAPH FEATURES STOPWATCH THAT CAN MEASURE UP TO 60 MINUTES.**

- 1. To start the chronograph: Press the upper pusher A**  
The chronograph hands will begin to move.
- 2. To stop the chronograph: Press the upper pusher A again.**  
The chronograph hands will stop and indicate the elapsed time.  
(Read the elapsed seconds on the large central hand and minutes on the sub-dial in the 3 o'clock position).
- 3. To reset the chronograph: Press the lower pusher B to reset the chronograph.** All the chronograph hands will be reset to "0" position.

*Nivada  
Grenchen*