

**SOLD
SECURE**



**APPROVED
PRODUCT**

RECOMMENDED FITTING INSTRUCTIONS

GARAGE DEFENDER

FOR UP AND OVER GARAGE DOORS

PLEASE NOTE:

**THE UNIT MUST BE RAWLBOLTED
INTO GOOD SOLID CONCRETE.**

**LUBRICATE LOCKING MECHANISM & SLIDE BOLT
AT REGULAR INTERVALS**


**SOLD
SECURE**



**APPROVED
PRODUCT**

STAGE:

1. Important Note: Position unit in front of garage door ensuring the door swings clear of the padlock lug before permanently fixing in position as in diagram A.
2. Using the base plate as a template drill through the two holes with a 10mm dia concrete drill 10mm deep.
3. Remove the base plate, then re-drill the two holes with a 16mm dia concrete drill 90mm deep.
4. Clear dust from prepared holes in concrete.
5. Drop both security bolts into the base plate and screw on both shields until they just touch the underside of the base plate.
6. Tap base plate down into the prepared holes until the base plate sits flush on the concrete base.
7. Tighten the two security bolts evenly to a torque of 25-30lbs.
8. Please note the external security fixing bolt may require a concrete pad if you have tarmac outside the garage door.



Please note: Only two security fixing points are required-should base plate NOT fit under garage door, follow option 1 or 2 as below.

1. Rebate base plate 5mm into concrete floor.
2. Cut off back section of base plate.