



ثلاجة (ثلاث أبواب) دليل المستخدم

الموديل:

RFHA-FD710NDS [^]

Refrigerator (French Door) User's Manual

Model:

[^] RFHA-FD710NDS

الرجاء قراءة هذا الدليل بعناية قبل تشغيل الجهاز،
و احتفظ به للرجوع إليه مستقبلاً.

هذه التصاميم و المواصفات عرضة للتغيير بهدف إدخال تحسينات عليها
و ذلك دون إشعار مسبق.

ISO9001 CB

Please read this manual carefully before operating your set.
Retain it for future reference.

Designs and specifications are subject to change for improvement
without prior notice.

ISO9001 CB



Model: RFHA-FD710NDS

Contents

Brief introduction.....	2	Helpful hints and tips.....	14
Important safety instructions.....	2	Cleaning and care.....	15
Installing your new appliance.....	5	Troubleshooting.....	16
Description of the appliance.....	7	Before requesting service.....	17
Display controls.....	8	Disposal of the appliance.....	18
Using your appliance.....	10		

Brief introduction

Thank you for your choosing Hisense products. We are sure you will find the new appliance a pleasure to use. Before you start using the appliance, we recommend that you read through this User Manual carefully, which provides description of the refrigerator functions and its usage in more details.

- Please ensure that all people who are using this appliance are familiar with its operations and safety features recommended in this User Manual. It is important that you install the appliance correctly and follow the safety instructions.
- We recommend that you keep this user's manual with the appliance for future reference and retain it for future users.

- This appliance is intended to be used in household and similar applications such as:
 - Kitchen area in shops, offices and other working environments;
 - Farmhouses, hotels, motels and Bed and breakfast and other residential types of environment;
 - Catering and similar non-retail applications.
- If you feel that the appliance is not operating correctly, please refer to the troubleshooting page for most common problem. If still in doubt contact the customer service help line for assistance or to arrange a call out by an authorized service engineer.

Important safety instructions

General safety and daily use



It is important to use your appliance safely. We recommend that you follow the guidelines below.

- We recommend that you wait for 4 hours before connecting the appliance to main plug to allow the refrigerant to flow back into the compressor. It is also recommend that you let the fridge run for 3 hours before storing any food inside.

- The packaging material is recyclable, and marked with the recycling symbol ♻️. Adhere to current local regulations when disposing of packaging material.
- Do not use sharp-edge object or metal instrument to remove the frost and ice, or any frozen items from the freezer. This might damage the tubing of the refrigerant circuit and create leakage and risk of fire.
- Don't try to repair the appliance yourself. It

is dangerous to alter the specifications or modify this product in any way. Any damage to the power cord may cause short circuit, fire or electric shock.

- Store any food in accordance with the storage instructions from the manufacturer.
- Don't place a large amount of food directly against the air outlet on the rear wall of both the refrigerator and freezer compartment, as it obstructs air circulation.
- Don't place hot items near the plastic components of this appliance.
- Frozen food must not be refrozen once it has been thawed out.
- Don't store bottled or canned drinks (especially carbonated drinks) in the freezer compartment. Bottles and cans may explode.
- Any type of pressurised aerosol containers with the "flammable" and or small flame symbol should not be stored inside the refrigerator or freezer since it may cause an explosion.
- Don't consume ice popsicles or ice cubes straight from the freezer as this can cause frost burn to the mouth and lips.
- To avoid items falling and causing injury or damage to the appliance, don't overload the door racks or store a large amount of food in the crisper drawers.
- Do not touch frozen items when your hands are wet. Your hands could freeze to the items and cause the frost burn.
- Don't use mechanical devices or other means to accelerate the defrosting process, unless they are approved by the manufacturer.
- If the supply cord is damaged, it must be replaced by the manufacturer, its service agent or similarly qualified persons in order to avoid a hazard.
- When disposing of the appliance, do so only at an authorized waste disposal center. Don't expose to flame.

Safety for children and infirm persons



This appliance can be used by children aged from 8 years and above and persons with educed physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved. Children shall not play with the appliance. Cleaning and user maintenance shall not be made by children without supervision.

- Keep all packaging away from children to avoid risk of suffocation.
- Protect children from being scalded by touching the very hot compressor at the rear bottom of appliance.
- Don't place items on top of the appliance as this could cause injury should they fall off.
- Never allow children to play with the appliance by hanging or standing over or on the doors, racks, shelves and drawers etc.

Safety about electricity



To avoid the risks that are always present when using an electric appliance, we recommend that you pay attention to the instructions about electricity below.

- We recommend after you unpack the appliance and check through the appliance. Should any damage be evident, don't plug in the appliance but contact the shop immediately from which you purchased it. Keep all packing materials in this case.
- The appliance must be applied with single phase alternating current of 220~240V/50Hz.
- The mains plug must be accessible when the appliance is installed.
- Make sure that the appliance is grounded properly. If still in doubt, call a qualified registered electrician.
- If the fitted plug is not suitable for your socket outlets, it should be cut off and carefully disposed of. To avoid a possible

shock hazard, do not insert the discarded plug into a socket. If in doubt contact a qualified, registered electrician.

- Do not use extension cords or multiple sockets which could cause overloading of wiring circuits and could cause a fire.
- Always plug your appliance into its own individual electrical socket which has a voltage rating that matched the rating plate.
- Make sure that the plug is not squashed or damaged. Otherwise, it may cause short circuit, electric shock or overheat and even cause a fire.
- Don't insert the mains plug if the socket is loose, there is a risk of electric shock or fire.
- Switch off the appliance and disconnect it from the mains power before you clean or move it.
- Never unplug the appliance by pulling on the electrical cord. Always grip the plug firmly and pull straight out from the socket to prevent damaging the power cord.
- Don't use the appliance without the light cover of interior lighting.
- Any electrical component must be replaced or repaired by a qualified electrician or authorized service engineer. Only genuine spares should be used.
- Don't use electrical appliances (such as

ice cream makers) inside the food storage compartments of the appliance, unless they are approved by the manufacturer.

- If the LED light uncovered, do not look direct into with an optical instruments to avoid eye injuries. If it is not functioning correctly, consult a qualified, registered electrician.

The refrigerant and risk of fire

The appliance contains a small quantity of refrigerant (**R600a**) in the refrigerant circuit.

- The iso-butane (**R600a**) refrigerant, is environmentally friendly but flammable, ensure that tubing of the refrigerant circuit is not damaged during transportation and installation to avoid risk of fire caused by leaking refrigerant.

Caution!




- Keep away burning candles, lamps and other items with naked flames and sources of ignition from the appliance and ventilate the room thoroughly to avoid the risk of fire and eye injury in the case of any leakage of refrigerant (R600a).
- Do not store products which contain flammable propellants (e.g. spray cans) or explosive substances in the appliance.

Installing your new appliance

This section explains the installation of the new appliance before using it for the first time. We recommend reading the following tips.



For proper installation, this refrigerator must be placed on a level surface of hard material that is the same height as the rest of the flooring. This surface should be strong enough to support a fully loaded refrigerator, or approximately 266 lbs. (120 kg). When moving, be sure to pull out and push back the unit in straight.



Location and ambient room temperature limits

It's essential to find a suitable place to locate your new appliance to ensure its efficient operation. Please consider the following instruction for your appliance:


- Install the appliance in a dry and low moisture area. The best range of ambient temperature for appliance is 10°C~43°C.
- Keep the appliance away from heat sources, such as stoves, fires places or heaters.
- Keep the appliance out of direct sunlight, and rain.

Class	Symbol	Ambient Temperature range(°C)
Extended Temperate	SN	+10 to +32
Temperate	N	+16 to +32
Subtropical	ST	+16 to +38
Tropical	T	+16 to +43

Leveling of appliance

For proper leveling and avoid vibration, this appliance is provided with adjustable feet in front. Please adjust the level by following below instructions:


1. Roll the refrigerator into place.
2. Turn the adjustable feet (with your fingers or a suitable spanner) until they touch the floor.
3. Tilt back the top backwards for about 10-15 mm by turning the feet 1~2 turn further. This will allow the doors to self-close and seal properly.
4. Whenever you want to move the appliance, remember to turn the feet back up so that the appliance can roll freely. Reinstall the appliance when relocating.



Warning: The rollers, which are not castors, should be only used for forward or backward movement. Moving the refrigerator sideways may damage your floor and the rollers.


Adjusting the door handle

Before you use the appliance, please check the refrigerator handles. If the handles are loose, please adjust them by using an Allen wrench in the clockwise direction until handles are securely in place. Each one of the handles is fitted with 2 screws.




Adjusting the doors

- Both left and right doors are equipped with adjustable axes, which are located in the lower hinges.
- Before adjusting its doors, please ensure that the refrigerator is level. Please review the previous section on "Leveling appliance". If you find the top of the doors are uneven, insert the Allen wrench into the hinge axis, and turn it clockwise to rise the door or anticlockwise to lower the door, and insert an E Ring into the gap.




Ventilation of appliance

In order to improve efficiency of the cooling system and save energy, it is necessary to maintain proper ventilation around the appliance for heat dissipation. For this reason, sufficient space should be provided around the refrigerator and the area should be clear of any obstruction that affects the air circulation.




Suggestion: It is advisable leaving at least 75mm of clearance from the back of appliance to the wall, and at least 100mm from top, and on both sides. When positioned in a corner area, provide a clear space at least 406mm on the each hinge side to allow the doors to open enough to enable the removal of drawers and shelves. As shown in the following diagram.




Description of the appliance

- 1 Cabinet
- 2 Top cover
- 3 Vertical baffle guide block
- 4 Glass shelf
- 5 Water storage box
- 6 Flexible pop can rack
- 7 Fruit and vegetables crisper
- 8 Vertical baffle part
- 9 My fresh choice
- 10 Twistable ice tray (inside)
- 11 Serving tray
- 12 Rollers
- 13 Adjustable bottom feet
- 14 Lower freezer drawer
- 15 Upper freezer drawer
- 16 Freezer LED light (inside)
- 17 Refrigerator door seal
- 18 Lower rack
- 19 Crisper cover
- 20 Upper rack
- 21 Egg tray (inside)
- 22 Rack cover
- 23 Refrigerator LED light (inside)
- 24 Display board
- 25 Cold water dispenser
- 26 Handles
- 27 Freezer door
- 28 Refrigerator door

View 1 of the appliance



View 2 of the appliance



Note: Due to constant improvement of our products, your refrigerator may be slightly different from the above illustration, but its functions and using methods remain the same.

Note: To get the best energy efficiency of this product, please place all shelves, drawers and baskets on their original position as the illustration above.

Display controls

All functions and controls of the unit are accessible from a control panel conveniently located on the door of the refrigerator. A keypad of touch buttons and a digital display allow easy configuration of features and settings in a simple and intuitive manner.

Important! Touch buttons require only a short press on a button to operate. The operation occurs when releasing your finger from the button, not while the button is pressed. There is no need for applying pressure on the keypad.

Child Lock function related to the "Alarm" button requires a long touch of at least 3 sec.

Please refer to those related sections of this Manual for detailed instructions.

The control panel consists of two indicating temperature areas, five icons representing different modes and six touch buttons. When the appliance is powered on for the first time, the backlight of the icons on display panel turns on. If no buttons have been pressed and the doors remains closed, the backlight will turn off after 60 sec.



Controlling the temperature

We recommend that when you start your refrigerator for the first time, the temperature for the refrigerator is set to 5°C and the freezer to -18°C. If you want to change the temperature, follow the instructions below.


Caution!

When you set a temperature, you set an average temperature for the whole refrigerator cabinet. Temperatures inside each compartment may vary from the temperature values displayed on the panel, depending on how much food you store and where you place them. Ambient temperature may also affect the actual temperature inside the appliance.

1. Fridge

Press "Fridge" button repeatedly to set your desired fridge temperature between 8°C and 2°C, the temperature will increase 1°C degrees with each press and the fridge temperature indicator will

display corresponding value according to the following sequence.



2. Super Cool

Super Cool Super Cool can refrigerate the food quicker and keep food fresh for a longer period.

● Press "Super Cool" button to activate this function. The Super Cool icon will light up and the Fridge temperature indicator will display 2°C.


Super cool automatically switches off after 6 hours.

● Press "Super Cool" or "Fridge" to cancel super cool mode and revert to previous temperature settings.

3. Freezer

Press "Freezer" button to set the freezer temperature between -14°C and -24°C to suit your desired temperature, and the

freezer temperature indicator will display corresponding value according to the following sequence.



4. Super Freeze



Super Freeze can rapidly lower frozen temperature and freeze your food substantially faster than usual. This feature also helps to keep the vitamins and nutrition of fresh food for longer period.

● Press "Super Freeze" button to activate the super freeze function. The Super Freeze light will be illuminated and the freezer temperature setting will display -24°C.


● For first time use, or after a period of inactivity, allow 6 hours of normal operation before using Super Freeze mode. This is particularly important if a large amount of food is placed in the freezer.

● Super freeze automatically switches off after 26 hours of usage and the freezer temperature goes to below -20°C.

● Press "Super Freeze" or "Freezer" to cancel Super Freeze mode and revert to previous temperature settings.

Note: When selecting the Super Freeze function, ensure there are no bottled or canned drinks (especially carbonated drinks) in the freezer compartment. Bottles and cans may explode.

5. Holiday



This function is designed to minimise the energy consumption and electricity bills while the Fridge is not in use for a long period of time. You can activate this function by pressing "Holiday" button for a short until the Holiday light icon is illuminated.

Important! Do not store any food in the refrigerator chamber during this time.

● When the holiday function is activated, the temperature of the refrigerator is automatically switched to 15°C to minimise the energy consumption. The refrigerator temperature setting displays "-" and the freezer compartment remains on.

● Press "Holiday" button to cancel Holiday mode and revert to previous temperature settings.

6. Alarm



In case of alarm, "Alarm" icon will light up and a buzzing sound will start.

Press "Alarm" button to stop alarm and buzzing then "Alarm" icon will turn off.

Caution! When the refrigerator is turned on after a period of inactivity, the Alarm may be activated. In this case, press "Alarm" button to cancel it.

Door Alarm

The alarm light on and a buzzing sound indicate abnormal conditions, such as accidentally a door left open or that a power interruption to the unit has occurred.

● Leaving any door of refrigerator or freezer open for over 2 minutes will activate a door alarm and buzzer. The buzzer will beep 3 times per minute for 10 minutes. Closing the door cancels the door alarm and buzzer.

● To save energy, please avoid keeping doors open for a long time when using refrigerator. The door alarm can also be cleared by closing the doors.

Temperature alarm

This is an important feature that alerts users of potential damage to stored food. If a power failure occurs, for example a blackout in your area of residence while you are away, the temperature alarm will memorize the temperature of the freezer when power was restored to the unit; this is likely to be the maximum temperature reached by frozen items.

A temperature alarm condition will be indicated by Alarm light and buzzer when the temperature reading is warmer than -9°C, then

- The Alarm icon lights up;
- The freezer temperature indicator displays "H";
- The buzzer beeping 10 times when the alarm is triggered and stop automatically.

Using your appliance

This section explains that how to use the refrigerator features. We recommend that you read through carefully before using the appliance.

Cold water dispenser

The cold water dispenser, located in the left refrigerator door, is used for storing drinking water. This feature provides chilled water easily without opening the door.

● Cleaning

Please clean the water dispenser before using it for the first time.

1. Put the water container out of the door carefully, and then wash the container, lids, and head lightly with water.

2. After you have cleaned the water dispenser, dry it in a natural way or using dry cloths.

● Assembling

Please refer to the following instruction to reassemble the dispenser.

- Hold tightly both sides of the water container then lift it up and put it out from the door.
- Unscrew the head in counterclockwise direction.
- Insert them back on the door and push the container until you hear a click sound.


Child Lock



Press and hold the "Alarm" button for 3 seconds to activate the child lock.

This will disable the display to prevent accidental changes to settings. Meanwhile, the "Child Lock" icon will be illuminated.

● To turn the child lock off, press and hold the "Alarm" button for 3 seconds. The "Child Lock" icon will be turned off.



Warning !

When inserting the water container, ensure the head sits correctly into the hole first.

Filling water


Before you fill the drinking water into the water container, ensure that the water container is steady and placed into a correct position.

To prevent water from overflowing and spilling, fill the water container below the maximum level mark which is approximately about 4.0L. There are two ways to fill the water container:

- By removing the small lid and fill water from the inlet of the large lid.
- By removing the large lid of the tank, and then fill water directly.

Caution!

Do not fill any other liquid than water inside the water container.



●Lock

Before you dispense the water, ensure that the dispenser is in "unlock" position.

Warning


The lock feature is used to lock the device. Don't push strongly the dispenser lever when the dispenser is in "lock" position, this may damage and break the dispenser.

●Using water dispenser

You should use a suitable cup size to fill the water underneath the water dispenser.

Warning! Don't pull the dispenser lever out without a cup underneath; this may cause the water leak from the dispenser.

Keep the water supply device installed when the water dispenser is out of use to prevent cold air leakage.




Note: Frequently usage of the water dispenser could spill drops on the tray which may overflow. Dry the tray with a towel as required.

Door rack

The refrigerator chamber is fitted with door racks suitable for storing canned liquid, bottled drinks and packed food. Do not place a large amount of heavy food and items inside door racks.


●The middle door rack is designed to adjust at different heights according to your requirements. Please empty the rack before lifting upward to remove it. Then reposition the rack at the desired height.

Note: There is an egg tray provided that should be located in the upper rack.




Pop can rack

●This rack stores up to 4 cans of standard size, but it is not suitable for cans with diameter smaller than 50mm. The rack also can rotate 25° along the shelf if required, to facilitate storing or taking drinks.




Glass shelves


The refrigerator chamber is provided with two glass shelves. While the top shelf is designed to be fixed, the lower shelf is adjustable. There are three placements for relocating the lower shelf. Adjust the height of the shelf according to your need:



- When removing the shelves, gently pull them forward until they exit the guides.
- When you return the shelves, make sure there is no obstacle behind and gently push them into the position.



Crisper and humidity control



The crisper, mounted on telescopic extension slides, is for storing vegetables and fruits. You can adjust the humidity inside by using the sliding block.


●The humidity control adjusts the airflow in the crisper; higher airflow results in lower humidity. Slide the humidity control to the right in order to increase humidity.

●High humidity settings are recommended for vegetables, while low humidity is suitable for preservation of fruit.

●Follow these simple instructions to remove the crisper chamber, or freezer drawer, for cleaning. Empty the crisper chamber; pull it out to fully open position. Lift the crisper from the lateral slides. Push the slides fully in to avoid damage when closing the door.

My Fresh Choice. Precision control of temperature (Optional)

Food can be preserved fresh for longer periods when stored at their optimal temperature, but different types of food require different storage temperatures. There is a chill drawer display on the right of the drawer. The temperature of the compartment can be set at 0°C, 3°C, and 5°C to suit either meat, or fruits and vegetables, or deli products respectively by using "My Fresh Choice" buttons. Please refer to the table below for the recommended settings to suit your storage needs.



<i>Deli</i> [5°C]	<i>Vege.</i> [3°C]	<i>0°C</i> [0°C]
<i>Cheese</i>	<i>Cucumber</i>	<i>Steaks</i>
<i>Ham</i>	<i>Lettuce</i>	<i>Fish</i>
<i>Salami</i>	<i>Oranges</i>	<i>Cold cuts</i>
<i>Olives</i>	<i>Corn</i>	<i>Poultry</i>

Using the refrigerator chamber

The refrigerator chamber is suitable for storage of vegetable and fruits. Separate packing of different foods is recommended to avoid losing moisture or flavour permeating into other foods.


Caution!

Never close doors while the shelves, crisper and/or telescopic slides are extended. It may damage the unit.

Using the freezer drawer

Freezer drawer is suitable for storing food required to be frozen, such as meat, ice cream, etc.

To remove the freezer drawer pull it out fully, tilt up the serving tray and lift it out, then open the refrigerator doors to the maximum angle and the lower freezer drawer can be taken out, as shown in the following pictures.




Caution

Do not allow babies or children go inside the refrigerator, as they could injure themselves or damage the refrigerator. Do not sit on the freezer door. The door may break. Do not allow children to climb into the freezer basket.

If you remove the divider to clean the basket bin, you must reinstall the divider after cleaning to prevent children from getting trapped inside the basket.

Twistable ice tray

- Twistable ice tray is placed in the upper freezer drawer to make and store ice cubes.
1. Pull out the twistable ice tray from the installation bracket.
 2. Fill with drinking water below the maximum level mark.
 3. Place the filled ice tray back to the bracket.
 4. Await for around 3 hours, twist the knobs clockwise and the ice will drop into the ice box below.



5. Ice cubes can be stored in the ice box, if you need them, you can pull out the ice box and take them out.

Note: If the ice tray is used for the first time or has not been used for a long time, please clean it before using.

Helpful hints and tips

Energy saving tips

We recommend that you follow the tips below to save energy.

- Try to avoid keeping the door open for long periods in order to conserve energy.
- Ensure the appliance is away from any sources of heat (Direct sunlight, electric oven or cooker etc).
- Don't set the temperature colder than necessary.
- Don't store warm food or evaporating liquid in the appliance.
- Place the appliance in a well ventilated, humidity free, room. Please refer to Installing your new appliance chapter.
- View 1 under the "Description of the appliance" section shows the correct arrangement for the drawers, crisper and shelves, do not adjust the combination as this is designed to be the most energy efficient configuration.

Hints for fresh food refrigeration

- Do not place hot food directly into the refrigerator or freezer, the internal temperature will increase resulting in the compressor having to work harder and will consume more energy.
- Do cover or wrap the food, particularly if it has a strong flavor.
- Place food properly so that air can circulate freely around it.

Hints for refrigeration

- Meat (All Types) Wrap in polythene food wrap and place on the glass shelf above the vegetable drawer. Always follow food storage times and use by dates suggested by manufacturers.
- Cooked food, cold dishes, etc.: They should be covered and may be placed on any shelf.
- Fruit and vegetables: They should be stored in the special drawer provided.
- Butter and cheese:

Should be wrapped in airtight foil or plastic film wrap.

● Milk bottles:

Should have a lid and be stored in the door racks.

Hints for freezing

- When first starting-up or after a period out of use, let the appliance run at least 2 hours on the higher settings before putting food in the compartment.
- Prepare food in small portions to enable it to be rapidly and completely frozen and to make it possible to subsequently thaw only the quantity required.
- Wrap up the food in aluminum foil or polyethylene food wraps which are airtight.
- Do not allow fresh, unfrozen food to touch the food which is already frozen to avoid temperature rise of the latter.
- Iced products, if consumed immediately after removal from the freezer compartment, will probably cause frost burns to the skin.
- It is recommended to label and date each frozen package in order to keep track of the storage time.

Hints for the storage of frozen food

- Ensure that frozen food has been stored correctly by the food retailer
- Once defrosted, food will deteriorate rapidly and should not be re-frozen. Do not exceed the storage period indicated by the food manufacturer.

Switching off your appliance

If the appliance needs to be switched off for an extended period, the following steps should be taken to prevent mould on the appliance.

1. Remove all food.
2. Remove the power plug from the mains socket.
3. Clean and dry the interior thoroughly.
4. Ensure that all the doors are wedged open slightly to allow air to circulate.

Cleaning and care

For hygienic reasons the appliance (including exterior and interior accessories) should be cleaned regularly at least every two months.

Caution! The appliance must not be connected to the mains during cleaning. Danger of electrical shock! Before cleaning switch the appliance off and remove the plug from the mains socket.

Exterior cleaning

To maintain good appearance of your appliance, you should clean it regularly.

-Wipe the digital panel and display panel with a clean, soft cloth.

-Spray water onto the cleaning cloth instead of spraying directly on the surface of the appliance. This helps ensure an even distribution of moisture to the surface.

-Clean the doors, handles and cabinet surfaces with a mild detergent and then wipe dry with a soft cloth.

Caution!

-Don't use sharp objects as they are likely to scratch the surface.

-Don't use Thinner, Car detergent, Clorox, ethereal oil, abrasive cleansers or organic solvent such as Benzene for cleaning. They may damage the surface of the appliance and may cause fire.

Interior cleaning

● You should clean the appliance interior regularly. It will be easier to clean when food stocks are low. Wipe the inside of the fridge freezer with a weak solution of bicarbonate of soda, and then rinse with warm water using a wrung-out sponge or cloth. Wipe completely dry before replacing the shelves and baskets.

Thoroughly dry all surfaces and removable parts.

● Although this appliance automatically defrosts, a layer of frost may occur on the freezer compartment's interior walls if the freezer door is opened frequently or kept open too long. If the frost is too thick, choose a time when the supply of food stocks are low and proceed as follows:

1.Remove existing food and accessories baskets, unplug the appliance from the mains power and leave the doors open. Ventilate the room thoroughly to accelerate the thawing process.

2.When defrosting is completed, clean your freezer as described above.

Caution! Don't use sharp objects to remove frost from the freezer compartment. Only after the interior is completely dry should the appliance be switched back on and plugged back into the mains socket.

Door seals cleaning

Take care to keep door seals clean. Sticky food and drinks can cause seals to stick to the cabinet and tear when you open the door. Wash seal with a mild detergent and warm water. Rinse and dry it thoroughly after cleaning.

Caution! Only after the door seals are completely dry should the appliance be powered on.

Warning!

The LED light must not be replaced by the user! If the LED light is damaged, contact the customer helpline for assistance.

Troubleshooting

If you experience a problem with your appliance or are concerned that the appliance is not functioning correctly, you can carry out some easy checks before calling for service, please see below. You can carry out some easy checks according to this section before calling for service.


Warning! Don't try to repair the appliance yourself. If the problem persists after you have made the checks mentioned below, contact a qualified electrician, authorized service engineer or the shop where you purchased the product.

Problem	Possible cause & Solution
Appliance is not working correctly	Check whether the power cord is plugged into the power outlet properly.
	Check the fuse or circuit of your power supply, replace if necessary.
	It is normal that the freezer is not operating during the automatic defrost cycle, or for a short period of time after the appliance is switched on to protect the compressor.
Odours from the compartments	The interior of the refrigerator may need to be cleaned.
	Some food, containers or wrapping cause odours.
Noise from the appliance	The sounds below are quite normal: ●Compressor running noises. ●Air movement noise from the small fan motor in the freezer compartment or other compartments. ●Gurgling sound similar to water boiling. ●Popping noise during automatic defrosting. ●Clicking noise before the compressor starts.
	Other unusual noises are due to the reasons below and may need you to check and take action: The cabinet is not level. The back of appliance touches the wall. Bottles or containers fallen or rolling.
	It is normal to frequently hear the sound of the motor, it will need to run more when in following circumstances: ● Temperature setting is set colder than necessary ● Large quantity of warm food has recently been stored within the appliance. ●The temperature outside the appliance is too high. ●Doors are kept open for a long period. ●After your installing the appliance or it has been switched off for a long time.
The motor runs continuously	
A layer of frost occurs in the compartment	Check that the air outlets are not blocked by food and ensure food is placed within the appliance to allow sufficient ventilation. Ensure that door is fully closed. To remove the frost, please refer to "cleaning and care" section.

Temperature inside is too warm	You may have left the doors open too long or too frequently; or the doors are kept open by some obstacle; or the appliance is located with insufficient clearance at the sides, back and top.
Temperature inside is too cold	Increase the temperature by following the "Display controls" chapter.
Doors can't be closed easily	Check whether the top of the refrigerator is tilted back by 10-15mm to allow the doors to self close, or if something inside is preventing the doors from closing.
Water drips on the floor	The water pan (located at the rear bottom of the cabinet) may not be properly leveled, or the draining spout (located underneath the top of the compressor depot) may not be properly positioned to direct water into this pan, or the water spout is blocked. You may need to pull the refrigerator away from the wall to check the pan and spout.
The light is not working	The LED light may be damaged. Refer to replace LED lights in cleaning and care chapter. The control system has disabled the lights due to the door being kept open too long, close and reopens the door to reactivate the lights.
Doors does not open smoothly	Check the door seal, and if it is necessary clean the rubber gasket seal around the edges of the door using dish soap and warm water. Dirt and grime can collect here and cause door stick to the fridge.

Disposal of the appliance

The refrigerator is built from reusable materials. It must be disposed of in compliance with current local waste disposal regulations. The appliance contains a small quantity of refrigerant (R600a) in the refrigerant circuit. For your safety please refer to the section of "the refrigerant and risk of fire" in this Instruction Manual before scrapping the appliance. Please cut off the power cord to make the refrigerator unusable and remove the door seal and lock. Please be cautious of the cooling system and do not damage it by puncturing the refrigerant container and/or bending the tubing, and/or scratching of the surface coating.

Correct Disposal of this product	
	<p>This symbol on the product or in its packing indicates that this product may not be treated as household waste. Instead, it should be taken to the appropriate waste collection point for the recycling of electrical and electronic equipment. By ensuring this product is disposed of correctly, you will help prevent potential negative consequences for the environment and human health, which could otherwise be caused by the inappropriate waste handling of this product. For more detailed information about the recycling of this product, please contact your local council your household waste disposal service, or the shop where you purchased the product.</p>

قد كنت قد تركت الأبواب مفتوحة لفترة طويلة جدا أو بشكل متكرر جدا، أو يتم إبقاها مفتوحة من قبل بعض المشاكل أو أد التلاجة تقع في مكان ذو مساحة غير كافية في الجانبين والخلف والأعلى	درجة الحرارة الداخلية دافئة جدا
زيادة درجة الحرارة عن طريق اتباع الفصل. "عرض الضوابط"	درجة الحرارة الداخلية باردة جدا
تحقق ما إذا كان يميل الجزء العلوي من التلاجة الى الخلف بـ 10-15ملمتر للسماح للأبواب الإغلاق بنفسها، أو إذا في شيء يمنع إغلاق الأبواب.	يمكن إغلاق الأبواب بسهولة
وعاء الماء (الموجود في الجزء السفلي الخلفي من الحجرة) قد لا تكون مستوية بشكل صحيح، أو صنوبرة تصريف المياه (الموجود تحت الجزء العلوي من مستودع ضاغط) قد لا تكون وضعت بشكل صحيح لتوجيه المياه إلى هذا الوعاء، أو صنوبرة الماء سدت. قد تحتاج إلى سحب التلاجة بعيدا عن الجدار للتحقق من وعاء الماء وصنوبر.	قطرات الماء على الأرض
• قد يكون ضوء LED معطوبا. الرجوع إلى استبدلا مصابيح LED فيفصل التنظيف والرعاية. • تم تعطيل نظام التحكم بالأضواء بسبب الباب يتم إبقاها مفتوحا فترة طويلة جدا، أغلق الباب وأعد فتحه لتفعيل الأضواء.	ضوء لا يعمل

التخلص من التلاجة

يحظر التخلص من هذا الجهاز مع النفايات المنزلية.
مواد التعبئة والتغليف

يمكن إعادة تدوير مواد التعبئة والتغليف ذات رمز إعادة التدوير. التخلص من مواد التغليف في حاوية جمع النفايات مناسبة لإعادة التدوير.


قبل التخلص من التلاجة

1. فصل قابس التيار الكهربائي عن مأخذ توصيل التيار الكهربائي.

2. فصل سلك الكهرباء ونزع من قابس التيار الكهربائي

تحذير! التلاجات تحتوي على غازات التبريد والغازات في العازل. يجب التخلص من غازات الاحتباس والمبردات مهنيا كما أنها قد

تأكد من أن أنابيب غازات التبريد للدارة ليست تلف قبل التخلص السليم.

التخلص بطريقة صحيحة من هذا الجهاز	
هذا الرمز الموجود على المنتج أو داخل العبوة يشير إلى أن هذا المنتج لا يمكن أن يتم معاملته كالنفايات المنزلية. بدلا من ذلك، ينبغي أن تؤخذ إلى نقطة جمع النفايات المناسبة لإعادة تدوير المعدات الكهربائية والإلكترونية. من خلال ضمان التخلص من هذا المنتج بشكل صحيح، سوف تساعد على منع الآثار السلبية المحتملة على البيئة وصحة الإنسان، والتي كان من الممكن أن تنجم عن معالجة النفايات بصورة غير ملائمة لهذا المنتج. للحصول على معلومات أكثر تفصيلا حول إعادة تدوير هذا المنتج، يرجى الاتصال بلامجلس المحلي، الخاص التخلص من النفايات المنزلية الخدمة أو المتجر الذي اشتريته منه المنتج.	

MADE IN CHINA

المشكلة	السبب المتوقع والحل
الأجهزة لا يعمل بشكل صحيح	تحقق ما إذا كان يتم توصيل سلك الطاقة في مقبس الطاقة بشكل صحيح.
	التحقق من الصمامات أو دائرة امدادات الطاقة الخاصة بك، استبدالها إذا لزم الأمر.
	درجة الحرارة المحيطة منخفضة جدا. حاول ضبط درجة حرارة الغرفة لتكون أكثر برودة لحل هذه المشكلة.
الروائح من الحجرات التبريد	فمن الطبيعي أن التجميد لا يعمل أثناء دورة إزالة الصقيع التلقائي، أو لفترة قصيرة بعد تشغيل التلاجة لحماية الضاغط.
	الاجزاء الداخلية تحتاج إلى تنظيف بعض المواد الغذائية والحاويات أو الاغذية الملفوفة السبب في الروائح الكريهة.
ضجيج من التلاجة.	الأصوات أدناه طبيعية تماما: • ضاغط يصدر الضوضاء. • ضوضاء حركة الهواء من مروحة صغيرة من حجرة التجميد أو حجرات أخرى. • صوت الغرغرة مماثلة إلى الماء المغلي. • سمع ضجيج أثناء إزالة الجليد التلقائي. • ضجيج النقر قبل بدأ الضاغط بالعمل.
	الأصوات الغير عادية الأخرى هي نتيجة لأسباب أدناه، وربما بحاجة لكم للتحقق واتخاذ الإجراءات: الحجرة ليست مستوية. الجزء الخلفي من التلاجة يلمس الجدار. زجاجات أو حاويات أو سقط تندررج.
المحرك يعمل بشكل مستمر	فمن الطبيعي أن نسمع في كثير من الأحيان صوت المحرك، وسوف تحتاج إلى تشغيل أكثر عندما تكون في الحالات التالية: • تم تعيين إعدادات درجة حرارة أبرد من اللازم • تم مؤخرا حفظ كمية كبيرة من الطعام الساخن داخل التلاجة. • درجة الحرارة خارج التلاجة مرتفع جدا. يتم ابقى الأبواب مفتوحة لفترة طويلة جدا أو في كثير من الأحيان. • بعد تركيب التلاجة الخاص بك أو تم إيقاف تشغيله لفترة طويلة.
	تأكد من أن عدم إغلاق منافذ الهواء بواسطة الأغذية وضمان وضع المواد الغذائية داخل التلاجة للحصول على تهوية كافية. تأكد أن ذلك الباب مغلق تماما. لإزالة الصقيع، يرجى الرجوع إلى فصل التنظيف والرعاية.

• الطعام المطبوخ، والأطباق الباردة، وما إلى ذلك:

يجب تغطيتها ويمكن وضعها على أي رف.

• الفواكه والخضروات:

وينبغي تخزينها في الإدراج الخاصة.

الزبدة والجبين: ينبغي أن تكون ملفوفة في فويل محكم أو لفاف البلاستيك.

• الحليب المعبأ في القوارير:

ينبغي أن يكون لها غطاء وتكون مخزنة في رفوف الباب.

نصائح للتجميد

• عند أول التشغيل في أو بعد فترة من عدم الاستخدام، أسمح للثلاجة أن تعمل ما لا يقل عن 2 ساعة على أعلى إعدادات قبل وضع الطعام في المقصورة.

• إعداد الطعام في أجزاء صغيرة لتمكينها من أنتجمد بسرعة وبشكل كامل وتمكن منذوبان الجليد في وقت لاحق فقط بأكمية المطلوبة.

• لف الطعام في رقائق الألومنيوم أو الأغشية الغذائية البولي إيثيلين التي تعتبر محكم.

• لا تسمح للأغذية الطازجة والغير مجمدة لمس الأغذية التي تم تجميدها لتجنب ارتفاع درجة الحرارة لهذه الأخيرة.

التنظيف والرعاية

وينبغي لأسباب صحية يتم تنظيف الثلاجة (بما في ذلك الملحقات الخارجية والداخلية) بانتظام على الأقل مرة كل شهرين.

تنبيه! يجب ألا تكون الثلاجة موصلة بالكهرباء خلال التنظيف. خطر الصدمة الكهربائية! قبل التنظيف، أوقف تشغيل الجهاز وإزالة القابس من مأخذ توصيل الكهرباء.

التنظيف الخارجي

للحفاظ على مظهر جيد للجهاز الخاصة بك، يجب عليك تنظيفه بشكل منتظم.

مسح اللوحة الرقمية ولوحة العرض بقطعة قماش نظيفة وناعمة رطبة الماء على قطعة القماش بدلاً من مباشرة على

سطح الجهاز. هذا يساعد على ضمان توزيع عادل للرطوبة على السطح.

• المنتجات المتلجة، إذا استهلك فور بعد إخراجها من حجرة التجميد سوف تسبب ربما الصقيع على الجلد.

• من المستحسن لتصنيف حسب التاريخ كل عبوة تجمد لإبقاء تتبع من وقت التخزين.

نصائح لتخزين المواد الغذائية المجمدة

• كد أنه قد تم تخزين المواد الغذائية المجمدة بشكل صحيح من قبل متاجر التجزئة الغذائية

• بمجرد إذابة الجليد، المواد الغذائية سوف تندهور بسرعة، وينبغي ألا يعاد تجميدها. لا تتجاوز فترة التخزين المشار إليها من قبل شركة الغذاء.

إطفاء الثلاجة الخاصة بـ

إذا كانت الثلاجة تحتاج إلى إيقاف تشغيلها لفترة طويلة، ينبغي اتخاذ الخطوات التالية لحيلولة دون العفن على الثلاجة.

1. إزالة جميع المواد الغذائية.

2. إزالة قابس الطاقة من مأخذ التيار الكهربائي.

3. قم بتنظيف وتجفيف المناطق الداخلية بدقة.

4. تأكد من أن جميع الأبواب مفتوحة قليلاً للسمح للهواء بالتدوير.

تنظيف الأبواب، مقابض لجرية والسطوح بواسطة منظف معتدل ثم مسحت بقطعة قماش ناعمة جافة.

تنبيه!

-لا تستخدم أدوات حادة حيث من المحتمل أن تخدش السطح.

-لا تستخدم المخففات، ومنظفات السيارات، كلوروكس وزيت أثري والمنظفات الكاشطة أو العضوية أو المذيبات مثل البنزين للتنظيف فإنها قد تلثف سطح الجهاز ويمكن أن يتسبب الحريق.

التنظيف الداخلي

يجب تنظيف المناطق الداخلية للثلاجة بانتظام. سيكون من الأسهل لتنظيف

عندما يكون مخزونات الأغذية منخفضة. امسح داخل الفريزر الثلجة بمحلول ضعيف من بيكربونات

الصودا، ثم شطف مع الماء الدافئ باستخدام الإسفنجة مهترية أو القماش. أسمح للتجفيف بشكل كامل قبل

إعادة الرفوف والسلال. جفف جميع الأسطح والأجزاء القابلة للإزالة. على الرغم من أن هذا الجهاز تلقائياً

تنويب، طبقة من الصقيع تحدث على جدران حجرة التجميد الداخلية إذا تم فتح باب الثلاجة في كثير من

الأحيان أو تبقى مفتوحة لفترة طويلة. إذا كان الصقيع سميك جداً اختر وقت توفير مخزونات الأغذية منخفضة و قم بما يلي على النحو التالي:

1. إزالة المواد الغذائية الموجودة وسلال الملحقة، افصل الجهاز عن التيار الكهربائي وترك الأبواب مفتوحة. تهوية الغرفة جيداً لتسريع عملية الذوبان.

2. عند اكتمال إزالة الجليد، وتنظيف الفريزر كما هو موضح أعلاه.

إن لم يتم الجهاز تلقائياً بإذابة الثلج، فسيتراكم الثلج في مناطق معينة من قسم الفريزر بعد فترة من الاستخدام.

يمكن كشط هذا الثلج باستخدام مكشطة بلاستيكية. لا تقم أبداً باستخدام أدوات معدنية أو حادة.

• مع ذلك، يجب تنفيذ عملية الإذابة الكلية للثلج حوالي أربع مرات كل عام، أو إذا زادت طبقة الثلج عن 4مم (1/4 بوصة) مؤثرة بذلك على كفاءة النظام. يجب تنفيذ عملية الإذابة الكلية للثلج في حال عدم إمكانية كشط

الثلج، أو إذا بدء الثلج في اعتراض عملية تخزين الطعام. اختر وقتاً تكون كميات الطعام قليلة واتبع التعليمات التالية:

أخرج الطعام والملحقات الموجودة، وافصل الجهاز عن مصدر التيار الرئيسي واترك الباب مفتوحاً. قم بتهوية الغرفة جيداً لتسريع عملية الإذابة.

استكشاف الأخطاء وإصلاحها

إذا واجهت مشكلة مع للثلاجة الخاص بك أو تشعر بالقلق من أن الثلاجة لا تعمل بشكل صحيح، يمكنك القيام ببعض الاختبارات السهلة قبل استدعاء للخدمة، الرجاء راجع أدناه. يمكنك تنفيذ بعض الفحوصات السهلة وفقاً لهذا القسم قبل استدعاء للخدمة.

تحذير: لا تحاول إصلاح الجهاز بنفسك. إذا استمرت المشكلة بعد أن قمت ب الاختبارات المذكورة أدناه، اتصل بكهربائي مؤهل، مهندس مرخص للخدمة أو بلامحل الذي اشترت منه المنتج.

2. اكشط ما تستطيع كشطه من الثلج باستخدام المكشطة البلاستيكية (المكشطة غير مرفقة).

3. إذا لزم الأمر، ضع قطعة قماش مبللة بماء دافئ على سطح الطبقة المتلجة لتسريع عملية ذوبانها.

4. عند اكتمال عملية إذابة الثلج، قم بتنظيف الفريزر على النحو الموضح – انظر التنظيف الداخلي.

تنبيه! لا تستخدم أدوات حادة لإزالة الصقيع من مقصورة الثلاجة. ينبغي ألا بعد أن تجف لأجزاء الداخلية تمام يتم تشغيل للثلاجة مرة أخرى بتوصيله مرة أخرى في مأخذ توصيل التيار الكهربائي.

تنظيف إطار إحكم قفل الباب

إعنتي بنظافة إطار إحكم قفل الباب للثلاجة. يمكن المواد الغذائية الزجة والمشروبات التسبب قفل التمسك حجرة التبريد والتمزق عند فتح الباب. غسل إطار إحكام قفل الباب بمنظف خفيف وماء دافئ. أشطف وجفف جيداً بعد التنظيف.

تنبيه! فقط بعد أن يجف إطار إحكام قفل الباب تمام يتم تشغيل الثلاجة.

استبدال لمبة الإضاءة:

تحذير: لا يجب استبدال لمبة الإضاءة من قبل المستخدم! إذا تلتفت لمبة الإضاءة، فيجب عليك الاتصال بخط خدمة العملاء لطلب المساعدة. يجب اتباع الخطوات التالية عند استبدال لمبة الإضاءة:

1. قم بفصل قابس التيار الكهربائي للجهاز.

2. أزل غطاء مكان الإضاءة بدفعه للأعلى ثم للخارج.

3. أمسك غطاء اللمبة المراد استبدالها بإحدى يديك واسحبها بلايد الأخرى للخارج بينما تضغط على لسان التوصيل.

4. أحضر لمبة جديدة و قم بتنصيبها في مكانها بشكل صحيح.

طبق الثلج المرن

- يمكن طبّق الثلج المرن هو جَرَار الفريزر العلوي.
- الطبق معد لصنع مكعبات الثلج وتخزينها. يجب عليك استخدامه على النحو التالي.
- 1. قم بسحب طبق الثلج المرن للخارج من رف التنصيب.
- 2. املاء بالماء ولكن أسفل علامة الحد الأقصى.
- 3. قم بتركيب طبق الثلج المرن المملوء في مكانه.
- 4. عند تكون مكعبات الثلج أدر الطبق من المقابض في اتجاه عقارب الساعة وسوف يسقط الثلج في الصندوق أذناه.



- يستخدم لتخزين الأطعمة التي تحتاج للتجميد، بما في ذلك اللحوم والأسماك والأيس كريم وغيرها.
- لإزالة جَرَار الفريزر - اسحب الجرار للخارج بالكامل. اقلب طبق التقديم للأعلى وارفعه للخارج، ثم افتح أبواب الثلاجة لأقصى زاوية، وحينها يمكن إخراج جَرَار الفريزر، على النحو الموضح في الصور التالية.

فتح الباب قفل الباب

طبق التقديم

جرار الفريزر السفلي

• تنبيه

- لا تسمح للأطفال أو الرضع بالدخول إلى داخل الثلاجة، حيث أنهم قد يعرضون أنفسهم للإصابات أو يقوموا بإتلاف الثلاجة. لا تجلس على باب الفريزر. قد ينكسر الباب. لا تسمح للأطفال بالتسلق إلى داخل سلة الفريزر.
- إذا قم بإزالة الموزع لتنظيف صندوق السلة، فينبغي عليك إعادة تثبيت الموزع بعد التنظيف لمنع الأطفال من التعرّض داخل السلة.

تلميحات ونصائح مفيدة

نصائح لتوفير إستهلاك الطاقة

- ننصحك باتباع النصائح التالية للتوفير في إستهلاك الطاقة
- لتوفير الطاقة، يرجى تجنب إبقاء الباب مفتوحاً لفترة طويلة عند استخدام الثلاجة من أجل المحافظة على الطاقة
- تأكد من الأجهزة بعيداً عن أي مصادر للحرارة (أشعة الشمس المباشرة، أو فرن كهربائي موقد الخ)
- لا تقم بضبط درجة حرارة أبرد من اللازم.
- لا تقم بتخزين الطعام الساخن أو السائل المتبخر في الثلاجة.
- ضع الثلاجة الكهربائية في غرفة جيدة التهوية وخلاية من الرطوبة. يرجى الرجوع إلى الفصل الخاص بتثبيت الثلاجة الكهربائية الجديدة.

- إذا كان الرسم البياني يبين التركيبة الصحيحة للحفاظ، والأدراج والرفوف، لا تعديل التركيبة حيث تم تصميم هذا لتكوين أكثر كفاءة للطاقة.

نصائح لحفظ الأطعمة الطازجة

- لا تضع الطعام الساخن مباشرة في الثلاجة أو الفريزر، فإن درجة الحرارة الداخلية سوف تزيد فيجبر الضاغط على العمل بجهد أكبر، وسوف تستهلك المزيد من الطاقة.
- قم بتغطية أو لف المواد الغذائية، خاصة إذا كان لديه نكهة قوية.
- ضع الغذاء بشكل صحيح بحيث يمكن السماح بتحرك الهواء حوله بحرية.
- لف اللحوم (كل أنواع) في البوليثلين الغذائي: لف وضع على الرف الزجاجي فوق درج الخضروات. اتبع دائماً أوقات تخزين المواد الغذائية واستخدامها حسب التاريخ المقترح من قبل الشركات المصنعة.

- عند إزالة صندوق حفظ الخضروات والفاكهة، اسحبه للأمام، ثم ارفعه عن المزلجات.
- لا تنس تفريغ الطعام من الصندوق أولاً.


بمجرد إزالتك للجرارات، تأكد من دفع المزلجات لمكانها كما ينبغي.

صندوق حفظ الخضروات والفاكهة بقسم الثلاجة

- يستخدم للتحكم في حرارة صندوق حفظ الخضروات والفاكهة وللمنع تعرض الخضروات للرطوبة.

الضبط الدقيق لدرجة الحرارة (اختياري)

هناك ثلاثة أوضاع لوطفية المأكولات الطازجة. يمكنك الاختيار بين الأوضاع المختلفة وفقاً لمتطلباتك بالضغط على زر وضع المأكولات الطازجة الخاصة "My Fresh Choice" بلوحة التحكم، وستضئ الأيقونة المعنية تبعاً للوضع المختار.



- يمكن ضبط درجة الحرارة في الداخل إلى 3 و 5 درجة مئوية على التعاقب، وذلك لتلبية احتياجاتك.


• يمكنه تخزين الأنواع المختلفة للأطعمة مثل الجبن واللحم والخضروات والفاكهة والأطعمة الأخرى القابلة للتلف في درجة حرارة ملائمة.

• زر الاختيار

1. عند اختيار وضع "Deli"، سيتم الاحتفاظ بدرجة حرارة القسم عند حوالي 5 درجة مئوية. هذا الوضع يساعد في الحفاظ على الطعام طازجاً لمدة أطول.
2. عند اختيار وضع "Vege"، سيتم الاحتفاظ بدرجة حرارة القسم عند حوالي 3 درجة مئوية. هذا الوضع يساعد في الحفاظ على الطعام طازجاً لمدة أطول.
3. عند اختيار وضع "0"، سيتم الاحتفاظ بدرجة حرارة القسم عند حوالي 0 درجة مئوية. هذا الوضع يساعد أيضاً في الحفاظ على اللحم والأسماك طازجة لمدة أطول.

0°C	Vege.	Deli
شرائح اللحم	الخيار	الأناناس
البهوت دوج	الكوسة	الليمون
شرائح اللحوم الباردة	البرتقال	الأفوكادو
لحم الخنزير المقعد	البقوليات	البطاطس

- هناك ثلاثة مواضع قابلة للتعديل للرف السفلي، حيث يمكنك تعديل ارتفاع الرف وفقاً لاحتياجاتك، بينما الرفع العلوي له موضع واحد.




التحكم في الرطوبة وصندوق حفظ الخضروات والفاكهة

- هذا الصندوق، المثبت على مزلجات تمديد متراكبة، معد لحفظ الخضروات والفاكهة. وبإمكانك ضبط رطوبة الصندوق باستخدام الكتلة المنزلفة.

- يمكن تحريك الكتلة المنزلفة على غطاء الصندوق إلى اليمين أو اليسار وسيزيد الهواء المتدفق أو ينقص وفقاً لحركتها. فزيادة فتحة الهواء المتدفق تعني رطوبة أقل والعكس بالعكس.

- نوصي بتخزين الخضروات في رطوبة عالية والفاكهة في رطوبة أقل.

يمكنك تعديل مستوى الرطوبة في الداخل باستخدام الكتلة المنزلفة.




يخبرك هذا القسم بكيفية استخدام غالبية الخواص. ولذا من الموصى به قراءته بعناية قبل استخدام الجهاز.

تعديل وضع الأبواب

● لكل من بابي الثلاجة الأيمن والأيسر أجزاء قابلة للتعديل، وتوجد أسفل المفصلة.

إذا كانت قمة الأبواب غير متساوية، قم بتعديل ارتفاع الباب عن طريق الربط باستخدام مفتاح سداسي (الأنكيه) في اتجاه عقارب الساعة أو عكسها. أدخل المفتاح السداسي إلى محور المفصلة، ثم أدرك لضبط مستوى الباب. (يمكنك إدارة المحور في اتجاه عقارب الساعة لرفع الباب أو في عكس الاتجاه لخفضه).

● قبل تعديل الوضع، يجب عليك التأكد أن الثلاجة في وضع مستوٍ على الأرض. (انظر قسم "تنصيب جهازك الجديد").



تحذير!



عند تثبيت خزان الماء، تأكد أنه قد تم إدخال الرأس في الفتحة أولاً، ثم أمسك جانبي خزان الماء بإحكام وثبته على الباب.

● ملء الماء

قبل ملء الخزان بماء الشرب، تأكد أن الخزان ثابت وفي موضعه الصحيح.

تنبيه!

- لا تضع أي شيء غير الماء في الخزان.
- املاً الخزان بالماء حتى 4.0 لتر. حيث أنه لو امتلأ الخزان لأعلى من العلامة المحددة، فقد ينسكب الماء منه عند فتح الباب وإغلاقه.
- ننصح بملء الماء باتباع الطرق الآتية.



● مبرد المياه

يوجد هذا المبرد في باب الثلاجة الأيسر، وهو معد لتخزين ماء الشرب. وهذه الخاصية تمكننا من الوصول إلى الماء البارد بسهولة دون الحاجة إلى فتح باب الثلاجة. يجب عليك مراعاة النصائح التالية.

● قبل الاستخدام

قبل استخدام المبرد للمرة الأولى، يجب عليك استخدامه على النحو التالي لفحصه وتنظيفه.


1. أمسك جانبي خزان الماء بإحكام، ثم ارفعه لأعلى وأخرجه من الباب.
2. قم بفك مسامير الرأس، ثم نظف الرأس وخزان الماء.

رف الباب

● ملانم لتخزين البيض والمشروبات المعلبة والأطعمة المغلفة وهكذا. لا تقم بوضع العديد من الأشياء الثقيلة في الأرفف.

● يمكن تعديل وضع رف الباب الأوسط في ارتفاعات مختلفة وفقاً لاحتياجاتك. برجاء إخراج الطعام من الرف قبل رفعه رأسياً لتغيير وضعه.

ملحوظة: هناك أطباق بيض في الرف العلوي.




رف تخزين المعلبات

● هذا الرف مخصص لتخزين المعلبات.

● كما يمكنه أن يدور بزاوية 40 درجة بطول الرف عند اللزوم، وهو ما يسهل أمر وضع المشروبات أو إخراجها.

● هناك أربعة مواضع متوافرة لتخزين المشروبات.


● قطر العبوة وطولها لا يمكن أن يكون صغيراً جداً أو كبيراً جداً.



ملحوظة: إذا كان قطر العبوة أقل من 50مم، فلن يمكن وضعها في الرف.

الرف في قسم الثلاجة

● هناك رفان رجايبان في قسم الثلاجة، ويمكن إخراجهما لتنظيفهما.



1. أزل الغطاء الصغير واملأ الماء من الفوهة في الغطاء الكبير.

2. أزل غطاء الخزان، ثم املأ بالماء مباشرة.

● القفل

قبل الحصول على الماء من المبرد، تأكد من أنه في وضع فتح القفل "Unlock".

تحذير!

خاصية القفل هذه تعرف بجهاز القفل "Lock device". لا تحاول دفع رافعة الوعاء بقوة عندما يكون الوعاء في وضع "القفل"، لأن ذلك ربما يؤدي إلى تلف آلية عمله.

● استخدام المبرد

يجب عليك استخدام كوب ملانم لتلقي الماء أسفل مبرد المياه.

تحذير! لا تسحب رافعة الوعاء للخارج بدون أن يكون هناك كوباً أسفله، لأن ذلك قد يؤدي إلى تسرب الماء من الوعاء.

اترك جهاز تصريف المياه مثبت في فتحة التثبيت بإحكام، في حالة عدم استخدام الوعاء، وذلك في حالة تسرب الهواء البارد.




التنظيف

1. قم بإخراج خزان الماء خارج الباب بحذر، ثم اغسله واغسل الأغشية والرأس بالماء برفق.

2. بعد أن قمت بغسل مبرد المياه، اتركه ليجف وحده أو جفّه بمجفف.

ملحوظة: إذا كنت قد استخدمت مبرد المياه لمرات عديدة، قد يكون الماء قد تساقط على الأرضية ما قد يسبب بللها، ومن ثم يجب عليك تنظيف الخزان بمنشفة جافة بانتظام قبل أن يمتلئ بشكل زائد.

تتكون لوح التحكم من منطقتين لعرض الحرارة، و 5 أيقونات تمثل الأوضاع المختلفة و 6 أزرار تعمل باللمس. عند تشغيل الجهاز للمرة الأولى، تبدأ الإضاءة الخلفية للأيقونات الموجودة على لوحة العرض بالعمل. إذا لم يتم الضغط على أي زر والأبواب مغلقة، تنطفئ الإضاءة الخلفية بعد 60 ثانية.




التحكم في درجة الحرارة

نوصي عند بدء تشغيل الثلاجة الخاصة بك لأول مرة، أن يتم تعيين درجة حرارة الثلاجة على 3°C والفرزير إلى 18°C-. إذا كنت ترغب في تغيير درجة الحرارة، اتباع التعليمات الواردة أدناه لتعيينها! عند تعيين درجة الحرارة، تعيين متوسط درجة الحرارة لكيينة الثلاجة الكهربائية بأكملها يمكن لدرجات الحرارة داخل الحجرة أن تختلف عن كل درجات الحرارة المعروضة على لوحة، وهذا يتوقف على كم الطعام الذي تم تخزينه والمكان الذي تم وضعه يمكن رفع أو خفض درجة حرارة الغرفة أن يؤثر أيضا على درجة الحرارة داخل الثلاجة الكهربائية الفعلية.

1. الفرزير

اضغط على زر الفرزير "Freezer" لضبط حرارة الفرزير ما بين 8 درجة مئوية إلى 2 درجة مئوية بحسب الطلب، وستقوم شاشة العرض بإظهار القيمة المتوافقة وفقاً للتسلسل التالي.



2. بارد جدا

يمكن لوضع بارد جدا ان يقوم بتبريد بشكل أسرع، مما يبقى الطعام طازج لفترة طويلة من الزمن، اضغط على "بارد جدا" لتفعيل وظيفة بارد جدا. سوف تضئ الإضاءة. تفعيل وظيفة سوبر كول سوف يضئ الضوء

• عند يتم تفعيل وظيفة سوبر كول، سيتم إضاءة الرمز المقابل.

• عند وظيفة السوبر كول في وضع التشغيل، يمكنك إيقاف تشغيل وظيفة السوبر كول عن طريق الضغط على زر "سوبر كول" أو الزر "ثلاجة" ووضع درجة حرارة الثلاجة ستعود مرة أخرى إلى الإعداد السابق .

3. الثلاجة

اضغط على زر الثلاجة "Fridge" لضبط حرارة الفرزير ما بين 14- درجة مئوية إلى 24- درجة مئوية بحسب الطلب، وستقوم شاشة العرض بإظهار القيم المتوافقة وفقاً للتسلسل التالي.



4. سوبر فريز

سوف يخفض سوبر فريز درجة الحرارة بسرعة داخل الفرزير حتى يجمد الغذاء بشكل أسرع. وهذا يمكن تأمين الفيتامينات والمواد المغذية من الطعام الطازج والحفاظ على المواد الغذائية الطازجة لفترة أطول.

- وسوف يضئ الضوء
- في حالة الحد الأقصى لمقدار الطعام المراد تجميده، يرجى الانتظار حوالي 24- ساعة.
- سوبر تجميد تلقائياً يتوقف عن العمل بعد 32 ساعة ودرجة حرارة الفرزير تعود الى وضع 25°C-.
- تتوقف خاصية التجميد السريع في الحالتين التاليتين:
 1. تم تشغيل الجهاز في هذا الوضع لمدة 26 ساعة ودرجة حرارة الفرزير أقل من 20- درجة مئوية.
 2. تم تشغيل الجهاز في هذا الوضع لمدة 27 ساعة.

• عند عمل وضع سوبر فريز يمكنك إيقاف الوضع بلاضغط على زر " سوبر فرزي" او " فريزر" وسوف تعود درجة حرارة الى الوضع السابق.

ملحوظة: عند اختيار وضع التجميد السريع "Super Freeze"، تأكد من عدم وجود أي زجاجات أو عبوات سائل، لأنها قد تنفجر نتيجة لتمدد حجمها.

5. عطلة

إذا كنت تريد الذهاب بعيدا لوقت طويل من الزمن، فإن وظيفة "عطلة" هو الخيار الأفضل لك، يمكنك تفعيل هذه الوظيفة عن طريق الضغط على لمدة ثلاث ثواني حتى يضئ الضوء.



عند تفعيل وظيفة العطلة يتم التغيير تلقائياً لدرجة حرارة الثلاجة إلى 15°C للحد من استهلاك الطاقة.

مهم! لا تقم بتخزين أطعام في الثلاجة خلال هذه الفترة.

• عندما تكون وظيفة العطلة في وضع التشغيل، يمكنك إيقاف التشغيل عن طريق الضغط على أي زر "عطلة"، "الثلاجة" و "سوبر كول" فإن درجة حرارة للثلاجة تعود مرة أخرى إلى الإعدادات السابقة.

6. الإنذار

في حالة الإنذار "الإنذار" ايقونة سوف تضئ وسوف يصدر صوت طنين . اضغط على "الإنذار" لإيقاف الإنذار و من ثم الانذر سوف ينطفئ و يتوقف الطنين.



إنذار الباب

• إذا تركت باب الثلاجة أو الفرزير مفتوحاً لأكثر من دقيقتين، فحينها ينطلق إنذار الباب. في حال إنطلاق إنذار الباب، يقوم الطنن بإطلاق صوت الإنذار لثلاث مرات في الدقيقة ثم يتم إيقاف الإنذار بعد 10 دقائق.

• لتوفير الطاقة، برجاء عدم ترك الأبواب مفتوحة لفترات طويلة عند استخدام الثلاجة. في حال إنطلاق إنذار الباب، يمكنك إيقاف الإنذار عن طريق إغلاق الأبواب.

إنذار درجة الحرارة

• إذا كانت درجة حرارة الفرزير مرتفعة للغاية بسبب انقطاع التيار الكهربائي أو لأسباب أخرى، فإنه سيتم إعطاء إنذار درجة الحرارة ودرجة حرارة الفرزير تعرض اعدادات "-".

• في حال إنطلاق إنذار الحرارة، يقوم المنبه الصوتي بإطلاق صوت مستمر لعشر مرات ثم يتوقف تلقائياً.

تنبيه! عند استعادة الطاقة، قد ينطلق إنذار الحرارة وهو ما يمكن إيقافه بالضغط على زر الإنذار "Alarm".

قفل منع عبث الأطفال "Child Lock"

اضغط مع الاستمرار في الضغط على زر قفل منع عبث الأطفال "Child Lock" لمدة ثلاثة ثوانٍ حتى تتمكن من




تفعيل هذا الوضع. وهذا الوضع سوف يوقف شاشة التحكم لمنع التغييرات غير المقصودة في الإعدادات. وفي هذه الأثناء تكون أيقونة وضع قفل منع عبث الأطفال "Child Lock" مضاءة.


• لإلغاء هذا الوضع، فقط اضغط مع الاستمرار في الضغط على زر قفل منع عبث الأطفال "Child Lock" لمدة ثلاثة ثوانٍ. وسوف تنطفئ أيقونة الوضع.

• لإلغاء هذا الوضع، فقط اضغط مع الاستمرار في الضغط على زر قفل منع عبث الأطفال "Child Lock" لمدة ثلاثة ثوانٍ. وسوف تنطفئ أيقونة الوضع.

العرض 1 للجهاز FD-630S



العرض 2 للجهاز FD-630S




- الخزانة
- الغطاء العلوي
- سدادة الحاجز الرأسية
- رف زجاجي
- صندوق تخزين الماء
- رف مرن لتخزين المعلبات
- صندوق حفظ الخضروات والفاكهة
- جزء الحاجز الرأسي
- طبق الثلج المرن (داخلي)
- طبق التقديم
- البكرات
- قدم سفلية قابلة للضبط
- جرار الفريزر السفلي
- جرار الفريزر العلوي
- لمبة إضاءة الفريزر (داخلية)
- وضع المأكولات الطازجة الخاصة
- سدادة باب التلاجة

- رف سفلي
- غطاء صندوق حفظ الخضروات والفاكهة
- رف علوي
- طبق البيض (داخلي)
- غطاء الرف
- لمبة إضاءة التلاجة (داخلي)
- لوحة العرض
- مبرد المياه
- المقبض
- باب الفريزر

ملحوظة: نظراً للتعديل المستمر على منتجاتنا، فقد تجد بعض التغييرات البسيطة في تاجتك عن المواصفات الموجودة في دليل الاستخدام هذا، إلا أن الوظائف وطرق الاستخدام تظل كما هي.

ملحوظة: لكي تحصل على أعلى كفاءة للجهاز، فرجاء وضع كل الأرفف والجرارات والسلات في أماكنها المخصصة لها كما هو موضح في الرسم.

• عند الوضع في أحد الأركان.



درجات حرارة الغرفة الموجود بها الجهاز

• تم تصميم التلاجة/الفريزر للعمل في درجات حرارة محيطية تم تحديدها بواسطة فئة درجة الحرارة الموضحة على لوح التصنيف.


درجة الحرارة المحيطة	الرمز	الفئة
+10°C to +32°C	SN	ممتد معتدل
+16°C to +32°C	N	معتدل
+16°C to +38°C	ST	شبه استوائي
+16°C to +43°C	T	استوائي

• ضع التلاجة في مكان جاف لتجنب الرطوبة الزائدة.

• احفظ الجهاز بعيداً عن أشعة الشمس المباشرة أو الأمطار أو الثلج. ضع الجهاز بعيداً عن مصادر الحرارة، مثل الأفران أو ألسنة اللهب أو السخانات.

الأدوات اللازمة (غير مرفقة):


مفتاح مسدس (الأنكيه) (3مم)	مفتاح ربط (8مم)
مفك فيليبس	مفك عادية



ضبط مستوى الجهاز

• لضبط الملائم للجهاز وتوفير دورة هواء ملائم في الجزء الخلفي السفلي للجهاز، قد تحتاج لضبط القدم السفلية. يمكنك تعديلهم يدوياً باستخدام يديك أو مفتاح ربط ملائم.

• للسماح للباب بالإغلاق الذاتي، أمل الجزء العلوي للثلاجة إلى الخلف بمقدار 10-15 مم.



تثبيت المقبض


• قبل استخدامك للمنتج، برجاء التحقق من مقبض التلاجة. إذا كان المقبض مفكوكاً، يجب عليك ربطه باستخدام مفك سداسي في اتجاه عقارب الساعة أو فكّه في اتجاه عكس عقارب الساعة. يتم استخدام ستة مسامير لتثبيت ثلاثة مقابض.

- يجب إبعاد الجهاز عن الشموع المشتعلة والمصابيح وأي أشياء أخرى ذات لبب وكذلك مصادر الإشعاع، ولا بد من تهوية الغرفة بشكل جيد لتجنب خطر الحريق وإصابات العين في حالة حدوث أي تسرب لغاز التبريد أيزو بيوتان (R600a).

- لا تقم بتخزين أي منتجات تحوي مواد قابلة للاشتعال (عبوات الإسبراي مثلاً) أو أي مواد متفجرة داخل الجهاز.

- يجب أن تكون مساحة الغرفة على الأقل 1 متر مكعب لكل 8 جم من المبرد (R600a). تتم الإشارة لكمية المبرد في جهازك على لوح التصنيف الموجود بالداخل.

- لتحسين فعالية نظام التبريد وتوفير الطاقة، من الضروري توفير تهوية جيدة حول الجهاز لتبريد الحرارة، ولهذا السبب، يجب توفير مساحة كافية حول الثلاجة.



- اقتراح: من الموصى به توفير مساحة لا تقل عن 75 مم من الجهة الخلفية ناحية الحائط، ولا تقل عن 100 مم من الأعلى، ولا تقل عن 100 مم من جانبيه المجاور للحائط، ومساحة من الأمام تسمح بفتح الباب بزواوية 155 درجة. كما هو موضح في الرسم البياني التالي.

يحتوي الجهاز على كمية بسيطة من سائل التبريد (R600a)



موجود في دائرة التبريد. راجع ملصق المكبس على الجهة الخلفية للجهاز للتعرف على نوع المبرد المستخدم في جهازك.


- إذا كان جهازك يحتوي على غاز التبريد أيزو بيوتان (R600a) وهو غاز مناسب وملئم للبيئة ولكنه قابل للاشتعال، فتأكد من أن أنابيب دائرة المبرد لم تتلف أثناء عمليتي النقل والتنصيب، وذلك كي تتجنب خطر الحريق الذي قد يسببه تسرب غاز التبريد

تركيب الجهاز الجديد

يخبرك هذا القسم بكيفية استخدام غالبية الخواص. قبل استخدام الجهاز للمرة الأولى، ننصح بمطالعته للنصائح التالية.

تهوية الثلاجة الكهربائية

- للتنصيب الصحيح، يجب وضع الثلاجة على سطح مستو لمادة صلبة بنفس ارتفاع بقية الأرضية. يجب أن يكون السطح قويًا كفاية لحمل ثلاجة مملوءة بالكامل، أو حوالي 266 رطل (120 كجم).



لضمان سلامة الأرضية، اقطع جزءًا كبيرًا من الورق المقوى وضعه أسفل الثلاجة. عند نقل الثلاجة، تأكد من سحب الوحدة للأمام ودفعها للخلف في اتجاه مستقيم عمودي.

- يجب أن يطبق الجهاز مع أحادية الطور من التيار المتردد 220 ~ 240V/50HZ. إذا كان الجهد تذبذب يتجاوز الحد الأعلى، ينبغي استخدامه منظم الجهد التلقائي لأكثر من 350W إلى الثلاجة للاستخدام الآمن.
- يجب أن القابس الرئيسية في المتناول عند تثبيت الأجهزة.

يجب تأريض هذا الجهاز. هذه الأجهزة يتم تركيبها مع المكونات مع فتيل وفقا للمعيار المحلية. ينبغي أن تكون القابس مع فتيل مناسبة للاستخدام في جميع المنازل مزودة مأخذ وفقا للمواصفات الحالية. إذا قابس-المجهزة ليست مناسبة لل مأخذ الخاص، ينبغي عليه قطعه والتخلص منه بعناية. لتجنب خطر الصدمة الكهربائية الممكنة، لا تقم بإدخال القابس المتضرر في المأخذ. إذا كنت في شك، اتصل بلامؤهلين، كهربائي مسجل.

- لا تستخدم أسلاك التمديد أو مأخذ متعددة التي يمكن أن تسبب حمل كهربائي زائد للدوائر التوصيلات ويمكن أن يسبب حريقًا.

القابس الأجهزة الخاصة بك دائما قم بتوصيل المقبس الكهربائي بمأخذ كهربائي فريد خاص الذي لديه جهد مطابقة لوحة التصنيف.

- تأكد من أن القابس ليست مسحوق أو تلاف. وإلا، فإنه قد يسبب بنماس كهربائي، أو ارتفاع درجة حرارة صدمة كهربائية وحتى ينتج عنه حدوث حريق.
- لا تقم بإدخال القابس الرئيسي لتيار الكهربائي إذا كان مأخذ غير محكمهناك خطر التعرض لصدمة كهربائية أو نشوب حريق.
- إيقاف تشغيل الأجهزة وفصله عن التيار الكهربائي قبل تنظيفه أو نقله.

- لا تفصل الجهاز بسحب السلك الكهربائي. دائما قم بالامساك ب القابس الرئيسي بقوة وسحب مباشرة من مأخذ التوصيل لمنع تلف سلك الطاقة.

- لا تقم بتشغيل الجهاز بدون غطاء ضوء الإنارة الداخلية.

- يجب أن يتم استبدال أي مكون أو إصلاح الكهربائية من قبل كهربائي مسجل مؤهل معتمد أو مهندس الخدمة. وينبغي استخدام قطع الغيار الأصلية فقط.

لا تعترض الأجهزة الكهربائية مثل صناعات الأيس كريم داخل حجرات تخزين المواد الغذائية من الثلاجة، ما لم تتم الموافقة عليها من قبل الشركة المصنعة.

- لا ننظر مباشرة إلى مصباح LED الموجود في مقصورة الثلاجة مع الأدوات البصرية لتجنب إصابات العين. إذا كان لا يعمل بشكل صحيح استشارة المؤهلين، الكهربائي.

تحذير

- تأكد من خلو فتحات التهوية الموجودة في الهيكل الخارجي للجهاز أو في الهيكل الداخلي من أي معوقات.
- لا تستخدم أي أجهزة ميكانيكية أو أي وسيلة أخرى لزيادة سرعة عملية إزالة الثلج سوى تلك الموصى بها من قبل الشركة الصانعة.
- لا تتسبب في تلف دائرة المبرد.
- لا تستخدم أي أجهزة كهربائية داخل الأماكن المخصصة لحفظ الطعام في هذا الجهاز، إلا إذا كانت من الأنواع الموصى بها من قبل الشركة الصانعة.
- إذا كان كابل الطاقة تالفاً، فيجب استبداله من قبل الشركة الصانعة أو وكيل الصيانة التابع لها أو الأشخاص المؤهلين على نفس المستوى، وذلك لتجنب تعرضك للخطر.
- لا يجب التخلص من الجهاز إلا في مركز معتمد للتخلص من النفايات. لا تقم بتعريض الجهاز لأسنة اللهب.

السلامة للأطفال والأشخاص العاجزين

- هذا الجهاز غير مخصص للاستخدام من قبل الأشخاص (بالإضافة إلى الأطفال) ذو الإعاقة الجسدية، الحسية والعقلية، أو الأشخاص الذين يفتقروا إلى الخبرة والمعرفة، إلا إذا تم الإرشاد والرقابة بكيفية الاستخدام للجهاز من قبل شخص مسؤول عن سلامتهم. 25. يجب مراقبة الأطفال حتى يتم التأكد من عدم عبث الأطفال بهذا الجهاز.

- قم بحفظ كل أغلفة الجهاز بعيدا عن الأطفال لتجنب خطر الاختناق.
- احمي الأطفال من خطر الحرق وذلك بلمس الكابيس الساخن جدا في أسفل موحرة الثلاجة.
- لا تضع أشياء على الثلاجة وذلك لإحتمال الإصابة في حالة وقوعها.
- يجب عدم ترك الأطفال اللعب بالثلاجة وذلك بالاتعلق أو الوقوف على الباب، الأدراج، أو الرفوف الخ.

السلامة من الكهرباء

- لتجنب المخاطر التي تكون دائما موجودة عند استخدام الأجهزة الكهربائية، نحن ننصح تولى اهتماما أكبر للتعليمات حول الكهرباء أدناه.

- فك حزم الجهاز والتحقق من خلال الجهاز. يجب أن يكون واضحا أي ضرر، لا توصل الأجهزة ولكن اتصل فوراً بالمثل الذي اشتريت منه. إبقاء كل مواد التعبئة والتغليف في هذا
- ننصح الانتظار لمدة 4 ساعات قبل توصيل الأجهزة للسماح لغازات التبريد في التدفق الى الضاغط.

- | | |
|----------------------------|---|
| 1.....مقدمة قصيرة. | 8.....استخدام التلاجة الكهربائية الخاصة بك. |
| 1.....تعليمات سلامة هامة. | 11.....تلميح ونصائح مفيدة. |
| 3.....تركيب الجهاز الجديد. | 12.....التنظيف والرعاية. |
| 5.....وصف الجهاز. | 13.....إستكشاف الأخطاء وإصلاحها. |
| 6.....عرض عناصر التحكم. | 15.....التخلص من التلاجة. |

ملاحظة CE

هذا المنتج تم تعيينه ليكون متماثل مع توجيهات لتيار كهربائي منخفض (CE/95/2006)، توجيهات الامتثال لتوافق الكهرومغناطيسي (CE/108/2004) وتوجيهات التصميم الاقتصادي (EC/125/2009) المنفذ من قبل لائحة (EC) رقم 2009/643 للاتحاد الأوروبي.


مقدمة قصيرة

- نشكركم لإختياركم منتجات هاي سنز. نحن متأكدين من أنك سوف تجد جهازنا الجديد ممتع الاستخدام، قبل استخدام الجهاز، ننصحك بقراءة هذا الدليل بدقة، والذي سوف يوفر لك معلومات عن استخدام الجهاز وخصائصه.
- الرجاء التأكد من أنك كل الأشخاص الذين يستخدمون هذا الجهاز على دراية بطريقة تشغيله وكذلك مميزات السلامة الخاص به. من المهم أن يتم تثبيت الجهاز بطريقة صحيحة والانتباه الى تعليمات السلامة بحذر.
- ننصحك أن تبقى دليل المستخدم مع الجهاز كمرجع في المستقبل واعطاه الى أي مستخدمين لهذا الجهاز في المستقبل.
- الجهاز مخصص للإستخدام المنزلي والتطبيقات المماثلة مثل:
 - منطقة موظفين المطبخ في المحلات، المكاتب وغيرها من أماكن العمل.
 - منازل المزارع والزبائن في الفنادق الصغيرة وغيرها من أماكن الإقامة.
 - البيئات الفرش والأفطار.
- إذا شعرت أن الجهاز لا يعمل بشكل صحيح، الرجاء انظر في صفحة مشاكل وحلول للمساعدة. إذا مازلت تشعر بشك قم بالاتصال مع خدمات العملاء للمساعدة او لترتيب إرسال مهندس لمساعدتك.

تعليمات سلامة هامة

السلامة العامة والاستخدام اليومي

- أنتبه ان لا تتلف انابيب دارة التبريد.
- لا تضع الكثير من الطعام مباشرة ماقبل لفتحات الهواء على الجدار الخلفي لحرارة التبريد والتلجيج، والتي قد تضر بكفاءة دوران الهواء.
- لا تضع اشياء ساخنة بالقرب من المكونات البلاستيكي للجهاز.
- الطعام المجمد يجب عدم تجميده مرة اخرى بعد إذابته.
- لا تحفظ قوارير المشروبات او العلب (خصيصا المشروبات الغازية) في حجرة التجميد. العلب والقوارير قد تنفجر.
- لا تستخدم المصاصات او مكعبات الثلج مباشرة من الفريزر والتي قد تتسبب بحرق جلدي للحم او الشفتين.
- لتجنب سقوط اشياء وإحداثا إصابات او ضرر بلاجهاز، لا تحمل أدرج الباب للثلاجة او وضع الكثير من الطعام في أدرج الهشة.
- من المهم استخدام هذا الجهاز بأمان. ننصحك بإتباع النصائح التالية:
 - قم بحفظ أي طعام بالاتفاق مع تعليمات الحفظ للمصنع.
 - لا تستخدم أجهزة ميكانيكية أو أي وسائل أخرى لتسريع إذابة الثلج، إلا إذا كان ذلك موصى به من قبل الشركة الصانعة.
 - لا تستخدم الأجهزة الميكانيكية أو أية وسيلة أخرى لتسريع عملية الذوبان، ما لم يتم الموافقة عليها من قبل الشركة المصنعة.
 - برجاء مراعاة عدم إتلاف الأنابيب في دائرة المبرد.
 - لا تحاول إصلاح الجهاز بنفسك. فمن الخطورة بمكان أن يغير مواصفات المنتج أو تعديل هذه بأي شكل من الأشكال. أي الأضرار تلحق بكيبال الطاقة قد يؤدي الى ماس كهربائي، حريق أو صدمة كهربائية.



الطراز: RFHA-FD710NDS