



ثلاجة عرض

دليل المستخدم

<mark>ال</mark>موديل:

USC1100 ⁴

USC595 A

USC465 A

USC325 A

الرج<mark>اء قراءة هذا الدليل بعناية قبل تشغي</mark>ل الجهاز، واحتفظ به للرجوع إليه مستقبلاً.

هذه التصاميم و الم<mark>واصفات عرضة للتغيير بهدف إدخال</mark> تحسينات عليها وذلك دون إشعار فسبق.

ISO9001 (B

Showcase

User's Manual

Models:

- ▲ USC1100
- △ USC595
- △ USC465
- △ USC325

Please read this manual carefully before operating your set.
Retain it for future reference.

Designs and specifications are subject to change for improvement without prior notice.

ISO9001 (B







Models: USC1100 USC595 USC465 USC325

CONTENTS

SAFETY AND WARNING INFORMATION 7-11
HOW TO USE ———— 8
DEFROSTING / FIRST USE AND INSTALLATION9
IN CASE THE FOLLOWING OCCURS —————— 11-12

PARTS NAME AND FUNCTION ————————————————————————————————————	-
SPECIFICATIONS ————————————————————————————————————	
TEMPERATURE ADJUSTMENT AND DESCRIPTION OF APPLIANCE	5
DISPOSAL OF THE APPLIANCE	ò

SAFETY AND WARNING INFORMATION

For your safety and correct usage, before installing and first using the appliance, read this user manual carefully, including its hints and warnings. To avoid unnecessary mistakes and accidents, it is important to make sure that all people using the appliance are thoroughly familiar with its operation and safety features. Save these instructions and be sure that they remain with the appliance if it is moved or sold, so that anyone using it throughout its life will be properly informed on usage and safety notices. For the safety of life and property, keep the precautions of these user's instructions as the manufacturer is not responsible for damages caused by omission.

Safety for children and others who are vulnerable

- According to EN standard This appliance can be used by children aged from 8 years and above and persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved. Children shall not play with the appliance. Cleaning and user maintenance shall not be made by children without supervision.
- •According to IEC standard
 This appliance is not intended
 for use by persons (including
 children) with reduced
 physical, sensory or mental
 capabilities, or lack of
 experience and knowledge,
 unless they have been given
 supervision or instruction
 concerning use of the
 appliance by a person
 responsible for their safety.

concerning use of the appliance by a person responsible for their safety.

- Keep all packaging away from children as there is risk of suffocation
- If you are discarding the appliance, pull the plug out of the socket, cut the connection cable (as close to the appliance as you can) and remove the door to prevent children playing from suffering an electric shock or from closing themselves inside.
- If this appliance, featuring a magnetic door seals, is to replace an older appliance having a spring lock (latch) on the door or lid, be sure to make the spring lock unusable before you discard the old appliance. This will prevent it from becoming a death trap for a child

General safety

This appliance is intended to be used in households and similar applications such as -staff kitchen areas in shops, offices and other working environments:

- -farm houses and by clients in hotels, motels and other residential type environments:
- -bed and breakfast type environments;
- -catering and similar nonretail applications
- WARNING Do not store explosive substances such as aerosol cans with a flammable propellant in this appliance.
- WARNING —If the supply cord is damaged, it must be replaced by the manufacturer, its service agent or similarly qualified persons in order to avoid a hazard.
- WARNING Keep ventilation openings in the appliance enclosure or in any built-in structure clear of obstruction.
- •WARNING Do not use mechanical devices or other means to accelerate the defrosting process, other than those recommended by the manufacturer.
- WARNING Do not damage the refrigerant circuit.
- •WARNING Do not use electrical appliances inside the food storage compartments of the appliance, unless they are of the type recommended by the manufacturer.

- •WARNING The refrigerant and insulation are flammable. When disposing of the appliance, do so only at an authorized waste disposal center. Do not expose to flame.
- •WARNING —When positioning the appliance, ensure the supply cord is not trapped or damaged.
- •WARNING —Do not locate multiple portable socket-outlets or portable power supplies at the rear of the appliance.
- WARNING—Damaged supply cord must be repalced by a special cord or assembly available from the manufacture or its service agent.

Replacing the LED light:

© Alhafidh Group Trading fzco. 2021

•WARNING — The LED light must not be replaced by the user! If the LED light is damaged, contact the customer helpline for assistance.

Refrigerant

The refrigerant isobutene (R600a/R134) is contained within the refrigerant circuit of the appliance, a natural gas with a high level of environmental compatibility, which is nevertheless flammable. During transportation and installation of the appliance, ensure that none of the components of the refrigerant circuit becomes damaged.

The refrigerant (R600a) is flammable.

 WARNING — Refrigerators contain refrigerant and gases in the insulation. Refrigerant and gases must be disposed of professionally as they may cause eye injuries or ignition. Ensure that tubing of the refrigerant circuit is not damage prior to proper disposal.



Warning: risk of fire/ flammable materials

If the refrigerant circuit is damaged:

- -Avoid naked flames and sources of ignition.
- -Thoroughly ventilate the room in which the appliance is situated.

It is dangerous to alter the specifications or modify this product in any way.

Any damage to the cord may cause a short circuit, fire, and/or electric shock.

Electrical safety

- 1. The power cord must not be lengthened.
- 2. Make sure that the power plug is not crushed or damaged. A crushed or damaged power plug may overheat and cause a fire.
- 3. Make sure that you can access the main plug of the appliance.
- 4. Do not pull the main cable.
- 5. If the power plug socket is loose, do not insert the power plug. There is a risk of electric shock or fire.
- 6. You must not operate the appliance without the interior lighting lamp cover.
- 7. The fridge is only supplied with power supply of single phase alternating current of 220 ~ 240 V/50Hz. If fluctuation of voltage in the district of user is so large that the voltage exceeds the above scope, for safety sake, be sure to apply A.C.

www.alhafidh.com

Automatic voltage regulator of more than 350W to the fridge. The fridge must employ a special power socket instead of common one with other electric

appliances. Its plug must match the socket with ground wire.

Daily use

- Do not store flammable gas or liquids in the appliance. There is a risk of an explosion.
- Do not operate any electrical appliances in the appliance (e.g. electric ice cream makers, mixers etc.).
- When unplugging always pull the plug from the mains socket, do not pull on the cable.
- Do not place hot items near the plastic components of the fridge.
- Do not place food products directly against the air outlet on the rear wall.
- Store pre-packed frozen food in accordance with the frozen food manufacturer's instructions.
- The manufactures storage recommendations should be

- strictly adhered to. Refer to relevant instructions for storage.
- Do not place carbonated or fizzy drinks in the freeze compartment as it creates pressure on the container, which may cause it to explode, resulting in damage to the appliance.
- Frozen food can cause frost burns if consumed straight from the freezer compartment.
- Opening the door for long periods can cause a significant increase of the temperature in the compartments of the appliance.
- Clean regularly surfaces that can come in contact with food and accessible drainage systems.
- Store raw meat and fish in suitable containers in the refrigerator, so that it is not in contact with or drip onto other food.
- If the refrigerating appliance is left empty for long periods, switch off, defrost, clean, dry, and leave the door open to prevent mould developing within the appliance.
- •Do not place the appliance in direct sunlight.

© Alhafidh Group Trading fzco. 2021

- Keep burning candles, lamps and other items with naked flames away from the appliance so that do not set the appliance on fire.
- The appliance is intended for keeping food and/or beverages in normal households as explained in this instruction booklet.
 The appliance is heavy.
 Care should be taken when moving it.
- Do not remove or touch items from the freezer compartment if your hands are damp/wet, as this could cause skin abrasions or frost/freezer burns.
- Never use the base, drawers, doors etc. to stand on or as supports.
- •Frozen food must not be refrozen once it has been thawed out.
- •Do not consume ice popsicles or ice cubes straight from the freezer as this can cause freezer burn to the mouth and lips.
- •To avoid items falling and causing injury or damage to the appliance, do not overload the door racks or put too much food in the crisper drawers.

Caution! Care and cleaning

- Before maintenance, switch off the appliance and disconnect the mains plug from the mains socket.
- Do not clean the appliance with metal objects, steam cleaner, ethereal oils, organic solvents or abrasive cleansers.
- Do not use sharp objects to remove frost from the appliance. Use a plastic scraper.

Installation important!

- •For electrical connection carefully, follow the instructions given in this manual.
- Unpack the appliance and check if there are damages on it. Do not connect the appliance if it is damaged.
 Report possible damages immediately to the place you bought it. In this case retain packing.
- •It is advisable to wait at least four hours before connecting the appliance to allow the oil to flow back in the compressor.

- Adequate air circulation should be allowed around the appliance reducing the risk of overheating. To achieve sufficient ventilation, follow the instructions relevant to installation.
- •Wherever possible the back of the product should not be close to a wall to avoid touching or catching warm parts (compressor, condenser) to prevent the risk of a fire, follow the instructions relevant to installation
- The appliance must not be locate close to radiators or cookers.
- Make sure that the mains plug is accessible after the installation of the appliance.
 Service
- Any electrical work required to do the servicing of the appliance should be carried out by qualified electrician or competent person. This product must be serviced by an authorized Serviced Center, and only genuine spare parts must be used.

Note: Children aged from 3 to 8 years are allowed to load and unload refrigerating appliances. (This clause applies only to the EU region.)

When refrigerating food, please be careful not to contact the surface of the inner box directly.

When frozen food, in order to prevent moisture loss, prevent the odor, should separate the different food sealed storage, and can only use non-toxic, tasteless, impermeable, waterproof sealing material.

Hot food should be cooled to room temperature first, then put into the freezer, otherwise it will affect the storage status of other foods and increase the power consumption.

Two-star frozen-food compartments are suitable for storing pre-frozen food, storing or making icecream and making ice cubes.

One-, two-and three-star compartments are not suitable for the freezing of fresh food.

Order	Compartments TYPE	Target storage temp.[℃]	Appropriate food	
1	Fridge	+2≤ +6	Eggs, cooked food, packaged food, fruits and vegetables, dairy products, cakes, drinks and other foods are not suitable for freezing.	
2	(***)*-Freezer	≤ -18	Seafood (fish, shrimp, shellfish), freshwater aquatic products and meat products (recommended for 3 months, the longer the storage time, the worse the taste and nutrition), suitable for frozen fresh food.	
3	***-Freezer	≤ -18	Seafood (fish, shrimp, shellfish), freshwater aquatic products and meat products (recommended for 3 months, the longer the storage time, the worse the taste and nutrition), are not suitable for frozen fresh food.	
4	**-Freezer	≤ -12	Seafood (fish, shrimp, shellfish), freshwater aquatic products and meat products (recommended for 2 months, the longer the storage time, the worse the taste and nutrition), are not suitable for frozen fresh food.	
5	*-Freezer	≤ -6	Seafood (fish, shrimp, shellfish), freshwater aquatic products and meat products (recommended for 1 months, the longer the storage time, the worse the taste and nutrition), are not suitable for frozen fresh food.	

© Alhafidh Group Trading fzco, 2021



HOW TO USE

This appliance is intended to be used in household and similar applications such as

- staff kitchen areas in shops, offices and other working environments;
- farm houses and by clients in hotels, motels and other residential type environments;
- bed and breakfast type environments;
- -catering and similar non-retail applications

BEFORE USE

- Remove shipping package, tape, etc. and leave doors open for a while in order to ventilate the appliance.
- The unit is cleaned before shipment. However, it is recommended toclean the compartment interior once after delivery.
- Please insert power supply plug into the wall outlet, type "grounded single-phase 220-240 V".
- Allow the unit to operate for about 1 hour to cool the compartment before placing items into the appliance.

WAIT 5 MINUTES OR MORE BEFORE RE-STARTING

 Restarting the unit immediately after it has been turned off may cause fuses to blow and activate the circuit-breaker, the compressor may become overloaded, and/or other damage may occur.

EFFICIENT USE

Please follow the following instructions, in order to save energy consumption.

- To prevent cold air escaping from the chest freezer, open and close the door quickly and keep the door opened for as short time period as possible.
- Please install the unit in a well-ventilated location.
- Do not use the unit to store water or food that requires water as a storage medium. Never place fresh seafood containing water directly into the unit.

CHECKS

To ensure the safety, perform the following checks after cleaning the unit:

- Is the power cord plug firmly inserted into a dedicated wall outlet? Confirm that the plug is not abnormally hot.
- Check the power cord for cracks and damage. Should the slightest irregularity be observed, contact the dealer from whom you purchased this unit or our customer service department.

CLEANING AND DEFROSTING

To prevent any electrical shock hazards or injury by the rotating circulation fan, disconnect the power cord plug from the wall outlet before cleaning.

EXTERIOR

Wipe with a soft, dry cloth. If very soiled, wipe with a cloth that has been moistened with detergent Then wipe with a cloth that has been dipped in clean water.

WARNING

Do not splash water directly onto the chest freezer and do not wash with water. A short-circuit and/or electrical shock could be caused.

- Clean the cooler regularly to keep it clean at all times.
- Never use polishing powder, soap powder, benzine, oil or hot water as these will damage the painting and plastic components.
- Keep ventilation openings, in the appliance enclosure or in the built-in structure, clear of obstruction.
- Open the door and wipe clean with a dry cloth.



DEFROSTING/FIRST USE AND INSTALLATION

You should defrost the freezer compartment two or three times a year when the ice is about 4 mm thick. To defrost, follow these steps:

- Set the thermostat to "Colder" at least 12 hours before defrosting.
- After this period has elapsed, switch off the freezer compartment by removing the plug from the main power supply.
- Remove all food from the freezer and wrap them in paper and store them in a cold place and leave the door open.
- When the defrosting is finished, the compartment must be cleaned and wiped dry.
- Switch the appliance back on using the thermostat set to "Colder"and, wait at least one hour before replacing the foodstuffs.
- After a few hours the thermostat can be set back to the original position.

WARNING:

Do not use mechanicals devices or other artificial means to accelerate the defrosting process, other than those recommended by the manufacturer.

WARNING:


Do not use electricals appliance inside the food storage compartment of the appliances, unless they are of the type recommended by the manufacturer.

Cleaning before use

© Alhafidh Group Trading fzco. 2021

Before using the appliance for the first time, wash the interior and all internal accessories with lukewarm water and some neutral soap so as to remove the typical smell of a brand new product, then dry thoroughly.

Important! It is necessary to have good ventilation around the freezer to allow for the dissipation of heat, high efficiency, and low power consumption. For this reason, sufficiently cleared space should be available around the freezer. It is advisable for there to be 75mm separating the back of the freezer to the wall and at least 100mm of space on its two sides, a height of over 100mm from its top.



Climate class	Ambient temperature
SN	+10°C to +32°C
N	+16°C to +32°C
ST	+16°C to +38°C
Т	+16°C to +43°C

Appliances must not be exposed to rain. Sufficient air must be allowed to circulate in the lower rear section of the appliance, as poor air circulation can affect perfor-mance. Built-in appliances should be positioned away from heat sources such as heaters and direct sunlight.

Leveling

The appliance should be level in order to eliminate vibration.

To make the appliance level, it should be upright and both adjusters should be in stable contact with the floor.

You can also adjust the level by unscrewing the appropriate level adjustment in the front (use your fingers or a suitable spanner).

IN CASE THE FOLLOWING OCCURS

Warning! Before trouble-shooting, disconnect the power supply. Only a qualified electrician or

other person must carry out the trouble-shooting that is not in the manual.

Important!

Repairs to the appliance may only be performed by competent service engineers. Improper repairs can give rise to significant hazards for the user. If your appliance needs repairing, please contact your specialist dealer or your local Customer Service Center.

Problem	Solution
	Keep the opening and closing of the door for a minimum time to prevent cold air from escaping.
POWER FAILURE	Avoid placing new items in the cooler as this will raise the temperature inside the compartment.
	In case of a long power suspension, place dry ice in the freezer
POWER CORD	If the supply cord is damaged. It must be replace by a special cord or assembly available from the manufacturer or the service agent.
PROBLEMS	The showcase must be positioned so that the plug is accessible to the wall outlet.
	Remove all items from the compartment and disconnect the power cord plug from the wall outlet.
WHEN NOT USED	Clean the compartment interior and wipe away all water.
FOR A LONG PERIOD	To prevent mold formation and foul odors, leave the door open to dry the compartment completely.
	Disconnect the power cord plug from the wall outlet.
TRANSPORTATION	When moving the appliance, make sure that the feet do not damage the power cord
	Do not let the feet hit against floor steps, thresholds, etc.
`	Put piece of wood or other similar item between, the door and main unit to prevent complete closing of the door.
TEMPORARY STORAGE	Be sure not to store the unused chest freezer in a location where children play.
	Should a child enter the compartment and the door is closed, the child may not be able to open the door from the inside.

www.alhafidh.com

Please check the following if you encounter problems with the unit. If the problem continues after taking the proper remedial actions, disconnect the power cord plug from the wall outlet.

Transfer the items stored in the cooler to a box or other container. Then contact the dealer from whom you purchased this unit ,and be ready to provide information as listed in the "REQUIRED INFORMATION" below.


To prevent any electrical shock hazards, do not disconnect the power cord plug from the wall outlet with wet hands.


	Is the power supply interrupted?	
No refrigeration at all	Is the power cord plug disconnected from the wall outlet?	
	Are the shop's power fuses blown and/or the circuit breaker activated?	
	Is the temperature control turned to OFF?	
	Is the place of installation ventilated?	
Inadequate	Is the freezer exposed to direct sunlight, placed near a heater or stove?	
refrigeration	Are the lids opened and closed frequently?	
	Is the temperature control dial in the direction of Colder . If it is too cold, turn dial in direction of Cold .	
	Is a lot of frost forming in the freezer compartment?	
	Is the floor underneath the freezer sturdy enough?	
Excessive noise	Is the unit shaking and/or rattling?	
Excessive noise	Is the rear panel of the unit in contact with a wall, etc.?	
	Is there a container or something behind the freezer? The compressor will generate a rather loud sound for a while after operation is started. The noise will cease together with refrigeration.	
Condensation on cooler exterior Wipe away condensation with a dry cloth. Condensation on cooler exterior Condensation on days or depending on the place of installation. This occurs humidity is high and water particles in the cold surfaces. This is norm with a dry cloth.		
The circumference of chest freezer feels hot	Especially in summer or in the period of starting running, the circumference of the chest freezer feels hot because the Chest freezer inside has a pipe for radiating and preventing condensation. The heat does not affect inside goods.	

© Alhafidh Group Trading fzco. 2021

PARTS NAME AND FUNCTION

Model NO: USC-325 / USC-465









12

The above image is for reference only, configaration is subject to actial product.

Model NO: USC-595 / USC-1100





The above image is for reference only, configaration is subject to actial product.

SPECIFICATIONS

Product Name	SHOWCASES			
Product No.	USC-325 / USC-465 / USC-595			
Outer Dimensions	Width Depth Height			
(mm)	540/540/600 575/615/670 1809		1805/1985/2108	
Net Weight	54Kg/60Kg/74Kg			
Provided accessories	3 shelves/ 4 shelves/ 5 shelves			
Performance	Actual compartment temperature 0-10 $^{\circ}$ C (ambient temperature ST38 $^{\circ}$ C (7(T)43 $^{\circ}$ C)), humidity 65%, unloaded state, not exposed to direct sunlight)			

Product Name	SHOWCASE			
Product No.		USC-1100		
Outer Dimensions	Width	Depth	Height	
(mm)	1010	710	2060	
Net Weight		153Kg		
Provided accessories		7 shelves		
Performance	Actual compartment temperature 0-10°C (ambient temperature ST38°C ($7/43$ °C)), humidity 65% unloaded state, not exposed to direct sunlight)			

The specifications may change please refer to the circuit name plate on the back of your




The thermost in the factory has been transferred to the best position, generally do not need to do adjustment.

TEMPERATURE ADJUSTMENT AND DISCRIPTION OF APPLIANCE

TEMPERATURE ADJUSTMENT

- . Thermostat was adjusted using temperature at factory So, please do not touch it. Excessive refrigeration will increase electricity consumption unnecessarily.
- . If need to adjust the temperature, please open the door, and turn the temperature control dial in the direction of MAX.If too cold.turn dial in the direction of MIN.
- When you need the unit to stop running temporally, please turn the temperature control dial in the direction of 0/Off.



DISCRIPTION OF APPLIANCE

Installation Any electrical work that is required to install this appliance MUST be carried out by a qualified electrician

Warning: THIS APPLIANCE MUST BE GROUNDED

Before making any electrical connections, ensure the following: Electrical connection

Electrical safety is only guaranteed when the grounding system of your house is in accordance with the related local régulations.

Do not damage the refrigerant circuit.

© Alhafidh Group Trading fzco, 2021

Reproduction in whole or in part is strictly prohibited

Do not bend, stretch or pull the supply cable to avoid electric shock

Do not use electrical appliances inside the food storage compartments of the appliance, unless they are of the type recommended by the manufacturer.

Ensure the power socket is suitable for the maximum power of the machine (fuses in the power circuit must be 13 amp).

The supply voltage should be the same as that indicated in the technical specifications and the appliance rating plate.

The appliance should be grounded and in compliance with the applicable laws.

When installed, the power socket must be within easy reach.

If the socket outlets in your home are not suitable for the plug supplied with this unit check with a qualified electrician for replacement.

The use of adapters, multiple connectors or extension cables is not recommended.

The appliance must be connected to a 220-240 volt 50Hz AC supply by means of a three-pin socket, suitably grounded and protected by a 13 amp fuse.

Should the fuse need to be replaced, a 13 amp fuse approved to BS1363/A standards must be used.

The plug contains a removable fuse cover that must be refitted when the fuse is replaced. If the fuse cover is lost or damaged, the plug must not be used until a replacement cover has been fitted or the plug is replaced.

A damaged plug should be cut off as close to the plug body as possible, the fuse should be removed and the plug disposed of safely

Plug replacement (UK & Ireland only)

Should you need to replace the plug, the wires in the power cable are coloured in the following way:

Blue - Neutral 'N'

Brown - Live 'L'

Green & Yellow - Earth 'E'

As the colours of the wires in the power cable may not correspond with the coloured markings identifying the terminals in your plug, and proceed as follows:

The green & yellow wire must be connected to the terminal in the plug that is marked with the letter E or by the earth symbol.

The blue wire must be connected to the terminal that is marked with the letter'N'

The brown wire must be connected to the terminal that is marked with the letter 'L'.

If power supply cord is damaged, it must replaced by the manufacturer or its service agent or a similar qualified person in order to avoid a hazard.



The specifications may change, please refer to the circuit name plate on the back of your chest.

DISPOSAL OF THE APPLIANCE

Disposal of the appliance

It is prohibited to dispose of this appliance in domestic household waste. Packaging materials

Packaging materials with the recycle symbol are recyclable. Dispose of the packaging in a suitable waste collection container to recycle it. Before disposal of appliance.

- 1. Disconnect the main plug from the main socket.
- 2. Cut off the main cable and discard it.

Correct disposal of this product



This symbol on the product, or in its packaging, indicates that this product may not be treated as household waste, Instead, it should be taken to the appropriate waste collection point for the recycling of electrical and electronic equipment. By ensuring this product is disposed of correctly, you will help prevent potential negative consequences for the environment and human health, which could otherwise be caused by the inappropriate waste handing of this product. For more detailed information about the recycling of this product, please contact you local council, your household waste disposal service, or the store where you purchased the product.

© محموعة الحافظ للتحارة .2021 fzco

الأستنساخ كليآأو حزئياً فمنوع فنعاباتاً

التخلص من المنتج

التخلص من المنتج يُحضِّر التخلص من هذا الجهاز مع النفايات المنزلية. مواد التعبئة والتغليف مواد التعبئة والتغليف التي تحمل رمز إعادة التدوير قابلة لإعادة التدوير، تخلص من مواد التعبئة والتغليف في حاوية جمع النفايات المناسبة لإعادة تدويرها. قبل التخلص من الوحدة. 1 – افصل القابس الرئيسي من المقبس الرئيسي.

2 – اقطع الكابل الرئيسي وتخلص فنه. 2 – اقطع الكابل الرئيسي

الطريقة السليمة للتخلص من المنتج



يشير هذا الرمز الموجود على المنتج أو على عبوته إلى أنه لا يجوز التعامل مع مذا المنتج بوصفه نفايات منزلية، بل يجب نقله إلى نقطة تجميع النفايات المناسبة لإعادة تدوير المعدات الكهربائية والإلكترونية. من خلال ضمان تخلصك من هذا المنتج بشكل صحيح، سوف تساعد في منع النتائج السلبية المحتملة على البيئة وعلى صحة الإنسان، والتي قد تنجم عن التخلص الخاطئ من هذا المنتج. للاطلاع على معلومات أكثر تفصيلاً بخصوص إعادة تدوير هذا المنتج، يرجى الاتصال بمكتب المجلس المحلي أو خدمة التخلص من النفايات المنزلية في بلدك أو المتحر الذي اشتريت منه هذا المنتج.

المواصفات

مبرد المشروبات		اسم, المنتج		
US	SC-595 / USC-465 / USC	325	رقم المنتج	
الارتفاع	العمق	العرض	الأبعاد الخارجية (فلف)	
1805/1985/2108	805/1985/2108 670/615/575 2108/1985/1805		(, - <u></u> ,	
74Kg/60Kg/54Kg		الوزن الصافي		
3 رفوف/ 5 رفوف		الملحقات المرفقة		
درجة الحرارة الفعلية 1-10 درجات مئوية (درجة الحرارة المحيطة دون الاستوائية 38 درجة مئوية (7 (استوائية)/ 43 درجة مئوية)، الرطوبة 26٪، حالة النفريغ، غير معرضة لاشعة الشمس المباشرة)		الأداء		

اسم المنتج	مبرد المشروبات		
رقم المنتج		USC-1100	
الأبعاد الخارجية (ملم)	العرض	العمق	الارتفاع
	1010	710	2060
الوزن الصافي	153Kg		
الملحقات المرفقة	7 رفوف		
الأداء	درجة الحرارة الفعلية 0-10 درجات متُوية (درجة الحرارة المحيطة دون الاستوائية 38 درجة متُوية (استوائية/ 43 درجة متُوية)، الرطوبة 26٪، حالة التفريخ، غير معرضة لاشعة الشمس المباشرة)		

www.alhafidh.com

🚺 تم ضبط الثرمو</mark>ستات في المصنع بأفضل وضع ممكن، وهو بشكل عام، لا يحتاج إلى الضبط

🚺 المواصفات أعلاه عرضة للتغيير، يرجى الرجوع إلى لوحة بيانات الدائرة الموجودة على الجزء الخلفي للجهاز.


ضبط درحة الحرارة ووصف الوحدة

ضبط درحة الحرارة

• تم ضبط الثرموستات باستخدام درجة الحرارة في

لذا، يرحى عدم لمسه. يؤدي التبريد المفرط إلى زيادة استهلاك الكهرباء دون داع.

- عند الحاحة إلى ضبط درحة الحَرارة، برحى فتح البات وإدارة قرص التحكم في درجة الحرارة في اتحاه MAX. إذا كانت درجة الحرارة شديدة البرودة، فأدر القرص في اتحاه MIN.
- عندما تُحتَاج إلَّى تعطيل الوحدة مؤقتاً، يرجى إدارة قرص التحكم في درحة الحرارة في اتحاه 0/



وصف الوحدة

التركيب: يجب أن يُنفِّذ أي عمل كهربائي مطلوب لتركيب هذه الوحدة بواسطة كهربائي فؤهل. تحذير: بحب تأريض هذه الوحدة.

قبل إجراء أي توصيلات كهربائية، تأكد فما يلي: التوصيل الكهربائي

يحرى ضمان السلاقة الكهربائية فقط عندما يكون نظاقم التأريض في منزلك متوافقاً مع اللوائم المحلية ذات الصلّة.

يُحظر إتلاف دائرة التبريد.

© محموعة الحافظ للتحارة .2021 fzco

الأستنساخ كليآ أو حزئياً فمنوع فنعآباتاً

يُحظر ثني كابل الإقداد بالطاقة أو تمديده أو سحيه؛ لتحنب حدوث صدمة كهربائية.

بحظر استخدام الأدوات الكهربائية داخل حجرات تخزين الطعام في الثلاحة، إلا إذا كانت من الأنواع التور توصوريها جّهة التصنيع.

تأكد من أن مقيس الطاقة مناسب لاستبعاب أقصى طاقة للحهاز (بحب أن تكون المصهرات في الدائرة الكهربائية ١٣ أميير).

بحب أن يكون حهد الإمداد هو نفسه الموضح في المواصفات الفنية ولوحة تصنيف الوحدة. بحب أن تكون الوحدة مؤرضة وممتثلة للقوانين المعمول بها.

عند التركيب، احرص على سهولة الوصول إلى مقيس الطاقة.

اذا كانت منافذ المقيس في منزلك غير مناسبة للقايس المرفق مع هذه الوّحدة، فاستشر كهربائياً مؤهلاً لاستبدالها.

لا يوصى باستخدام المهابئات أو الموصلات المتعددة أو كابلات التمديد.

بحب توصيل الوحدة بمصدر تبار فتردد 240-220 فولت 50 هرتز من خلال مقيس ثلاثي السنون، وتأريضها ىشكل فناسب وجمانتها بواسطة قصهر 13 أقبير. في حاّل الحاحة إلى استبدال المصهر، بحب استخدام مصهر 13 أمسر معتمد وفقاً لمعاسر A /BS1363. يحتوى القانس على غطاء قصهر قابل للإزالة يحب إعادة تركيبة عند استبدال المصهر. في حال فقدان غطاء المصهر أو تلفه، يجب عدم استخّدام القابس حتى يُركّب غطاء بديل أو يُستبدل القايس. بحب قطع القانس التالف بالقرب من حسم القانس قدر

الإمكان، وبحب إزالة المصهر والتخلص من القابس بأمان.

استبدال القابس (خاص بالمملكة المتحدة والإلندا فقط)

عند الحاحة الي استبدال القابس، تحد الأسلاك في كابل الطاقة فلونة بالطريقة التالية:

> الأزرق - محايد 'N' البني - بمريه تبار كهربائي (L' الأخضِّر والأصفر - أرضى E'"

نظراً لأن ألوان الأسلاك في كابل الطاقة قد لا تتطابق <mark>مع ا</mark> العلامات الملونة التي تحدد أطراف التوصيل في القانس الخاص بك، فأتبع ما بلي: بحب توصيل السلك الأخضر والأصفر بطرف القا<mark>بس</mark> المميز بالحرف E أو رفز التأريض. تحت توصيل السلك الأزرق بالطرف المميز با<mark>لحرف "N".</mark>

بحث توصيل السلك البنق بالطرف الم<mark>ميز بالحرف "L".</mark> في حال تلف سلك الكهرباء، يجب اس<mark>تيداله عن طريق</mark> حَقَّةَ التَصِنْيَعِ، أو وكبل الخَدَمَاتِ التَابِعِ لَهَا، أو الأَشْخَاصِ المؤهلين بنَّفس فستوى الكفاءة<mark>؛ لتحنُّب أي فخاطر.</mark>


> وصِّل السلك الأزرق بـ "N" - محا<mark>يد</mark> وصِّل السلك الأخضر/ الأصف<mark>ر بـ "E" أو - الأرض</mark> وصِّلَ السلك البنى بـ "L" <mark>- يمربه تيار كهربائي</mark>




المواصفا<mark>ت عرضة للتغيير، يرجى الرج</mark>وع إلى لوحة بيانات ا<mark>لدائرة الموجودة على الجزء</mark> الخلفى من الجهاز.

أسماء الأجزاء ووظائفها

رقم الطراز: USC-1100 / USC-595







الصور التوضيحية أعلاه هي لغرض الاط<mark>لاع فقط، ويجري التركيب حسب الم</mark>نتج الفعلي.

www.alhafidh.com

أسماء الأجزاء ووظائفها رقم الطراز: USC-465 / USC-325





الصور التوض<mark>يحية أعلاه هي لغرض الاطلاع فقط،</mark> ويجري التركيب حسب المنتج الفعلي.

www.alhafidh.com



في حال حدوث ما يلي

تحذير! قبل إصلاح الأعطال، افصل التيار الكهربائي. يجب أن يتولى كهربائي أو أي شخص مؤهل إصلاح الأعطال غير المذكورة في الدّليلُ.

المشكلة	الحل
	لا تفتح الباب وتغلقه كثيراً؛ لمنع تسرب الهواء البارد.
انقطاع التيار الكهربائي	تجنب وضع أصناف جديدة؛ لأن ذلك يرفع درجة الحرارة.
	في حال انقطاع التيار الكهربائي لفترة طويلة، ضع الثلج الجاف في الفريزر.
مشاكل سلك	في حال تلف سلك الكهرباء، يجب استبداله من قبل من جهة التصنيع أو وكيل الخدمة المعتمد.
الكهرباء	يجب وضع الجهاز في مكان تتام فيه إمكانية توصيل القابس بمنفذ الحائط.
	أخرج جميع العناصر من الجهاز وافصل قابس سلك الكهرباء من منفذ الحائط.
في حال عدم الاستخدام	نظَّف الجهاز من الداخل وأزل أي ماء موجود.
لفترة طويلة	اترك الباب مفتوحاً لتجفيف الداخل تماماً؛ لتجنب تكون العفن وانبعاث الروائم الكريهة.
	افصل قابس سلك الكهرباء من منفذ الحائط.
النقل	عند تحريك الوحدة، تأكد من ألا تتلف قدما الوحدة سلك الكهرباء.
	لا تجعل القدمين يصطدمان بالسلالم أو العتبات وما إلى ذلك.
التخزين المؤقت	ضع قطعة من الخشب أو أي عنصر مشابه بين الباب والوحدة الرئيسية؛ لمنع الإغلاق الكامل للباب.
	تأكد من عدم، تخزين الجهاز غير المستخدم، المستخدم، في مكان يلعب فيه الأطفال.
	إذا دخل الطفل وكان الباب مغلقاً، فقد لا يتمكن الطفل من فتع الباب من الداخل.

هام!

. لا يجوز إجراء إصلاحات في الوحدة إلا من قبل مهندسي الخدمة المؤهلين. تؤدي الإصلاحات غير السليمة إلى زيادة الأخطار الكبيرة على المستخدم. إذا احتاجت الوحدة إلى الإصلاحات، يرجى الاتصال بالوكيل المختص أو مركز الخدمة المعتمد.

جي التحقق فما يلي إذا واجهت فشاكل فع الوحدة. إذا استمرت المشكلة بعد اتحاذ الإجراءات
تصحيحية المناسبة، فافصل قابس سلك الكهرباء من منفذ الحائط.
قل الأصناف المخزنة في المبرد إلى صندوق أو حاوية أخرى. ثم اتصل بالـوكيل الذي اشتريت فنه هذه
وحدة، وكن مستعداً لتقديم المعلومات على النحو الوارد في "المعلومات المطلوبة" أدناه.
حنب خطر الصعق الكهابائي ، يُحظر فصل قايس سلك الكهرباء من منفذ الحائط بأيد مبللة.

	هل انقطع التيار الكهربائي؟		
انقطاع التيار الكهربائي	هل قابس سلك الكهرباء غير متصل بمنفذ الحائط؟		
الكهربائي	هل تلفت المصهرات المُورَّدة من المتجر و/ أو نشط قاطع الدائرة؟		
	هل ضُبطت درجة الحرارة على وضع "إيقاف التشغيل - OFF"؟		
	هل مكان التركيب جيد التهوية؟		
	هل الجهاز معرض لأشعة الشمس المباشرة أو مثبت بالقرب من سخان أو طباخ؟		
انقطاع التيار الكهربائي	هل تفتح الأغطية وتغلق بشكل متكرر؟		
	هل قرص التحكم في درجة الحرارة في اتجاه (Colder)؟ إذا كان شديد البرودة، فأدر القرص في اتجاه (Cold).		
	هل يتكون الكثير من الثلج في حجرة الفريزر؟		
	هل الأرضية الموجودة أسفل الجهاز متينة بدرجة كافية؟		
الضوضاء المفرطة	هل الوحدة تهتز و/ أو تتحرك؟		
, ,	هل اللوحة الخلفية للوحدة ملامسة للحائط، وما إلى ذلك؟		
	هل هناك وعاء أو شيء ما خلف الجهاز؟ يصدر الضاغط صوتاً مرتفعاً إلى حد ما لفترة بعد بدء التشغيل، وتتوقف <mark>هذه الضوضاء مع التبريد.</mark>		
التكثف على الجزء الخارجي للمبرد	قد يحدث التكثف على الجزء الخارجي من الـوحدة والباب خلال الأيام ا <mark>لحارة والرطبة أو حسب مكان</mark> التُركيب، وذلك عندما تكون الرطوبة عالية وتتكون جزيئات الما <mark>ء في الأسطح الباردة، هذا الأمر</mark> طبيعي. امسح التكثف باستخدام, قطعة قماش جافة.		
محيط الفريزر يبدو ساخناً	خاصة في فصل الصيف او في فترة بدء التشغيل، يبدو <mark>محيط الفريزر ساخناً لانه يحتوي م</mark> ن الداخل على انبوب للإشعاء ومنع التكثف. لا تَوَّثَر الحرارة على المواد الموجودة بالداخل. Pipe		



كيفية الاستخدام \int

هذه الوحدة فُصممة للاستخدام في الأغراض المنزلية والأغراض المماثلة مثل:

- المطابخ الخاصة بالعاقلين في المتاحر، والمكاتب، وبيئات العمل الأخرى.ّ
- السوت الملحقة بالمزارع، ومن قبَل النزلاء في الفنادق والموتيلات والبيئات السكنية الأخرى. – أماكن الإفطار والمبيت.
- خدمات المطاعم والتطبيقات المماثلة بخلاف تطبيقات البيع بالتحزئة.

تعليمات قبل الاستخدام

- أزل مواد التغليف والشريط وما الي ذلك، واترك الأبواب ففتوحة لبعض الوقت لتهوية الوحدة.
- تُنظِّف الوحدة قبل الشحن. وقع ذلك، يوصق يتنظيف الحجرة الداخلية مرة واحدة بعد التسلُّم.
 - يرجى إدخال قابس مصدر الطاقة في منفذ الحائط، من النوع "الأرضى الأحادي الطور 220-240 فولت".
- اترك الوحدة تعمل لمدة ساعة تقريباً لتبريد الحجيرة قبل وضع الأصناف بداخلها.

انتظر ٥ دقائق أو أكثر قبل إعادة التشغيل

• قد يؤدي إعادة تشغيل الوحدة فور إيقاف تشغيلها <mark>الى تلف ال</mark>مصهرات وتنشيط قاطع الدائرة، وقد يزيد <mark>الحمل على ا</mark>لضاغط و/ أو يُحدث تلفاً آخر.

الاستخدام الفعال

يرجى <mark>اتباع التعليم</mark>ات التالية لتوفير استهلاك

- افتح الياب وأغلقه يسرعة ولا تتركه مفتوحاً لفترة طويلة؛ لمنع تسرب الهواء البارد.
 - برحى تركيب الوحدة في مكان حيد التهوية.
- يُحظر استخدام الوحدة لتخزين الماء أو الطعام الذي يحتاج إلى الماء كوسيط تخزين. يُحظر وضع المأكولا<mark>ت البحرية الطازجة التي ت</mark>حتوي على الماء مباشرة داخ<mark>ل الوحدة.</mark>

عمليات الفحص

ضمان سلامة الوحدة، يحب إحراء عمليات الفحص لتالية بعد تنظيف الوحدة:

- · هل قايس سلك الكهرباء مثبت باحكام في منفذ لحائط المخصص؟ تأكد من أن القانس ليسّ ساخناً بشكل غير طبيعي.
- افحص سلكَ الكهرباء بحَّثاً عن أي شقوق أو تلف. في حال ملاحظة أي شيء بسيط غير مألوف، اتصل التوكيل الذي اشتريت قنه هذه الوحدة أو يقسم خدمة العملاء لدينا.

لتنظيف واذابة الثلج

تجنب خطر الصعق الكهربائي أو الإصابة بسبب مروحة توزيع الهواء الدوارة، افصّل قايس سلك الكهرباء من منفذ الحائط قبل التنظيف.

الجزء الخارجى

مسح الحزء الخارحي باستخدام قطعة قماش ناعمة وحافة. وإذا كآن متسخاً يشدة، فنظِّفه باستخدام قطعة قماش مبللة في منظف ثم امسحه بقطعة قماش مغمورة في الماء النظيف.

حظر رش الماء فناشرة على الحهاز أو غسله بالماء، خ قد پتسبب ذلك في حدوث قصر في الدائرة لكهربائية و/ أو صدمة كهربائية.

- نظِّف المبرد بانتظام للحفاظ على نظافته في
- يُحظر استخدام مسحوق تلميع أو مسحوق صابون أو ينزين أو زيت أو ماء ساخن؛ لأن ذلك يؤدي إلى تلف لطلاء والمكونات البلاستبكية.
 - حافظ على فتحات التهوية الموحودة في غلاف ِ دن الثلاجة أو الهيكل الداخلى لها من أي

، افتح الباب وامسحه باستخدام قطعة قماش جافة.

© Alhafidh Group Trading fzco. 2021
Reproduction in whole or in part is strictly prohibited

إذاية الثلج/ الاستخدام للمرة الأولى والتركيب

بحب إذابة الثلج من حجرة الفريزر مرتين أو ثلاث مرات في السنة عندما ببلغ سمك الثلج حوالي 4 ملم. لاذاَّية الثلج، اتبع الخُطوات التالية:

- اضبط الثرموستات على درجة أبرد COLDER قبل 12 ساعة على الأقل من إذاية الثلج.
- بعد انقضاء هذه المدة، أوقف تشغيل حجرة الفريزر عن طريق إزالة القايس من مصدر الطاقة
- أخرج جَميع الأطعمة من الفريزر ولفها في ورق واحفظها في مكان بارد واترك الباب مفتوحاً.
- عند الانتهاء من إذابة الثلج، بحب تنظيف الحجرة ومسحها حتى تحف.
- أعد تشغيل الوحدة مرة أخرى مع ترك الثرموستات مضبوطاً على درحة أبرد، وانتظر لمدة ساعة على الأقل قبل ادخال المواد الغذائية.
- بعد بضع ساعات، يمكن إعادة الثرموستات إلى الوضع الأصلى.

تحذى:


بحظر استخدام الأحهزة المبكانيكية أو غيرها من الوسائل الاصطناعية لتسريع عملية إذاية الثلج، باستثناء تلك الموصى بها من قبل جهة التصنيع.

بحظر استخدام الأدوات الكهربائية داخل حجرات تخزين الطعام في الثلاجة، إلا إذا كانت من الأنواع التي توصى بها جُهة التصنيع.

التنظيف قبل الاستخدام

قبل استخدام الوحدة للمرة الأولى ، اغسلها من الداخل واغسل حميع الملحقات الداخلية باستخدام الماء الفاتر وبعض الصابون المحايد لإزالة رائحة المنتج الجديد، وقرن ثمَّ حففها جيداً.

هام! من الضروري وحود تهوية حيدة حول الحهاز للسماح بتبديد الحرارة، والعمل بكفاءة عالية، واستهلاك الطاقة بشكل فنخفض. لذا، بحب ترك مساحة خالية يشكل كاف حول الفريزر. يوصي بترك مسافة 75 ملم بين الجزء الخلفي من الجهاز والحائط، ومسافة 100 ملم على الأقل من الحانيين، وارتفاع يزيد عن 100 ملم من أعلاه.



درجة الحرارة المحيطة	الفئة المناخية
+32°C to +10°C	SN
+32°C to +16°C	N
+38°C to +16°C	ST
+43°C to +16°C	Т

يحت ألا تتعرض الوحدة للمطر. يحت السمام يتوزيع نسبة كافية من الهواء في القسم السفلي ُلخلفوي للحهاز، لأن قلة نسبة الهواء الموزع تؤثر على الأداء. بحب وضع الأحهزة المدمحة بعيداً عن مصادر الحرارة مثل السخانات وأشعة الشمس المناشرة.

تسوية الجهاز

بحب أن يكون الجهاز مثبت على الأرض<mark> بشكل .</mark> مستوى لتحنب الاهتزازات. لضبط ال<mark>مستوى، ثبت</mark> الحهاز عُمودياً واضبط الأقدام الس<mark>فلية يحيث تكون</mark> متصلة بالأرض بشكل محكم.

بمكنك أيضاً استخدام البدين <mark>أو ففتاح ربط لإزالة .</mark> البراغي لضبط المستوى.

تنىيە!

التنظيف والعناية

- قم بإيقاف تشغيل الجهاز، وافصل قابس الإمداد بالتيار الكهربائي الرئيس من المقبس قبل إجراء الصيانة.
- لا تنظف الجهاز باستخدام مواد معدنية، أو جهاز التنظيف بالبخار، أو الزيوت الأثيرية، أو المذيبات العضوية، أو المنظفات القوية الكاشطة.
 - لا تستخدم مواد حادة لإزالة الثلج. استخدم مكشطة بلاستبكية.

ملاحظات مهمة عند التركيب!

- اتبع التعليمات المقدمة في هذا الدليل لإتمام التوصيل الكهربائي بعناية.
- قم بإفراغ الثلاجة وتُحقق من عدم وجود أي تلف بها. لا توصل الثلاجة بمصدر التيار الكهربائي إذا كانت تالفة. أبلغ الجهة التي اشتريت منها الثلاجة عن الأعطال المحتملة فور حدوثها. في هذه الحالة احتفظ بهواد التغليف.
- يُنصح بالانُتظار أربع ساعات على الأقل قبل توصيل الثلاجة بمصدر التيار الكهربائي للسماح للزيت بالتدفق في الضاغط.

- يجب أن تكون هناك تهوية جيدة حول الجهاز، وإذا لم يتوافر ذلك يتعرض الجهاز لارتفاع درجة الحرارة. اتبع التعليمات المتعلقة بالتركيب لتوفير التهوية الكافية.
- ينبغُي ألا يكون ظهر الجهاز قريباً جداً من الحائط قدر الإمكان لتجنب ملامسة الأجزاء الدافئة أو الإمساك بها (الضاغط، المكثف) لمنع خطر حدوث حربة، اتبع التعليمات المتعلقة بالتركيب.
 - يُحْظر وضْع الجهاز بجوار أجهزة التدفئة أو الطباخات.
 - تأكد أن قابس الإمداد بالتيار الكهربائي الرئيس يسهل الوصل إليه بعد تركيب الجهاز.

الصبانة

- يجب أن تكون هناك تهوية جيدة حول الجهاز، وإذا لم يتوافر ذلك يتعرض الجهاز لارتفاع درجة الحرارة. اتبع التعليمات المتعلقة بالتركيب لتوفير التهوية الكافية.
- ينبغي ألا يكون ظهر الجهاز قريباً جداً من الحائط قدر الإمكان لتجنب ملامسة الأجزاء الدافئة أو الإمساك بها (الضاغط، المكثف) لمنع خطر حدوث حريق، اتبع التعليمات المتعلقة بالتركيب.
 - يُحظر وضع الجهاز بجوار أجهزة التدفئة أو الطباخات.
 - تأكد أن قابس الإمداد بالتيار الكهربائي الرئيس يسهل الوصل إليه بعد تركيب الجهاز.

- ملاحظة: يمكن للأطفال الذين تتراوح أعمارهم بين 3 و8 سنوات تعبئة أجهزة التبريد وتفريغها. (ينطبق هذا البند فقط على منطقة الاتحاد الأوروبي).
- عند تبريد المواد الغذائية، يرجى الحرص على عدم ملامسة سطح الصندوق الداخلي مباشرة. من أجل منع فقدان الرطوبة الداخلية، يجب عند تجميد المواد الغذائية في الفريزر الحرص على فصل أنواع الطعام, كل نوع في وحدة تخزين منفصلة واستخدام, مواد تغليف غير سامة عديمة الطعم, مقاومة للماء وغير منفذة للرائحة.
- يجب تبريد الطعام الساخن أولاً إلى درجة حرارة الغرفة ثم وضعه في الفريزر حتى لا يؤثر على حالة تخزين الأطعمة الأخرى ويزيد من استهلاك الطاقة.
- حجرات الطعام المجمد ذات النجمتين مناسبة لتخزين الأطعمة المجمدة مسبقاً أو تخزين الآيس كريم. أو صنعها وصنع مكعبات الثلج.
 - لاً تُعد الحجُرات ذات النَّجمة الـوأحدة والنجمتين والثلاث نجوم مناسبةً لتجميد الطعام الطازج.

الطعام المناسب		درجة حرارة التخزين المستهدفة [درجة مئوية]	نوع الحجرة	التسلسل
لأطعمة المطبوخة، والأغذية المُعلبة، والفواكه ات، ومنتجات الألبان، والكيك، والمشروبات وغيرها من غير مناسبة للتجميد.	والخضراوا	+2≤ +6	الثلاجة	1
ت البحرية (السمك، الجمبري، المحار) ومنتجات اللحوم تخزينها لمدة 3 أشهر، وكلما طالت فترة التخزين ازداد بوءاً وتناقصت القيمة الغذائية) مناسبة للأغذية الطازجة	ا (يُوصيٰ با	≤ -18	(***)*-الفريزر	2
ت البحرية (السمك، الجمبري، المحار) ومنتجات اللحوم تخزينها لمدة 3 اشهر، وكلما طالت فترة التخزين إزداد بوءاً وتناقصت القيمة الغذائية) غير مناسبة للأغذية ـمجمدة.	ا (يُوصي با	≤ -18	***—الفريزر	3
ت البحرية (السمك، الجمبري، المحار) ومنتجات اللحوم تذرّينها لمدة شهرين، وكلما طالت فترة التخرّين ازداد بوءاً وتناقصت القيمة الغذائية) غير مناسبة للأغذية ـمجمدة.	ا (يُوصيٰ با	≤ -12	**-الفريزر	4
ت البحرية (السمك، الجمبري، المحار) <mark>ومنتجات اللحوم</mark> تذرينها لمدة شهر، وكلما طالت فترة التخزين ازداد الطعم اقصت القيمة الغذائية) غير مناسبة للأغذية الطازجة	ا (يُوصِيَ بنا	≤ -6	*-الفريزر	5

من الخطورة تغيير المواصفات أو محاولة تعديل هذا المنتج بأي حال من الأحوال.

بمكن أن يؤدي أي تلف في السلك إلى حدوث قصر في الدائرة الكهربائية أو اندلاع حريق أو التعرض لصدفة كهربائية.

السلامة الكهربائية

1. بحب عدم تطويل السلك الكهربائي. 2. تأكد أن قابس الْكَهرباء ليس متهالكًّا أو تالفاً. قد يسبب قايس الكهرباء المتهالك أو التالف ارتفاعاً في درحة الحرارة، فما يؤدي إلى حدوث

3. تأكد أن بإمكانك الوصول إلى القابس الرئيسي

4. لا تشد الكابل الرئيسي.

5. إذا كان المقيس مرتخياً فلا تدخل قايس الطاقة؛ حيث يزداد خطر التعرض للصدقة الكهربائية أو الحرىق.

6. يُحظِّر تشغيل الثلاحة دون غطاء المصباح

7. تعمل الثلاحة فقط من خلال الإمداد بتبار كهربائي متناوب أحادي الطوريجهد 220~240 فولت/ تُردد 50 هرتز. تأكد من تركيب منظم حهد متردد تلقائي بقدرة تزيد على 350 واط للثلاحة اذا كانت تقلبات الحهد في منطقة المستخدم كبيرة <mark>حداً بحيث</mark> بتعدى الحهد النطاق المذكور. بحب أن يكون للثلاجة مقيس مخصص بدلاً من استخدام

مقيس مشترك مع أحهزة كهربائية أخرى. / يجب أن يوافق القابس الخاص بها المقبس مع وحود سلك أرضى.

الاستخدام اليومى

- ، لا تُخزرن غازات أو سوائل سرىعة الاشتعال في الثلاجةُ، حيث يمكن أن يؤديّ ذلك إلى حدوثٌ
- لا تُشْغل أي جِهاز كهربائي داخل الثلاجة (مثل صانعة الآيس كريم الكهريّائية، والخلاطات وغيرها). عند فصل التبار الكهربائي ، انزع القابس من لمقيس الرئيسي، ولا تسحّب الكابل.
 - ، لا تضع أحساماً ساخنة بحانب المكونات البلاستبكية للثلاحة.
- لا تضع أي منتحات للطعام قرب مخرج الهواء في لحزء الخلَّفور.
 - احرص على تخزين الطعام المحمد المغلف مسيقاً وفقاً لتعليمات حهة تصنيع الطعام
- يجب الالتزام التام بتعليمات التخزين الصادرة عن عهة التصنيع. يُرحق الاطلاع على التعليمات المتعلقة بالتخزين.

- لا تضع المشروبات الغازبة في قسم الفريزر، حيث تُحدث ضغطاً عَلَى الوعاء قد يَّتسبب في أَنْفُحاره مماً يؤدي المرتلف الحهاز.
- بمكن أن يتسبب الطعام المحمد في حدوث قضمة الصقيع اذا تم تناوله فياشرة فن الثلاجة.
- بمكن أن بتسبب فتح باب الثلاجة لفترات طويلة من الزمن بارتفاع ملحوط في درجة الحرارة داخلُ
- احرص على التنظيف المنتظم لحميع الأسطح التى تلامس الأطعمة وأنظمة التصريف التى يمكر· الوصول البها.
 - احرص على تخزين اللحوم والأسماك النبئة في حاويات فناسية داخل الجهاز، حتى لا تلافس أو تختلط بالأطعمة الأخرى.
- في حال تُركت الثلاجة فارغة لفترات زمنية طويلة، احرض على إطفاء الحهاز وإذابة الثلج وتنظيف وتحفيف الحهاز، وبعدها اترك الباب مفتوحاً لمنع تكوِّن العفرن.
 - لا تعرض الحهاز لأشعة الشمس المباشرة.

- أبعد الشموع المشتعلة والمصابيح وغيرها من العناصر ذات ألسنة اللهب المكشوفة عن الحهاز، فقد يؤدي ذلك الي اشتعال النيران بها.
- تم تصمَّيم الحهاز لحفظ المواد الغذائية و/أو المشروبات للأغراض المنزلية العادية كما هو فيين في كتبب التعليمات. يُرحي توخي الحذر عند تحريك الثلاحة لأنها ثقيلة.
- لا تقم بأخذ أو لمس المواد الموحودة داخل قسم الفريزر إذا كانت بداك رطبتين أو فيللتين، حيث يمكن أن يؤدى ذلك إلى حدوث جروح بالجلد أو الاصابة بقضمة الصقيع.
- لا تستخدم قاعدة الثلاحة، والأدراج، والأبواب، وخلافه مطلقاً للاستناد عليها أو كدعائم.
- يُحظر إعادة تحميد الطعام المحمد بمحرد ذوبان
- لا تتَّناول المثلحات أو مكعبات الثلج مباشرة عقب إخراجها من الفريزر، حيث يمكن أن يؤدي ذلك إلى حدوث حروق بالفم والشفاه.
- لا تضع حملاً زائداً على رفوف الباب، ولا تضع كماً كبيراً من الطعام في درج الخضراوات والفواكه لتحنب سقوطها وحدوث إصابات أو تلف الحهاز.

- احتفظ بحميع مواد التغليف بعيداً عن الأطفال لسلامتهم من مخاطر الاختناق.
- اذا رغبت بالتخلص من الجهاز، اسجب القابس من مقيس الكهرباء واقطع كابل الاتصال (قربياً من الحهاز قدر المستطاع) وقم بازالة الباب لمنع الأطفال من التعرض لصدمة كهربائية أو حيس أنفسهم في الداخل.
- إذا تضمن هذا الحهاز أقفال مغناطيسية للياب في حال رغبت باستبدال جهازك القديم الذي يحتوي علَّى قفل مزلاج للباب، تأكد من إيطال وظيَّفة القفل المزلاج قبل التخلص من الحهاز القديم. يساهم ذلك في منع تعرض الأطفال للخطر، إذ قد بشكل القفل المزلاج مصيدة مميتة لهم.

معلومات السلامة العامة

هذا الجهاز فخصص للاستخدام المنزلي والأماكن المشابهة، مثل: أماكن إعداد الطعام في المحلات والمكاتب وأماكن العمل الأخرى؛

- أماكن إعداد الطعام في المحلات والمكاتب وأماكن العمل الأخرى؛
- المنازل الريفية، و من قبَل العملاء في الفنادق والنَّزُل والأماكن السكنيةَ الأخرى؛
- · الأماكن التي تقدم خدمات المبيت والافطار؛ - الأماكن التي تقدم خدمات التموين وتزويد الطعام، وغيرهًا من الأماكن الغير مخصصة للبيع ا
- ، تحذیر بحب عدم تخزین مواد متفحرة مثل ليخاخات القابلة للاشتعال في هذا الجهاز. تحذير – في حال تلف سلك الإمداد بالطاقة، بحب ستبداله عن طريق الحهة المصنعة أو مراكز الخدمة المعتمدة أو أشخاص مؤهلين على نفس لمستوى الكفاءة وذلك لتحنب حدوث أي مخاطر. ، تحذير – بحب عدم تغطية فتحات التهويةً في لحهاز أو الهبكل المدمج بأي عوائق. • تحذير – يحب عدم استخدام أحهزة فيكانيكية أو أي وسائل أخرى لتسريع عملية تذويب الثلج، غير تلك
- الموصى عليها من قبل الحهة المصنعة.
 - تحذیر یجب عدم إحداث أی ضرر بدائرة التبرید.
- ، تحذير بحب عد استخدام أي أحهزة كهربائية داخل لأقسام المخصصة لتخزين الأطعمة، الا اذا كانت عن النوع الموصى عليه من قبل الحهة المصنعة.

وسيط التبريد

• تحذير – يحتوى الحهاز على وسيط التبريد وغاز

من الحهاز، احرص على استخدام مركز معتمد

العزل، وهذه المواد سريعة الاشتعال. عند التخلص

للتخلص من النفايات. ولا تعرض الحهاز لأي لهب.

• تحذير – عند تركيب الحهاز، تأكد من أن لا يُكون

سلك الإمداد بالطاقة تالفاً أو عالقاً في مكان ما.

من استخدام مقيس مشترك مع أحهزة كهربائية

• تحذير - بحب تبديل سلك الاقداد بالطاقة التالف

فقط من قبل الحهة المصنعة أو مركز الخدمة

• تحذير - لا يجب استبدال المصابيح من قبل

خدمة العملاء للحصول على الدعم اللازم.

المستخدم! في حال تلف المصابيح، اتصل بمركز

المعتمد.

تبديل المصابية LED:

• تحذير – يجب أن يكون للجهاز مقبس مخصص بدلاً

بوحد وسيط التبريد إيزونوتان (R600a/R134) -بُرحِي التأكد من عدم تلف أي من أحزاء دائرة وسيط التبريد عند نقل الثلاجة وتركبيها. نُعد وسيط التبريد (R600a) مادة سريعة الاشتعال.

ذلك مِن أن أناست دائرة وسبط التبريد غير تالفة.



تحذير: خطر الحريق/ قواد قابلة للاشتعال

- تَحْنَبُ اِشْعَالَ لَهُبُ وَأَى مَصَادِرِ اشْتَعَالَ أَخْرِي.

أحد الغازات الطبيعية الصديقة للبيئة ولكنه أيضاً سريع الاشتعال - داخل دائرة وسيط تيريد الثلاحة. ، تحذير – الثلاحات تحتوى على وسبط التبريد وغازات. عند الرغبة بالتخلّص من وسبط التبريد والغازات، يحب القيام بذلك بشكل صحيح من خلال مراكز معتمدة للتخلص من النفايات، لأنها قد تسبب إصابات في العبن أو اشتعال. وتأكد قبل



في حال تلف دائرة وسبط التبريد:

- ، قم يتهوية الغرفة التولُّ توجد بها الثلاجة حيَّداً.



الطراز: USC1100 **USC595 USC465 USC325**

المحتوىات

12-1	أسماء الأجزاء ووظائفها	معلومات السلامة والتحذيرات
14	المواصفات	كيفية الاستخدام
	ضبط درجة الحرارة ووصف الـوحدة–––––––	
16 -	التخلص من المنتج ،	في حال حدوث ما يلي12-11

معلومات السلامة والتحذيرات

لسلامتك وضمان الاستخدام الصحيح كالمستخدم هذا للحهاز، يرجُى قراءة دليل المستخدم هذا بعناية قبل تركييه واستخداقه للمرة الأولى ، يما في ذلك النصائح والتحذيرات الموضحة. لتجنب الأخطاء والحوادث غير الضرورية، من المهم أن يكون كل من يستخدم هذا الحهاز على دراية كافلة بخصائص التشغيل والسلافة. احتفظ بهذه التعليمات وتأكد من إرفاقها مع الجهاز في حال إعطائه لشخص آخر أو بيعه، ليتبح ذلك إقكانية استخدامه من قبل أي شُخص آخْرُ والتأكد من حصوله على معلومات الاستخدام والسلامة. ولسلامة الأرواح والممتلكات، احرص على اتباع الإجراءات الـوقائية الـواردة في التعليمات، إذ أن الشركة المصنعة غير مسؤوَّلة عن أي أضرار قد تحدث نتبحة سوء الاُستخدام أو الاَهماَّل.

سلامة الأطفال وغيرهم من الأشخاص من ذوى القدرات المحدودة

• وفقاً لمعابير EN

بمكن للأطفال الذين تبلغ أعمارهم 8 سنوات فأكثر، والأشخاص ذوى القدرات البدنية أو الحسية أو الذهنية المحدودة، أو الأشخاص الذين تنقصهم الخبرة والمعرفةُ استُخدام هذا الحهازُ، على أن يكون ذلك تحت إشراف أحد البالغين، أو تُزويدهم ... بالتعليمات المتعلقة حول استخدام الحهاز بطريقة آمنة تمكُنهم من فهم المخاطر المحتملة حرًّاء الاستخدام الخاطئ. يحب على الأطفال عدم العيث بالحهاز. لا يُسمح للأطفال يتنظيف الحهاز أو صيانته دون اشراف.

• وفقاً لمعاسر IEC هذا الحهاز غير مخصص للاستخدام من قبل

الأشخاص (بمن فيهم الأطفال) من ذوى الق<mark>درات</mark> البدنية أو الحسية أو الذهنية المحدودة، أو الأشخاص الذينُ تنقصهم الخبرة والمعرفة، ما لم ي<mark>تم ذلك</mark> تحت إشراف أحد البالغين المسؤولين عن سلامتهم، أو تزويدهم بالتعليمات ال<mark>متعلقة حول</mark> استخدام الجهاز بطريقة آمنة.

1

© Alhafidh Group Trading fzco. 2021
Reproduction in whole or in part is strictly prohibited