

# PHANTOM MINI ICE MAKER

## QUICK START GUIDE



Note: Before getting started wash all parts with soap and warm water or in a dishwasher


### FREEZING

1. Fill stainless steel container with water to just above inner fill line.
2. Take silicone Shape Tray and make note of the Snap Posts and holes on each half. Align *PULL* tab on top half of tray with notch in bottom half and assemble. Make sure to lock in place all 7 Snap Posts in their holes.
3. Place assembled Shape Tray into stainless steel container and it will slowly lower itself. Add water so that cups on top are full. Move to a level freezer shelf set between -10 and +10 °F for about 28 hours.

#### TIPS:

- Snap posts must all be locked in place prior to freezing. This is easiest to do when the posts and holes are wet.
- Aligning *PULL* tab first on top of tray makes it easy to line up the two halves.
- Freezing duration varies based on your specific conditions. You may only need 24 hours for fully-formed shapes.

SNAP POSTS



SHAPE TRAY ASSEMBLY



### EXTRACTION

1. Lift up on the *PULL* tab to remove the top of the tray, then lift up on the arms on the sides to lift the bottom of the tray out of the container.
2. Pop out ice balls to serve or store in an airtight container in your freezer for another time.
3. Remove any remaining ice in the bottom of the container to re-set for another batch.

Cheers!



#### TIPS:

- If Shape Tray is in the freezer for longer than 30 hours, you may need to lift up on the arms to loosen the tray before lifting up on the *PULL* tab.
- If you see air bubbles in your ice, try using warmer water for your next batch or increasing your freezer temperature closer to +10 °F
- Let your ice “temper” outside of the freezer at room temperature for 2-3 minutes before pouring liquid over it to prevent cracking.

FOR VIDEO INSTRUCTIONS, VISIT [WINTERSMITHS.COM/MINI](http://WINTERSMITHS.COM/MINI)