

Prosport Inc. Premium Boost Gauge



Lighting Diagram

Boost sender

Day Time	Night Time	Installation
White	White	White — Connect to acc. Power Amber— Do not connect
Blue	Blue	White — Do not connect Amber— Connect to acc. Power
White	Blue	White — Connect to acc. Power Amber — Connect to parking lamp
Blue	White	Amber — Connect to acc. Power White — Connect to parking lamp



Boost line

Plug in sender cable from

Gauge.

SENSOR MOUNTING: Please mount the sensor inside the cabin. Mounting it in the engine bay will expose it to high temps and possible water/moisture. We take no responsibility in damaged sensors by these elements.

WWW.PROSPORTGAUGES.COM