Riding at Night

While the SlickRock 900 will improve your control and enjoyment of night riding, please remember that cycling at night is an inherently dangerous activity. In addition to using your lighting system properly and riding with extreme caution, NiteRider urges you to:

- never ride alone
- always let someone know where you are going
- wear a helmet and reflective clothing
- carry an auxiliary light and emergency supplies.

Quick Start

- 1. Fully charge the battery before the first use. See "Using the 2.5-hour Fast Charger"
- To mount the headlamp and battery, see "Mounting the Headlamp" and "Mounting the Battery".
- 3. Connect the battery to the headlamp.
- 4. To turn the system on and off, simply press and release the headlamp power button.

Mounting the Headlamp

The HID headlamp can be mounted to the handlebar or a helmet.

Universal Handlebar Mount

The Universal Handlebar Mount (UHM) is designed to fit on virtually any handlebar. Included with the mount is a 2.5 mm Allen wrench, a pair of black rubber bumpers already in place, and a thin rubber shim to customize the fit on large handlebars up to 32 mm in diameter.

Turn the knob counter-clockwise, allowing the hinge to swing open. Place the mount on the handlebar on the left side the stem, orienting the rectangular notch in the slider clip to the rear. Swing the hinge down to make contact with the handlebar. Swing the hex bolt up, seating the knob into its recess. Turn the knob clockwise to tighten and secure the mount to the handlebar.

The UHM can be adjusted to accommodate any handlebar angle. By loosening the 2.5×30 mm Allen screw, you can move the swing arm back and forth to straighten the headlamp. Tighten the 2.5×30 mm screw after the adjustment.

To pivot the headlamp, loosen the 2.5 x 12 mm screw located under the slider clip and swing arm and rotate the headlamp to the desired position. Make this adjustment before tightening the 2.5 x 30 mm screw.

Helmet Mount

- Unclamp the straps on each side of the helmet mount and pull them free.
- Position the plastic mounting plate as close to the centerline of the helmet as possible, orienting the parallel grooves on the slider clip to the rear.
- Feed each strap into and out of two helmet vents, circling each strap back to the upper edge of the corresponding clamp.
- 4. Fasten the straps by inserting them into the clamps.

Inserting the Headlamp into the Handlebar or Helmet Mount

Insert the headlamp mount into the handlebar or helmet mount slider clip from the rear of the slider clip forward. Gently rocking the lamp as you slide it may help. Do not push the release lever when inserting the headlamp into the slider clip; let the lamp snap into place by itself.

To remove the headlamp, push the release lever and slide the lamp backward.

Note: After mounting the headlamp, adjust the headlamp so it illuminates the road properly without distracting oncoming riders.

Mounting the Battery

The NiMH battery can be mounted to the bike frame or placed in a jersey pocket, hydration pack, or fanny pack.

Warning: For safety reasons, a cyclist should never be tethered to the bike. If the headlamp is mounted to the helmet, do not mount the battery to the frame. Conversely, if the headlamp is mounted to the handlebar, do not place the battery in a pocket or pack.

Frame Mount

- 1. Thread the wide Velcro strap through the slots on the top of the battery clip.
- Attach the concave surface of the battery to a safe, convenient location on the frame (typically under the top or down tube), placing the Velcro strap over the tube but under any shift or brake cables.
- Secure the handlebar cord to the frame using the thin Velcro tie. Make sure the cord does not interfere with any moving parts.

Pocket or Pack

 Route the helmet cord through a helmet vent or along the outside of the helmet using the thin Velcro tie to secure the cord.

- Connect the helmet cord to the battery, making sure the cord does not interfere with any moving parts.
- 3. Simply place the battery in a pocket or pack.

Operation

- Connect the battery cord to the headlamp or helmet cord.
- To turn the lamp on, press and release the headlamp power button. The LED will turn green indicating power. It is normal for the HID bulb to flicker and change color as the bulb stabilizes.
- 3. Cycle through the two brightness levels by pressing and releasing the power button.
- 4. To turn the lamp off, press and release the power button. The lamp will go out and the LED will glow amber for four seconds. The lamp cannot be restruck for eight seconds.
- When the LED turns red, it is time to recharge your battery. Turn off your lamp to avoid over-discharging and damaging your battery.

Note: If the LED is flashing, the battery must be disconnected to unlock this battery protection feature.

Warning: HID headlamps require adequate airflow during operation (as in riding conditions). NiteRider discourages use of the light in stationary conditions as excessive heat retention will occur.

Thermal Step Down

If the SlickRock 900 HID headlamp is used in a stationary condition, such as bench testing, heat retention, due to inadequate airflow, will cause the light output to "step down" to a lower level to avoid damage to the lamp. Simultaneously, the LED indicator on the headlamp will be set to flash, red-green. When the temperature drops into a safe range, the LED indicator will return to solid green and then return to "high" light output by pressing and releasing the headlamp power button.

Battery Charging and Care

Rechargeable batteries can last years with proper care. Most importantly, fully charge your battery:

- before the first use
- after each use
- before storing
- every 45 to 60 days when not in use

Using the 2.5-hour Fast Charger

Note: The charger will charge a fully depleted battery in approximately 2.5 hours.

- 1. Plug the power cord into the charger and then the wall socket. The charger will conduct a self-diagnosis and the charging indicator light (located on the back. upper-left corner of the charger) will illuminate green, then amber, and then back to green.
- 2. Connect the charger cable to the battery. If the battery is not fully charged, the indicator light will turn amber. signifying fast-charge mode. If the light flashes when you first plug in the battery, the charger is preparing an overly discharged battery for fast charging.
- 3. When the battery is fully charged, the indicator light will turn green and charging will shut off automatically.
- 4. Unplug the charger from the battery and wall socket. grasping the connectors rather than the cables. (Leaving the battery and charger connected indefinitely will not harm the cells.)

Battery Initialization

Until the battery has been charged and discharged up to ten times, you may experience shorter than expected run times as well as higher than normal charger and battery temperatures.

Warning: NiteRider discourages battery initialization through "bench testing" (operating the light in static conditions) as the excessive heat generated can damage the HID headlamp.

Storage

Rechargeable batteries perform better and last longer if they are brought to a complete charge before storing and every 45 to 60 days when not in use.

Disconnect the battery from the headlamp, and store the system in a cool dry place.

Run Time

SlickRock 900 will run for 2:15 on a fully charged battery. Run times are approximations and will vary.

Light output is 920 Lumens.

Lumen values represent an average of 10 randomly selected headlamps as measured in a 0.6 meter Integrating Sphere.

Protecting Your Investment

When not in use, always disconnect the headlamp from the battery. To unplug, grasp the connector, not the cable.

Properly charge your battery to maximize its lifespan (see "Battery Charging and Care"). To avoid damaging your system, only charge your NiteRider battery with the appropriate NiteRider charger.

While the SlickRock 900 will perform in wet weather conditions, submerging it in water will damage the system. If you need a submersible light, NiteRider manufactures industrial-grade dive light systems. For information, contact NiteRider Dive Lights at 858.268.3850 or visit www.niteriderdive.com.

Support

If you experience difficulties during product installation or operation. NiteRider provides free telephone support on weekdays from 8:00 AM to 4:30 PM (Pacific Time) at 800.466.8366, ext. 4. You may also e-mail us at support@niterider.com.

Warranty

NiteRider stands behind its products with the following warranties:

- Lifetime warranty on all mechanical components.
- 2 years on the HID bulb and ballast.
- 1 year on cables and connectors, electronic components and printed circuit boards.
- 180 days on rechargeable batteries and fast chargers

To repair or replace your product while under warranty, return it (postage prepaid and insured with original sales receipt) to the address below. Out-of-warranty repair service is also available. For complete warranty information, please visit our website.

Parts List and Identification

Please verify the contents of your SlickRock 900 system:

A. High-output HID headlamp

B. 4.0 Ah-13.2 Volt NiMH battery (pocket/frame mount)

C. Universal handlebar mount

D. 2.5-hour fast charger

E. Helmet mount

F. Charger power cord

G. 36" helmet cord

H. Velcro cable tie

NiteRider Technical Lighting Systems 8205 Ronson Road, Suite E San Diego, CA 92111 USA 800.466.8366 www.niterider.com

NiteRider and SlickRock 900 are trademarks of NiteRider, Inc. All other trademarks are the property of their respective owners. The information in this document is subject to change without notice. © 2008 NiteRider,

Inc. All rights reserved. 150-21613 150-21613 - Rev B



SlickRock 900 **USER GUIDE**

Thank you for choosing the SlickRock 900™ from NiteRider, the innovator in technical lighting systems. The SlickRock 900 uses high-intensity discharge (HID) lamp technology for bright, white light. The SlickRock 900 system includes:

- HID Solarc[™] lamp
- Compact, lightweight nickel metal hydride (NiMH) batterv
- 2.5 hour fast charger
- Low battery indicator
- Frame and helmet mounting

To get the most from your NiteRider light, we urge you to familiarize yourself with the following safety and operating instructions.