

Manual

Chargery SMPS

1500Watt power supply for charger



MODEL. S1500



Index

Introduction	3
Service Centre	3
Declaration of conformity	3
Intended use	4
Package content	4
Technical Data	4
Symbols explication	5
Safety notes	5
Use	6
Settings	6
Warning messages	7
Notes on environmental protection	8
Care and maintenance	8
Warranty	8

Introduction

Thank you very much for purchasing the Chargery SMPS S1500. This power supply is extremely versatile.

Read this manual carefully to achieve the best results with your Chargery SMPS S1500 and first of all to safely control your models. If you experience any trouble during operation, take the instructions to help or ask your dealer or Service Centre.

Due to technical changes, the information may be changed in this manual without prior notice. Be always updated by checking periodically on our website, www.chargery.com to be always up to date with the products and firmwares.

This product complies with national and European legal requirements.

To maintain this condition and to ensure safe operation, you must read and follow this user manual and the safety notes before using the product!



NOTE

This manual is part of that product. It contains important information concerning operation and handling. Keep these instructions for future reference and give it to third person in case you gave the product.

Service Centre

Servicehotline

(+86) (0)755 2643 6165

Monday - Friday:

9:15 am - 6:00 pm

✉ jasonwang3a@163.com

Website: www.chargery.com

www.chargerystore.com

Chargery in Internet

For the service centers outside China please refer to our website www.chargerystore.com

Declaration of conformity



Chargery SMPS S1500

Chargery declares that the product is conform to EU norms.

EN 55032: 2015 + AC:2016, EN 55035: 2017

EN 6100-3-2: 2014, EN 6100-3-3: 2013

EN 62368-1:2020 + A11:2020

Intended use

The Chargery S1500 Power supply is a microprocessor controlled power supply that provides a balanced voltage from the net voltage.

The Chargery S1500 is only suitable for being used as power supply for RC model battery chargers.

Other uses are not allowed. For any improper use no warranty or liability is accepted.

The Chargery S1500 power supply should not be used to directly charge any battery. The batteries should be charged only with a proper battery charger.

Read through this entire manual before you attempt to install or use the Chargery S1500 power supply.

Chargery constantly works on the development of all products; we reserve the right to change the item, its technology and equipment.

Target group

The product is not a toy. It is not suitable for children under 14 years. The installation and operation of the Chargery S1500 must be performed by experienced modellers. If you do not have sufficient knowledge about dealing with R/C models power supplies, please contact an experienced modeller or a model club.

Package content

- ① Chargery SMPS S1500
- ① Power cable
- ① XT-90 connection cable
- ① Manual

Technical Data

Chargery SMPS S1500

Input voltage (nominal voltage)	110 - 230 Volt AC / 50/60 Hz
Output voltage	10 - 30 Volt DC
Output current	1 - 60 Ampere
Operating temperature	10 - 45°C
Operating humidity	5 - 95 %
Outputs	3 pairs 4 mm connectors 1 x XT-90 connector
Dimensions	265 x 170 x 68 mm
Weight	2,86 Kg

Symbols explication



Always observe the information indicated by this warning sign. Particularly those which are additionally marked with the CAUTION or WARNING. The signal word WARNING indicates the potential for serious injury, the signal word CAUTION indicates possibility of lighter injuries.



The signal word Note indicates potential malfunctions. Attention indicates potential damages to objects.

Safety notes

CAUTION



These safety instructions are intended not only to protect the product but also for your own and other people's safety. Therefore please read this section very carefully before using the product.

- ⓘ Do not carelessly leave the packaging material lying around, since it might become a dangerous toy for children.
- ⓘ Persons, including children, with reduced physical, sensory or mental capabilities, or lack of experience or knowledge, or not capable to use safely the power supply must not use the power supply without supervision or instruction by a responsible person.
- ⓘ Protect the device from dust, dirt, moisture. All equipment must be protected from vibration as well as excessive heat or cold.
- ⓘ The slots in the housing are used to cool the device and must not be covered or sealed. The device must be positioned so that the air can circulate without restriction.
- ⓘ The power supply, the charger and the battery to be charged must be placed on a non-combustible, heat-resistant and non-conducting surface during operation. Never place the device on a car seat, carpets or similar surfaces. Combustible or highly flammable objects are to be kept away from the charging area.
- ⓘ Only use in rooms fitted with a smoke detector.
- ⓘ Do not connect any battery directly to the power supply, risk of fire!


Use

Connect the power supply to the net socket with the proper voltage by using the including connection power cable.

The power supply starts with switched off output voltage, in the display will be shown in the highest line "POWER OFF".

In the display will be shown the actually set output voltage, the maximum output current, the actual watt consumption and the internal temperature of the power supply.

The output voltage can be set in this display by pushing the arrow buttons.



1. Connect power supply to AC socket range from 120V/230V
2. Turn on the power supply by pressing the switcher.
3. Set output voltage by pressing UP or Down arrow,
4. Set maximum output current by pressing SET button enter into program setup menu and press UP or Down arrow modify
5. Press START button, the power supply start and show power on



CAUTION

Before you switch the output voltage on:

a too high voltage can lead to fire and can destroy the connected battery charger. Inform yourself about the maximum voltage needed by the battery charger that is connected to the power supply. Set the voltage previously properly through the arrow buttons.



The output voltage is switched on through the Start/Enter button. In the highest line of the display will appear "POWER ON"

on power on status, press UP or Down arrow can adjust output voltage

Settings



To access to the settings menu push and hold the STOP/SET button for approx. 2 seconds.



Through the arrow buttons you can select the menu points. The selected menu point changes to yellow.

If you push the Start/Enter button the menu point blinks, now you can change the value through the arrow buttons.

You have the following setting possibilities in the single menu points:

Max. Current

Maximum current given by the power supply, 1 - 60 A

Fan on Temp.

Switch-on temperature of the cooling fans in the device, 30-50°C

The fan power will be regulated depending on the load.

Shut Down Temp.

Switch-off temperature, once the set temperature is reached the output will be switched off, 70 - 90°C

Buzzer

Button tone on or off, ON - OFF

Back Light

Display illumination time, 1 - 20 min or always on

Note

If the illumination has switched off, it can be switched on again by pushing each button.



Temp. Unit

Set the temperature unit, Celsius or Fahrenheit

Warning messages

Over-voltage	If the output voltage is 2 V higher than the set voltage, the power supply switches off. It is only possible to re-switch the power supply on manually OVER VOLTAGE - Warning will be shown in the highest line of the display
Over-current	If the output current is 2 A higher than the set value, the power supply switches off. It is only possible to re-switch the power supply on manually OVER CURRENT - Warning will be shown in the highest line of the display
Over Temperature	If the power supply temperature is higher than shutdown setting for more than 2 sec, the power supply switches off. The power supply switches automatically on again when the temperature gets lower. OVER TEMPERATURE - Warning will be shown in the highest line of the display.
Short-circuit at the output	If there is a short-circuit in one output, the power supply switches off. It is only possible to re-switch the power supply on manually. SHORT CIRCUIT - Warning will be shown in the highest line of the display

Notes on environmental protection



Disposal notes

This symbol on the product, user manual or packaging indicates that this product must not be disposed of with other household waste at the end of its life. It must be handed over to the applicable collection point for the recycling of electrical and electronic equipment.

The materials are recyclable as marked. By recycling, material reusing or other forms of scrap usage you are making an important contribution to environmental protection.

Batteries and accumulators must be removed from the device and disposed of at an appropriate collection point. Please inquire if necessary from the local authority for the appropriate disposal site.

Care and maintenance



Notes on care

The product does not need any maintenance, it works so as it is without any special care. In your own interests protect it from dust, dirt and moisture.

Warranty

The Chargery Power co., Ltd. grants from the date of purchase of this product for a period of 24 months. The warranty applies only to the material or operational defects already existing when you purchased the item. Damage due to misuse, wear, overloading, incorrect accessories or improper handling are excluded from the guarantee. The legal rights and claims are not affected by this guarantee. Please check exactly defects before a claim or send the product, because we have to ask you to pay shipping costs if the item is free from defects.

The present construction or user manual is for informational purposes only and may be changed without prior notice. The current version can be found on the Internet at www.chargery.com on the relevant product page. In addition, the company Chargery has no responsibility or liability for any errors or inaccuracies that may appear in construction or operation manuals.

No liability can be accepted for printing errors.