







MOBY







MOBY SLING INSTRUCTIONS

THREADING A SLING





Find info and instructions for other ways to wear baby with the MOBY Sling at mobywrap.com.

TUMMY TO TUMMY





Find info and instructions for other ways to wear baby with the MOBY Sling at mobywrap.com.

TUMMY TO TUMMY SAFETY CHECK





Find info and instructions for other ways to
wear baby with the MOBY Sling at mobywrap.com.

HIP CARRY 5M+



Find info and instructions for other ways to wear baby with the MOBY Sling at mobywrap.com.

HIP CARRY SAFETY CHECK 5M+



Find info and instructions for other ways to
wear baby with the MOBY Sling at mobywrap.com.

TAKING BABY OUT



Find info and instructions for other ways to
wear baby with the MOBY Sling at mobywrap.com.

IMPORTANT! KEEP FOR FUTURE REFERENCE

Read and follow all printed instructions before use.

! WARNING



EN

**FAILURE TO FOLLOW THE MANUFACTURER'S INSTRUCTIONS CAN RESULT IN DEATH OR SERIOUS INJURY.
ONLY USE THIS SLING CARRIER WITH CHILDREN WEIGHING BETWEEN 8 LB (3.6 KG) - 33 LB (15 KG)**

SUFFOCATION HAZARD

Babies younger than 4 months can suffocate in this product if face is pressed tightly against your body. Babies at greatest risk of suffocation include those born prematurely and those with respiratory problems.

- Check often to make sure baby's face is uncovered, clearly visible, and away from caregiver's body at all times.
- Make sure baby does not curl into a position with the chin resting on or near baby's chest. This position can interfere with breathing, even when nothing is covering the nose or mouth.
- If you nurse your baby in carrier, always reposition after feeding so baby's face is not pressed against your body.
- Never use this carrier with babies smaller than **8 pounds** without seeking the advice of a healthcare professional.



FALL HAZARD

Leaning, bending over, or tripping can cause baby to fall. Keep one hand on baby while moving.

ADDITIONAL INFORMATION

Check for ripped seams, torn straps or fabric and damaged hardware before each use, if found, stop using the sling carrier

ALWAYS check to ensure that all knots, buckles, snaps, straps and adjustments are secure.

ALWAYS ensure that the baby is safely positioned in the sling carrier according to manufacturer's instructions for use.

NEVER leave a baby in a sling carrier that is not being worn. Check on the baby often. Ensure that the baby is periodically repositioned.

NEVER use a sling carrier when balance or mobility is impaired because of exercise, drowsiness, or medical conditions.

NEVER place more than one baby in the sling carrier.

NEVER use/wear more than one carrier at a time.

NEVER use sling carrier while engaging in activities such as cooking and cleaning which involve a heat source or exposure to chemicals.

NEVER wear sling carrier while driving or being a passenger in a motor vehicle.

MAINTENANCE, CLEANING & STORAGE

Cleaning Instructions

Machine wash in cold water on normal cycle. Do not bleach. Line Dry or hang to dry and avoid direct sunlight. Do not iron.



Maintenance Instructions

Always check to assure all buckles, snaps, straps, and adjustments are secure before each use. Keep this sling away from children when it is not in use.

Storage Instructions

Store in a cool, dry place and away from direct sunlight.

IMPORTANT! KEEP FOR FUTURE REFERENCE

Read all instructions before assembling and using the sling.

WARNING

EU

WARNING Constantly monitor your child and ensure the mouth and nose are unobstructed.

WARNING For pre-term, low birthweight babies and children with medical conditions, seek advice from a health professional before using this product.

WARNING Ensure your child's chin is not resting on its chest as its breathing may be restricted which could lead to suffocation.

WARNING To prevent hazards from falling ensure that your child is securely positioned in the sling.

ADDITIONAL INFORMATION

Only use this carrier with children weighing between **8 lbs (3.6 kgs) to 33 lbs (15 kgs)**.

The child must face towards you until he or she can hold head upright.

Tie a secure double knot on your back, hip or front.

NEVER let any children play with or around the sling carrier.

Use hand to support baby's head until baby can support its own head.

Do not use this sling carrier in the near vicinity of open fires or other sources of strong heat, such as electric or gas fires. Be aware of domestic hazards such as harmful chemicals in cleaning materials and spilling hot drinks.

Only use the product for the number of children for which the product is intended.

Your movement and the child's movement may affect your balance.



Take care when bending and leaning forwards or sideways.

The sling is not suitable for use during sporting activities e.g. running, cycling, swimming and skiing.

Wearer should be aware of the increased risk of baby falling out of the sling as baby becomes more active.

Check for ripped seams, torn straps or fabric and damaged hardware before each use, if found, stop using the sling carrier.

Keep this sling away from children when it is not in use.



MAINTENANCE, CLEANING & STORAGE

Cleaning Instructions

Machine wash in cold water on normal cycle. Do not bleach. Line Dry or hang to dry and avoid direct sunlight. Do not iron.



Maintenance Instructions

Always check to assure all buckles, snaps, straps, and adjustments are secure before each use.

Storage Instructions

Store in a cool, dry place and away from direct sunlight.

IMPORTANT ! LIRE ATTENTIVEMENT ET CONSERVER POUR RÉFÉRENCE ULTÉRIEURE

Lire toutes les consignes avant d'assembler et d'utiliser le sling.

FR

AVERTISSEMENT

AVERTISSEMENT Surveillez constamment votre enfant et assurez-vous que sa bouche et son nez ne sont pas obstrués.

AVERTISSEMENT Pour les bébés prématurés, d'un faible poids à la naissance et les enfants atteints de maladies, demandez conseil à un professionnel de santé avant d'utiliser ce produit.

AVERTISSEMENT Veillez à ce que le menton de l'enfant ne repose pas sur sa poitrine, car cela peut restreindre sa respiration et provoquer un étouffement.

AVERTISSEMENT Pour éviter les risques de chute, assurez-vous que l'enfant est positionné de manière sécurisée dans le sling.

INFORMATIONS COMPLÉMENTAIRES

Utilisez ce porte-bébé uniquement avec des enfants d'un poids allant de **3,6 à 15 kg**.

L'enfant doit être face à vous jusqu'à ce qu'il parvienne à tenir sa tête droite.

Faites un double nœud solide dans votre dos, sur la hanche ou à l'avant.

Ne laissez **JAMAIS** aucun enfant jouer avec le sling ou à proximité de celui-ci.

Utilisez les mains pour soutenir la tête de bébé jusqu'à ce qu'il puisse lui-même la soutenir.

N'utilisez pas ce sling à proximité de flammes nues ou d'autres sources de chaleur forte, telles que des cheminées électriques ou à gaz. Prenez garde aux dangers domestiques tels que les produits nettoyants contenant des produits chimiques nuisibles ou les boissons chaudes pouvant être renversées.

Utilisez le produit exclusivement avec le nombre d'enfants

pour lequel il a été conçu.

Vos mouvements et ceux de l'enfant peuvent nuire à votre équilibre.


Faites attention quand vous vous inclinez ou vous penchez vers l'avant ou de côté.

Le porte-bébé ne convient pas pour un usage pendant les activités sportives, par exemple la course à pied, le cyclisme, la natation ou le ski.

La personne porteuse doit être consciente du risque accru de chute du bébé hors du porte-bébé à mesure qu'il devient plus actif.

Repérez toute couture défaite, toute bretelle ou tissu déchiré et tout matériel endommagé avant chaque utilisation et, le cas échéant, cessez d'utiliser le sling.

Maintenez ce porte-bébé éloigné des enfants quand vous ne l'utilisez pas.



ENTRETIEN, NETTOYAGE ET STOCKAGE

CONSIGNES DE NETTOYAGE

Laver à la machine à l'eau froide en cycle normal. Ne pas javelliser. Laisser sécher, éviter la lumière directe du soleil. Ne pas repasser.



INSTRUCTIONS D'ENTRETIEN

Vérifiez toujours que tous les fermoirs, réglages, boucles et sangles sont solides avant chaque utilisation.

INSTRUCTIONS DE RANGEMENT

Rangez le produit dans un endroit frais et sec, à l'abri de la lumière directe du soleil.

¡IMPORTANTE! LEER CON ATENCIÓN Y CONSERVAR PARA FUTURAS CONSULTAS

Lea todas las instrucciones antes de armar y usar el fular.

▲ ADVERTENCIA

ADVERTENCIA Vigile constantemente a su hijo y compruebe que la boca y la nariz no están obstruidas.

ADVERTENCIA Para bebés prematuros de bajo peso y niños con problemas médicos, consulte con un profesional de la salud antes de usar este producto.

ADVERTENCIA Verifique que la barbilla de su hijo no está descansando sobre su pecho y que respira sin obstrucciones que podrían asfixiarlo.

ADVERTENCIA Para evitar el peligro de una caída, compruebe que su hijo está colocado en el fular de forma segura.

INFORMACIÓN ADICIONAL

Use este portabebés solo con niños de peso entre **8 lb (3,6 kg) y 33 lb (15 kg)**.

El niño debe estar mirando hacia usted hasta que pueda mantener la cabeza erguida.

Haga un nudo doble seguro en su espalda, cadera o parte delantera.

NUNCA deje que los niños jueguen con el portabebés o a su alrededor.

Apoye con su mano la cabeza del bebé hasta que el bebé pueda mantenerla erguida.

No use este fular portabebés cerca de fuegos abiertos o de otras fuentes de calor extremo, tales como fuegos eléctricos o de gas. Tenga en cuenta los peligros domésticos, tales como los elementos químicos dañinos que contienen los productos de limpieza y la posibilidad de derramar bebidas calientes.

Use el producto solo para el número de niños para el que está hecho.

El movimiento del niño y el suyo propio pueden afectar a su equilibrio.



Lleve cuidado al doblarse e inclinarse hacia delante o hacia los lados.

El portabebés no es apto para utilizarse al hacer actividades deportivas, como correr, subir en bicicleta y esquiar.

El usuario debe tener en cuenta que el peligro de que el bebé se caiga del portabebés aumenta a medida que el bebé va siendo más activo.

Verifique que el fular no tiene costuras abiertas, correas o tejido rotos, y que las piezas de metal no están dañadas antes de cada uso. De lo contrario, deje de usar el portabebés.

Mantenga el portabebés fuera del alcance de los niños cuando no lo esté utilizando.



MANTENIMIENTO, LIMPIEZA Y ALMACENAMIENTO

INSTRUCCIONES DE LIMPIEZA

Lavar en la lavadora con agua fría y en el ciclo normal. No use blanqueador y cuélgalo o tiendalo para secar. Evite ponerlo directo al sol y no lo planches.



INSTRUCCIONES DE MANTENIMIENTO

Verifique siempre que todas las hebillas, cierres, correas y ajustes están bien fijados antes de cada uso.

INSTRUCCIONES DE ALMACENAMIENTO

Guárdelo en lugar fresco y seco alejado de la luz directa del sol.



mobywrap.com

Brands Four Kids, LLC
3567 Old Conejo Road
Newbury Park, CA 91320