Access Failsafe Mode to change Wifi Credentials

1. Get your foobot in failsafe mode

Power the device with the light strip facing down (cable on device's top).

Place Foobot like this:



Plug it, it will blink orange / blue:





Then you can now put it back straight:



2. Access fail safe webpage

Connect to the foobot-failsafe AP (no encryption):



Once connected to the wifi signal visit http://10.10.100.254/index_en.html with your web browser

Enter as login: foobot and password: foobot4u

2. Connect the product to wifi


I WiFi Config tab, click on Scan



Select the network you want to connect to (Foobot doesn't support 5G networks)



Back on this page, you will have to enter the network passphrase and Save.



The device will reboot and connect to the network. If it successfully access internet, its lights stay solid, otherwise it will blink slowly.

Once correctly connected, you can check the data from http://dashboard.foobot.io (use your regular email and password).