## artos

## INSTALLATION INSTRUCTIONS FOR REPLACING HEATING ELEMENT

- **1.** Slacken the upper bracket adjusting screws and remove the lower bracket adjusting screws.
- 2. Unscrew back plate from the wall; disconnect the wire cover elbow by sliding if off the bottom of the towel warmer and out of the wall. (It may be necessary to carefully pull the bottom of the towel warmer away from the wall to do this).
- **3.** Ensure that electricity is off and disconnect the wires.
- **4.** The towel warmer can now be taken off the wall by removing the upper bracket adjusting screws and pulling the towel warmer forward.
- 5. Turn the towel warmer UPSIDE DOWN.
- 6. Slide the back plate and elbow off the wire and then unscrew the original element. Take care not to spill the heat transfer fluid.
- **7.** Apply pipe thread tape or paste to the new element and screw it in tight, using a wrench.
- **8.** Remove the plug off the new element and feed the wire first through the elbow and then through the back plate.
- 9. Reattach the towel warmer RIGHT WAY UP.
- **10**.Reconnect the wires using wire nuts, again ensuring that the power is off.
- **11.**Push the elbow onto the bottom of the new element and into the hole in the back plate.
- **12.**Lastly, attach the back plate to the wall and tighten the bracket adjusting screws.

Enjoy!