


Assembly Instructions



ASSEMBLY RATING

The Assembly Rating is a 5-point system that shows the degree of effort needed in assembling a specific product (with 1 being easy and 5 being difficult). For some products, two persons are recommended.

EASY  DIFFICULT

Tools Required For Assembly:

Allen Wrench



Phillips Screwdriver




2 PERSONS RECOMMENDED


ASSEMBLY & CARE ADVICE

FOR YOUR FURNITURE TO LAST, CORRECT ASSEMBLY AND PROPER MAINTENANCE ARE NECESSARY. PLEASE FOLLOW THE INFORMATION PROVIDED BELOW TO FULLY ENJOY YOUR FURNITURE.


BASIC ASSEMBLY TECHNIQUES




When lock or spring washer is used in an assembly, please make sure the lock or spring washer is placed between the larger flat washer and the head of the screw or bolt.




Position each part correctly and insert screws or bolts into their respective holes by hand tighten or using the proper hand tool. Only tighten when step is completed or when instructed to do so.




Use cardboard or carpet area when assembling furniture to prevent scratches. Make sure the furniture rests on a flat and level surface with each leg evenly touching the floor.



Some furniture comes with height adjustment knobs underneath each leg. To lower or to raise each leg, you need to turn clockwise or counterclockwise, respectively.



Make sure all parts are properly aligned, then use the appropriate hand tool to completely tighten the bolts or screws. Do not use power tools and do not overtighten.




Save the instructions and store the Allen wrench or any supplied tool for later maintenance. After two weeks, check and tighten any loose hardware and repeat again every six months thereafter.

IT IS THE USER'S RESPONSIBILITY TO MAINTAIN THE FURNITURE. THE HARDWARE MAY LOOSEN OVER TIME AND MAY CAUSE THE FURNITURE TO BE WOBBLY AND UNABLE TO SUPPORT ITS INTENDED WEIGHT CAPACITY. THIS MAY LEAD TO COLLAPSE AND MAY CAUSE SERIOUS INJURY.




FAILURE TO FOLLOW THE GUIDELINES ABOVE MAY RESULT IN INJURY AND/OR PROPERTY DAMAGE.




Before you begin, please read Page 2 of "Assembly and Care Advice".

And remember, do not tighten until each step is completed or instructed.


Parts List




#1 x 1pc
Front Frame




#2 x 1pc
Rear Frame



#3 x 2pcs
Top Side Hooks



#4 x 18pcs
Lower Hooks




#5 x 1pc
Top Middle Hook




#6 x 1pc Long
Right Side Tube




#7 x 1pc Short
Left side Tube




#8 x 2pcs
Top Shelf




#9 x 2pcs
Bottom Shelf



#10 x 2pcs
Middle Shelf




#11 x 2pcs
Big Shelf




#12 x 3pcs
Small Shelf



#13 x 4pcs
Adjustable Foot



#14 x 2pcs
Side Lower Tube



Before you begin, please read Page 2 of "Assembly and Care Advice".

And remember, do not tighten until each step is completed or instructed.

Hardware List



#A x 6pcs
Bolt 1/4" X 5/8"



#B x 8pcs
Bolt 1/4" X 3"



#C x 44pcs
Screw M5x12



#D x 1pc
Allen Wrench M4



#E x 1pc
Screw M4x37



#F x 2pcs
Plate




#G x 1pc
Anchor




#H x 1pc
Girding

Exploded View






#A x 6pcs
#B x 8pcs
#F x 1pc

3) Align hooks (#,5) to the upper holes of the front and rear frames (#1,2). Secure by using bolts (#A).



1) Align right and left side tubes (#6,7) to the holes of the front and rear frames (#1,2). Secure by using bolts (#B).



2) Align side lower tubes (#14) to the bottom holes of the front and rear frames (#1,2). Secure by using bolts (#B).




#3

#C x 8pcs



1) Align top shelves (#8) to the holes of the hooks (#3,5), then secure by using screws (#C).

3-1



SCREWDRIVER (NOT PROVIDED)

3-2



2) Attach adjustable foot (#13) to the holes at the bottom of the frames (#1,2).



#4

#C x 36pcs





Align lower hooks (#4) to the panels (#9,10,11,12). Secure by using screws (#C).

x2


x2

x2

x3





#9/#10/#11/#12




SCREWDRIVER (NOT PROVIDED)



Hook the shelves as shown in the picture.




ASSEMBLY COMPLETED






#E x 1pc
#F x 1pc
#G x 1pc



#H x 1pc



To Prevent Tip over
Product Must Be
Attached To Wall

