



# STP-381-IV-US Light Tarp Penta Ivory



Tarp x 1



Paddle Hooking cover x 1



Rope with Tensioner x 3  
(3m/9.8' x 1, 1m/3.3' x 2)



Duralumin Peg x 6  
(17.5cm/6.9" x 6)



Carry Bag x 1



Peg Case x 1

**Before use: please read thoroughly to ensure safety and to avoid accidents.**

**⚠ DANGER** Misuse could easily result in a serious accident or death.

**⚠ WARNING** Misuse could result in serious injury to the user.

**⚠ CAUTION** Misuse could result in injury to the user and/or damage to property.

**Precautions for Handling**

**⚠ DANGER** Misuse could easily result in a serious accident or death.

- Do not use combustion-based heat sources such as lanterns, stoves or heaters, or open flames such as matches, candles, lighters or cigarettes, inside the tent. The use of such heat or light sources inside a small enclosed space is very dangerous and may result in fire, oxygen deficiency, or carbon monoxide poisoning.
- Do not keep fuel, or flammable items for replenishing the fuel, inside the Tarp.

**⚠ WARNING** Misuse could result in serious injury to the user.

- Pay close attention to the weather. If extreme weather is in the forecast, pack up camp and evacuate to a safe place.
- Choose a flat, well-drained area with firm ground to pitch the Tarp. Choose an area where there is no chance of avalanches, landslides, wind gusts or sudden flooding.

**⚠ CAUTION** Misuse could result in injury to the user and/or damage to property.

- This product is not intended to be in permanent use.
- Sunlight can cause the surface of the Fly to heat up, potentially causing low-temperature burns.
- Do not assemble or use the tent close to a bonfire, fireworks, etc. Flying sparks can create holes in the tent fabric.
- Firmly hold the Tent Pole when assembling and disassembling the tent. Unexpected accidents may occur due to the Pole ends recoiling, etc., so ensure that the surroundings are safe, with no other people in the vicinity.
- Firmly secure the Pegs, Guy Lines, etc.
- If the tent is left in the sun for long periods, the materials may fade in color or the fabric may deteriorate and lose strength. Do not leave the tent set up permanently.

**Regarding Condensation**

Mist is a collection of water droplets suspended in the air that turns into condensation in rapidly falling temperatures. In smaller spaces such as the inside of a tent, the concentration of water vapor is higher than in an ordinary room and frequently results in more condensation. Additionally, water accounts for 60 percent of the human body and is released through breathing and perspiration. This also causes the amount of water vapor in the tent to increase, resulting in more condensation. Inside the tent, condensation can commonly be found on materials that are highly waterproof, such as the Fly or the Bottom Sheet. Depending on the surrounding conditions, it may be impossible to avoid condensation completely, even with the use of waterproof materials. To reduce condensation, it is recommended that you allow steady ventilation while the tent is in use.

**Water-Repellent and Waterproof Functions**

- The fabric of the Fly is treated with a high-quality, water-repellent finish. However, the level of water-repellent capacity and durability may vary slightly due to the characteristics of each material. The water-repellent finish will lose effectiveness after repeated use. When the water repellence decreases, please use a water-repellent spray purchased from your local outdoor gear retailer. When using such sprays, please follow the product's instructions.
- Materials with high waterproof capacity are used in this product. However, if the materials are in contact with pools of water on the ground for long periods, the water may be absorbed into the material.
- The PU coating may be damaged by agricultural chemicals causing an abnormal drop in water pressure resistance. Please note that the product cannot be guaranteed if this occurs.
- The logo may peel off due to the water-repellent treatment.

**Regarding the Effect of Ultraviolet Rays**



A UV protection treatment has been applied to the material. The UV protection treatment will lessen the permeation of ultraviolet rays, which are harmful to humans, and also slow the deterioration of the Fly.

\*The UV protection treatment does not completely shield humans from ultraviolet rays or stop the deterioration of the material's strength.

**■ Setup Procedure**

**Instructions For Setting Up Alone (Figure 1)**


- Decide where the tarp will be set up, then spread the tarp on the ground, set the rope with rope tensioner, and peg down A (see Fig. 1).
  - Temporarily peg down B or C, set a pole (or an alternative) to D, and temporarily peg down C or B while standing up the tarp. Then, position D in a straight line to A (see Fig. 2).
  - Peg down B and C while adjusting as needed to smooth out any wrinkles, and then lightly apply tension to B and C.
  - Peg down E and F while adjusting as needed to smooth out any wrinkles.
  - Double-check the peg position of B, C, E and F, and apply tension to each.
- \*Do not apply too much tension, as this may cause damage to the pole.



**Maintenance & Storage**

- A combination of Polyester fabric is used for this product. Taking the material characteristics into consideration, we adopted processing and color patterns that will result in less color migration. However, depending on storage conditions, slight color migration may occur. Do not store the product while it is wet.
- Clean and dry the surface of the Poles before storing them. If stored when wet, corrosion may occur, resulting in strength deterioration.
- Store the product in a well-ventilated area, away from heat and moisture.
- Slight damage to the cloth can be mended with repair tape that can be purchased from your local outdoor gear retailer. Refer to the product instructions for the correct use of such repair tape.
- Depending on the conditions during use, the tent material may deteriorate over a wide area, losing its durability and becoming irreparable.
- Before the next use, check and maintain the product (including all accessories such as the pegs).
- The seam tape is pressure-bonded at a temperature that does not damage the PU coating. However, it may peel off as you use it repeatedly. If peeling is confirmed, set an iron to a low temperature and re-attach only the peeled section. Please note that excessive heat may cause the fabric to change color or deteriorate. Do not force the seam tape to come off. If the PU coating is removed altogether, it may not be possible to repair it.
- If sap sticks to the tent, it is difficult to fully remove. Please avoid setting up under the trees where the sap might drip. The fabric and coating will be damaged if it is removed by solvent.

**■ Function of Paddle Hooking Cover**



Hook both P Hooks inside the bottom of the Padded Hooking Cover onto the D-ring on the tarp, then tighten the Cord Lock.

**Regarding Warranty**

The specifications of Snow Peak products are determined based on field testing and quality control, ensuring proper function and longevity of every product. If apparent defects in the manufacturing of the product are found, the defective product will be repaired or exchanged free of charge. Damages, as follows, are not covered under warranty.

- Damage caused by improper use.
- Material deterioration caused by age or the influence of ultraviolet rays.
- Damage caused by modifications or rough handling.
- Damage caused by unforeseen accidents.
- Damage not caused by defects in the manufacturing process.
- Damage caused by dust or rust.
- Damage or defects caused when dismantling the products.
- Damage and defects caused by dropping or other shocks to the products.
- Defects, breakage or deterioration of replaceable parts.
- Damage caused by use of the product in combination with other maker's products

**Regarding Repairs**

- If a professional repair is necessary, please contact the dealer where the product was sold or Snow Peak Customer Service.
- Please dry and clean the product before sending it for repair.
- Please stick a memo onto the damaged area of the product. In the memo, include details explaining the circumstances that led to the damage.
- The cost of repair will be determined as follows:
  - If the damage is subject to warranty, transportation cost (both ways) and repair cost will be covered by Snow Peak.
  - If the damage is not subject to warranty, transportation cost (both ways) and repair cost will be covered by the customer.

## WARNING

### KEEP ALL FLAME AND HEAT SOURCES AWAY FROM THIS TENT FABRIC

This tent is made with flame resistant fabric which meets CPAI-84 specifications. It is not fire proof. The fabric will burn if left in continuous contact with any flame source.


The application of any foreign substances to the tent fabric may render the flame resistant properties ineffective.

### Specification

- Material: Tarp / 75D Fire-resistant Polyester Taffeta, PU coating Waterproof rating 1,800mm minimum, Water-repellent finish, UV protection treatment
- Set content: Tarp; Rope with tensioner (3m(9'8")x1, 1m(3.3')x2) ; Duralumin Peg (17.5cm(6.7")x6) ; Carry Bag; Peg Case; Paddle Hooking Cover
- Carry Bag size: 21x37(h)cm (8.2x14.5")
- Weight: 980g (2.1 lbs)

If you have any questions or concerns,  
please contact your retailer or Snow  
Peak customer service.

**Snow Peak Customer Service**

 **+1 503-697-3330**

Email: [info@snowpeak.com](mailto:info@snowpeak.com)

**Snow Peak USA, Inc.**

404 NW 23rd Avenue, Portland, Oregon 97210, USA

Tel. +1 (503) 461-0781 / Instagram. @snowpeakusa

Email. [info@snowpeak.com](mailto:info@snowpeak.com) / [www.snowpeak.com](http://www.snowpeak.com)

MADE IN VIETNAM