



MODEL RTA-7050

Thanks for purchasing one of our products.
please read carefully the assembly instructions before the installation.
Please save this manual for future reference.



PRODUCT DIMENSIONS:

RTA-7050 PRODUCT DIMENSIONS



GENERAL SPECIFICATIONS

WIDTH: 53.5"-82.75"

DEPTH: 15.35"


HEIGHT: 18"

PRODUCT NET WEIGHT: 80 Lbs




















SHIPS IN 1 BOX

Drawer opens ≈10" to front from edge of cabinet top

MAXIMUM WEIGHT CAPACITIES



PARTSLIST (Part number, Description, Qty):

<p>1. Left Cabinet Top Panel, 1 pc</p> 	<p>2. Left Cabinet middle Panel, 1 pc</p> 	<p>3. Left Cabinet Support Panel, 2 pcs</p> 	<p>4. Left Cabinet Left Side Panel, 1 pc</p> 
<p>5. Left Cabinet Right Side Panel, 1 pc</p> 	<p>6. Left Cabinet Bottom Panel, 1 pc</p> 	<p>7. Right Cabinet Top Panel, 1 pc</p> 	<p>8. Right Cabinet Bottom Panel, 1 pc</p> 
<p>9. Right Cabinet Left Side Panel, 1 pc</p> 	<p>10. Right Cabinet Right Side Panel, 1 pc</p> 	<p>11. Right Cabinet Middle Left Side Panel, 1 pc</p> 	<p>12. Right Cabinet Middle Right Side Panel, 1 pc</p> 
<p>13. Right Cabinet Back Panel, 1 pc</p> 	<p>14. Drawer Front Panel, 2 pcs</p> 	<p>15. Drawer Left Side Panel, 2 pcs</p> 	<p>16. Drawer Right Side Panel, 2 pcs</p> 
<p>17. Drawer Back Panel, 2 pcs</p> 	<p>18. Drawer Bottom Panel, 2 pcs</p> 	<p>19. Sliders, 2 sets (each set is for 1 drawer)</p>  <p>You will find on each set 4 pcs: 2 flat and 2 L-shaped</p>	


PARTS LIST (Part number, Description, Qty):

No.	PICTURE	SIZE	QTY	No.	PICTURE	SIZE	QTY
A		M6x35	26	E		St3x14	16
B		Φ8x30	34	F		Φ25	10
C		St7x58	16	G		Φ22	8
D		St3. 5x14	8				


HOW TO ASSEMBLE PARTS USING CAM BOLTS AND CAM LOCKS:

 • Cam bolt  • Cam lock


1. Screw the bolt into the corresponding panel.



2. In the other panel, insert and align the cam lock. Join the panels.



3. Turn the cam lock.



If the panel already comes with the cam lock inserted, make sure is aligned:



**MISALIGNED:
TURN CAM LOCK
TO POINT TOWARDS
THE HOLE**




CORRECT

ASSEMBLY STEPS:


STEP 1:


First insert the wooden pins (B) into the corresponding holes on panels(1) as shown, then assemble the panels(3) to (1) using cam bolts/locks(A) as shown and as explained in page 4.

A   M6x35 4 | **B**  $\phi 8 \times 30$ 4

**STEP 2:**


First insert the wooden pins (B) into the corresponding holes on the panel(5) as shown, then assemble the panels(2) to (1) using cam bolts/locks(A) as shown and as explained in page 4.


A   M6x35 2 | **B**  $\phi 8 \times 30$ 2



STEP 3:


First insert the wooden pins (B) into the corresponding holes on panels(1) and (3) as shown , then assemble them to the panels (2) and (5) using cam bolts/locks(A) as shown and as explained in page 4.

A  **M6x35** 2 | **B**  **φ8x30** 6

**STEP 4:**


First insert the wooden pins (B) into the corresponding holes on panels(1) as shown, then assemble the panel (4) to (1) using cam bolts/locks(A) as shown and as explained in page 4. Finally, Using screws (C), assemble the panel(2) to panels(3) as shown.

A  **M6x35** 2 | **B**  **φ8x30** 2 | **C**  **ST7x58** 4




STEP 5:

First insert the wooden pins (B) into the corresponding holes on panels(4) and (5) as shown , then Using screws (C), assemble the panel(6) to panels(4) and (5) as shown.


**STEP 6:**

First, Pasting Wool Feet (F) into the panel(6), then pasting the stickers (G) into the corresponding the panels(5) and (3).




STEP 7:

Separate the sliders (19) according to their shapes: The "L" shaped sliders (DL, DR) will be used until step 15, please set them aside. The flat sliders (CL, CR) are the ones being used in step 8.



STEP 8:


Assemble the sliders (CL) and (CR) to the panels (9) and (11), and to the panels (12) and (10) using screws (E) as shown. Please pay attention to the orientation of the parts.



STEP 9:


First insert the wooden pins (B) into the corresponding holes on panels (7) as shown, then assemble the panel (9), (11), (12) and (10) to (7) using cam bolts/locks (A) as shown and as explained in page 4.

- A** M6x35 8
- B** Ø8x30 8




STEP 10:

Insert the panels (13) in between the panels (9) and (10) as shown.,

**STEP 11:**

First insert the wooden pins (B) into the corresponding holes on the panels (9),(11),(12) and (10) as shown, then Using screws (C), assemble the panel(8) to panels(9),(11),(12) and (10) as shown.


B  $\phi 8 \times 30$ 8 **C**  ST7x58 8



STEP 12:


Pasting Wool Feet (F) on the the panel(8).
Turn over then cabinet.

F  $\phi 25$ 6

**STEP 13:**


Using screws(D), assemble the Back panel (17) to the panels (16) and (15) as shown.

D  ST3. 5x40 4

**STEP 14:**


Assemble the the panel(14) to the panels(16) and(17) using cam bolts/locks(A) as shown and as explained in page 4.

A  M6x35 4



STEP 15:


Assemble the L shaped sliders (19-DL) and (19-DR) to the bottom of the drawers using screws (E) as shown. Please note the orientation of the sliders; the rollers go at the back of the drawers, and they touch the wood on the bottom and the side.



REPEAT STEPS 13 TO 15 FIX ANOTHER DRAWER

STEP 16:

Insert the drawers to the cabinet as shown. The TV stand can be stretched and closed.



CARE, MAINTENANCE AND WARNINGS:

- ⚠ Do not expose the surfaces to direct sunlight or to extreme environmental conditions. Damages caused by this kind of exposure is not covered by the product's warranty.
- ⓘ Clean the surfaces preferable with a soft cloth damped with a solution of mild and water, then dry with a clean tower.
- ⚠ Do not use solvents or abrasive materials to clean any part of the unit.
- ⓘ Do not allow children to play over or under the unit.
- ⓘ Before moving or transporting the unit:
 - a) Remove all objects from the top, drawers and compartments that are heavy or might fall off.
 - b) If the unit is on glides, it is preferable to pull rather than push.
 - c) The unit must be handled by at least 3 persons, two holding the ends and one holding the outside corner. Use both of your hands and bend your knees, not your backs.
 - d) For easier transportation, you can also partially disassemble the unit into 2 sections: the tabletop with structures/privacy panel, and the cabinet.