

IMPORTANT: IN THE INTEREST OF PRODUCT PERFORMANCE AND SAFETY PLEASE READ THESE INSTALLATION AND WARRANTY INSTRUCTIONS BEFORE INSTALLING THE PRODUCT.



SAL products are designed in accordance with all mandatory International and Australian Standards, which require installation by a qualified installer and regular cleaning and maintenance of the equipment. Products are sold in accordance with the following instructions and SAL standard terms and conditions of sale, which are available via www.sal.net.au.

S-FIRE MK II LED Emergency light SELK1500SF2 electrical and installation specification effective 23/4/2018.

| Model No. | Input (V)/(Hz) | Power (W) | Recharge hours | Battery type | Emergency Classification | Mass (N.W. kg) | Colour | Dimension Ø x H (mm) |
|--------------------|----------------|-----------|----------------|----------------------------------|--------------------------|----------------|--------|----------------------|
| SELK1500SF2 | 240/50 | 4 | 16 | LiFePO ₄ , 6.4V 1.5Ah | D63 | 0.4 | White | 95 x 31 |

| | | | |
|---|-----------------------|--|---------------------|
| Electrical class | II inverter, III head | In-rush current | 10A@150µs |
| Power factor | > 0.6 | Earth Leakage current | <1mA |
| Operating ambient min/max (°C) | 0 ~ 40 | Storage ambient limit (°C) | 0 to 60 |
| Operating humidity | +10% to 85% RH, NC | Storage humidity | +10% to 85% RH, NC |
| Calculated TM - 21, L ₇₀ @ 85 °C (hrs) | >66,000 | Reported TM-21, 85 °C, L ₇₀ (hrs) | >54,000 |
| Aiming restrictions (if any) | No | Product application | Interior commercial |
| IK rating (if relevant) | NA | Product installation orientation | Ceiling horizontal |
| CCT (k) switch control | NA | Dimmable | No |
| Insulation cover rating (if any) | IC-4 (head only) | PIXIE connectivity | No |
| Replaceable LED | No | IP rating | 20 |
| User replaceable LED | No | Attachment type | X |
| Line current | Refer inverter label | Cut out | 70 mm |
| IP rating for interior products: The designated IP rating is "from below the ceiling" unless otherwise specified. | | | |
| IP rating ALL products; Termination of the product must be made in accordance with the IP rating. | | | |
| Earth Leakage current: Is calculated in accordance with AS/NZ 60598.1.2013 table 10.3. | | | |

Product application requirements:

- 1. Recycling** – SAL encourages recycling, please consider the environment when disposing off packaging and components.
- 2. Switching or test intervals** – For optimum product performance, good design practice does not encourage 24/7 operation of lighting products without the provision of a routine switching or regulatory test cycle. As a guide for continual operation installations, a twelve (12) hour duration for Industrial and Commercial applications and six (6) hour duration for Residential applications should be considered.
- 3. Product maintenance** – In line with the relevant design standards and to protect your investment, it is important to have in place a routine cleaning program that reflects the installation environment and maintains the product in a clean and functional condition.


IMPORTANT - The supply must be isolated before any product maintenance or cleaning is conducted. In addition, damage to ANY cable or cord supplied with the product must be addressed as follows; For attachment type X having a specially prepared cable, if the external flexible cable is damaged, it must be replaced by an equivalent cable exclusively available from the manufacturer or authorised installer. For attachment type Y, if the external flexible cable is damaged, it must be exclusively replaced by an equivalent cable by the manufacturer or authorised installer. For attachment type Z, if the external flexible cable is damaged, the cable cannot be replaced and the luminaire must be destroyed.

- 4. Adverse, corrosive and coastal installation applications** – Unless the product is specifically designated for such applications in these installation instructions, which is supported by a professional maintenance program; installation of equipment in such environments is not recommended.
- 5. Dimming products** – Dimming circuits and product compatibility must be validated by the installer before installation; SAL cannot be responsible for third party changes in dimmer compatibility.
- 6. Suspended products** – For installation safety, any suspended products must NOT be installed in high air movement spaces or locations subject to impact.

7. Specific installation procedures

7.1 Adapter for SELK1500SF2

If the size of the cut out is within the range of 86-135mm, add the accessory ring by fixing the springs into it and adjusting the lamp head in the right position.



7.2 Clearance dimensions

| Dimension | Clearance |
|--|-----------|
| The minimum clearance distance from the top of the luminaire to any normally flammable building element | 0 mm |
| The minimum clearance distance from the top of the luminaire to any building insulation | 0 mm |
| The minimum clearance distance from the side of the luminaire to any normally flammable building element | 0 mm |
| The minimum clearance distance from the side of the side of the luminaire to any building insulation | 0 mm |
| Side clearance to auxiliary equipment control gear (CG) (if supplied) | 100 mm |

7.3 Emergency enabled products – In the interest of transport and safety, emergency products are supplied with the battery disconnected. In addition to specific emergency commissioning instructions, this battery **MUST** be connected at the time of installation. Continual use in emergency mode greater than 240 hours without recharge, will result in battery failure and void battery warranty.

7.4 Commissioning and operation

- Switch on mains supply. The charge monitor LED will illuminate.
- Allow the unit to operate for 30 minutes and then depress the test switch to check emergency operation.
- Release the test switch and allow the unit to operate for 16 hours to fully charge the battery after which time the unit is ready for duty.
- Self-contained emergency luminaires shall be subjected to a battery discharge test for the required duration at regular intervals in accordance with AS/NZS 2293 applicable to emergency lighting. Batteries should be replaced with the same brand/type when the rated duration is no longer achieved.

Note: In the interest of safety, the 6 monthly test should be undertaken during daylight hours to allow for the possibility of failures of the standard lighting supply whilst the battery is discharged.

8. Warranty – In accordance with SAL's standard terms and conditions of sale, SAL warrant this product to be free from defects in materials and or workmanship for a period as stated below for goods not subject to incorrect installation, maintenance, operation, mishandling, environmental, unauthorised modifications or electrical operating conditions outside the nominated product specification as detailed in these installation instructions. The benefits to you given by this warranty are in addition to other rights and remedies you have under law. Our goods come with guarantees that cannot be excluded under the Australian Consumer Law. You are entitled to a replacement or refund for a major failure and compensation for any other reasonably foreseeable loss or damage. You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and the failure does not amount to a major failure.

Warranty term – Twenty four (24) months from date of purchase.

How to make a claim?

Step # 1 – Within 30 days of the fault discovery, please contact the original place of the SAL product purchase during standard (local) business hours, with the following information (a) proof of purchase (b) description and quantity of the claimed fault (c) address of installation. (d) operating hours of the product.

Step # 2 – It is then the responsibility of the original place of product purchase to report the matter to SAL aftersales;

NSW | ACT | QLD – SAL Pty Ltd 40 Biloela Street Villawood NSW 2163 | P: 02 9723 3099
VICT | TAS | SA | NT | WA – SAL Pty Ltd 46-48 Keys Road Moorabbin Victoria 3189 | P: 03 9532 3168

Step # 3 – Upon review of your claim and if the product is required to be returned to SAL for technical evaluation, then at the owners expense the product must be returned to SAL as per the above nominated locations.

Step # 4 – Pending the evaluation, the claim will be validated resulting in the product being repaired or replaced with the same or best equivalent product at the discretion of SAL, or rejected if the product fault was found to be caused by conditions beyond the responsibility of SAL warranty obligations. Consideration of installation, product removal, return freight and or testing fees are not the responsibility of SAL.