

PUSH HC-97

CHARGER 2.1 Rebound Tuning Guide

This guide applies to Charger 2.1 only. (Orange band on the Red Piston)



- Step 1 - Select your Rebound Code based on your rider weight range.
- Step 2 - Use a ruler or caliper to identify the shims for the selected Rebound Code.
- Step 3 - Lay out the shims in the order defined below on a clean lint-free surface.
- Step 4 - Install the shims onto the Rebound Bolt starting with the 15mm shims.

REBOUND CODE	WEIGHT RANGE
STOCK	< 160
RP4	160 - 190
RP5	190 - 220
RP6	220 <

