




3.4' X 7.3' BLACK STEEL WALL- AND FLOOR-MOUNTED MODULAR PIPE WARDROBE KIT

NEED HELP OR ADVICE PUTTING THIS KIT TOGETHER? MISSING PIECES?
EMAIL US AT SUPPORT@PIPE-DECOR.COM FOR ANY QUESTIONS



HOW TO PREVENT PIPE CORROSION

PIPE DECOR industrial-grade black pipes and fittings are coated with a rust-preventive oil during manufacturing. For best results, **SEAL THE PIPES TO AVOID ANY RUSTING** after cleaning the kit.

CLEAN AND SEAL INSTRUCTIONS:

CLEAN: Recommended supplies: regular degreasing dish soap, washcloths, gloves (optional)
1. Wash your pipes and fittings with warm water and dish soap until the oil is completely removed.
2. Wipe the pipes with a dry washcloth and wait until the pipes are completely dry.

IMPORTANT: THE PIPES MUST BE COMPLETELY DRY BEFORE YOU START THE SEALING PROCESS.

SEAL:

IF USING POLYURETHANE SPRAY: Spray each dry pipe and fitting with a polyurethane matte or satin finishing spray and let it dry before assembling the kit.

IF USING FINISHING WAX: Coat each dry pipe with a finishing wax. Wait for 20 minutes, then polish the pipe with a dry washcloth by wiping them down. Faster wiping will result in a shinier finish.

RESORE PIPE DECOR®

3.4' X 7.3' BLACK STEEL WALL- AND FLOOR-MOUNTED MODULAR PIPE WARDROBE KIT


EASY INSTALLATION:

RECOMMENDED TOOLS FOR INSTALLATION




STEP 1


Start with the longest nipple (36")




STEP 2




STEP 3



STEP 4




STEP 6



Anchors will be installed
IF NO WALL STUD IS
PRESENT.

PART	DESCRIPTION	QTY
A	1/2" FLANGE	6
B	90° ELBOW	2
C	1/2" SIDE OUTLET TEE	2
D	1/2" COUPLING	2
E	12" NIPPLE	6
F	36" NIPPLE	5
G	SCREWS/ANCHORS	16

STEP 5



- Place flange against wall in desired location and mark holes with pencil
- Using stud finder, locate and mark wall stud if found
- **If a wall stud is present**, attach flange to wall with included screws
- **If no wall stud is present:**
 - A) Drill pilot holes in wall using 1/4" drill bit
 - B) Insert anchor fully into pilot hole using hammer and Phillips screwdriver as needed
- Attach flange to wall using included screws