


B3 bench Assembly instructions

Parts list



Handles: 2x

Legs: 2x

IMPORTANT!

Marks have been punched on the inside faces of the legs and under the seat. They identify which leg goes on what side. Be sure to install the legs accordingly.

Seat: 1x

Tensioner: 1 per shelf.
Provided only with 48 in. benches.

Tensioner: 1x (2x for 2 shelves configuration)

Provided only with 48 in. benches.

Screws: 8x

Corner brackets: 2x

Bolts: 4x

4mm hex key: 1x


Shelf pins: 4x (8x for 2 shelves configuration)

Shelf: 1x (2x for 2 shelves configuration)

IMPORTANT!

If your bench is equipped with two shelves, one will be wider than the other. The wider one should be installed first at the lower position.


1.




IMPORTANT!

Don't forget to install the legs according to their marking: the two punched marks should go together and the same goes for the single punched holes.

2.




3. Only for 48 inches benches



Install the two corner brackets using the eight (8) provided screws. Start with the screws that go under the seat and then with the screws that go in the legs.


4.



Slide the shelf trusses over the legs, starting from the narrow part, underneath the seat.


If your configuration has 2 shelves, start with the wider one. By comparing the two, you'll see one is wider than the other.

5. Only for 48 inches benches




The 48" trusses have insets cut at an angle. When installed, this angle should be parallel to the angle of the leg. Otherwise, the shelf top surface won't be horizontal.

6.




Lower the shelf until it's aligned to its corresponding hole. The rope should feel quite tight at this point.

7.




Push one side of the shelf so it goes lower, under the holes on the corresponding leg so you have room to insert the brass pin.

There will be a bit of resistance in the shelf due to the rope tension. This is normal. Once all the brass pins are installed, this makes for a very solid shelf assembly.




IMPORTANT!

The brass pin flat side should face towards the floor, not up.




Repeat the operation for the other side of the shelf and the higher shelf if you have a two shelves configuration.

8. Only for 48 inches benches



If it's not already done, place the two threaded rods and wing nuts into the wood block so you get the same assembly as the image to the left.




Unscrew the wing nuts so the rods sit deeper into the wood block.




This allows to shorten the overall length of the tensioner unit so you can insert it between the shelf trusses.

9. Only for 48 inches benches




Align the tensioner rods with the holes located in the middle of the shelf trusses, on the interior side.



Screw the nuts until the tips of the rods reach the bottom of the holes pierced in the trusses.

The more you screw the nuts, the more the trusses spread. Adjust the nuts so the trusses are parallel.

You're done!



Need help?

For any questions or request about your order or if you think there's something missing in the box, contact us by email. We'll respond quickly, as always. Please make sure to write your order's number and your name in the email title.

info@usetcoutumes.com
www.usetcoutumes.com

2025A Masson, suite 101A
Montreal, Qc, Can
H2H 2P7