

# Chicken Run Assembly

---

## Step 1

Identify the section of your new chicken run. Ex. Front (always has the door) back, side, etc....

## Step 2

Measure the side or the “end” of your run. This will determine the placement of the sides of the run against the exterior wall of the coop.

## Step 3

Place the back wall of the run against the corner trim of the coop. There should be some pre-drilled holes on the outside of the run. This run wall should be lined up with the siding of the coop NOT flush with the outside of the trim itself. \* approximately 1” in from the outside edge of the trim.

## Step 4

Fasten the run into the trim piece using 3” screws into the pre-drilled holes.

## Step 5

Now use the measurement from step #2 and mark this measurement on the trim so the distance between this wall and the front wall measures the same as the end wall.

## Step 6

Fasten the front wall with the door using the same method you used in steps 3-4. \* door should be on the far side of the coop.

## Step 7

Now place the end wall between the 2 sides and fasten through the side walls with 3” screws.

## Step 8

Place the top on the run. It should fit flush with the outside of the walls. Fasten with 3” screws through the top into the walls.

## Step 9

You will likely have to use the short pieces of 1x4's (these should be in your kit) to close off the gap between the run and the coop at the very bottom of the corner trims. These will fasten directly into the bottom board of the run with the shorter wood screws provided.

**Congratulations! You're all done!**