

 AVI_8

For more details on operating this timepiece please refer to the enclosed booklet or visit:

AVI-8.COM



AVI-8

**HAWKER
HARRIER**

MATADOR CHRONOGRAPH

For more information
Pour plus d'informations
Para más información
Per maggiori informazioni
Für mehr Informationen
想要查询更多资讯
詳細については



Instruction Manual


Vol. 1.65 EN

AV-4065

CHRONOGRAPH WATCH


This watch is powered by a quartz Chronograph movement capable of split micro measurements of time.

With pinpoint accuracy you may use this watch to measure separate periods of elapsed time while simultaneously reading the current time.




For more details on operating this timepiece please refer to the enclosed booklet or visit:

AVI-8.COM




HOW TO SET THE TIME

1. Pull the crown to position [2]-(2nd click).
2. Turn the crown clockwise to set the correct time.
3. Push the crown in.



HOW TO SET THE DATE

1. Pull the crown to position [1]-(1st click).
2. Turn the crown clockwise to set the correct date.
3. Push the crown in.




* If the date is set between the hours of around 9:00 P.M. and 3:00 A.M., the date may not change on the following day.


STOPWATCH FUNCTION

- This chronograph is able to measure and display time in 1/20 second united up to maximum of 59min 59sec.
- The chronograph 1/20 second hand moves continuously for 30 seconds after starting, and then stops at Zero position.

STANDARD MEASUREMENT



ACCUMULATED ELAPSED TIME MEASUREMENT



Restart and stop of the stopwatch can be repeated by pressing the button A.

CHRONOGRAPH RESET



(incl. after replacing battery)

This procedure should be performed when the chronograph second hand does not return to the Zero position.

1. Pull the crown out to the [2]-(2nd click).
2. Press the button "A" once to set the chronograph second hand to the Zero position.
3. Press the button "B" once to set the chronograph 1/20 second hand to the Zero position.

* The chronograph hands can be advanced rapidly by continuously pressing button "A" or "B".

4. Once the chronograph hands are set at Zero position, readjust the normal hour and minute hands to the correct time and return the crown to its normal position.



USING THE TACHYMETER


The most common use of a tachymeter is for measuring the approximate speed of a vehicle over a known distance.

(E.g.) Based on how many seconds it takes a vehicle to travel 1 km or 1 mile (the available measuring range is up to 60 seconds), the average speed within the distance can be calculated.

1. Start the chronograph when the vehicles commence travel.
2. After the vehicle has travelled 1 km/1 mile, stop the chronograph.

The approximate average speed within the distance can be determined by observing the present position of the stopwatch second hand and reading the outer bezel.


THE AVERAGE SPEED IS 80 KPH



Note: The tachymeter indications may appear on dial ring, rather than on the outer bezel (depending on model).

As shown in the illustration, it takes the vehicle 45 seconds to travel 1 km so the approximate average speed is 80 kph (50 mph).

HOW TO USE A DEPLOYANT CLASP




1. Flip the cover.

2. Press the buttons on the clasp sides.


HOW TO RESIZE METAL BRACELET

On the inside of the bracelet, you will see some small arrows engraved on removeable links.




1.


2.




3.




4.




5.



6.




7.




8.

Nylon Head
Hammer




9.


Micro size
adjustment




10.



11.




12.



WATER RESISTANCE

Note that the water resistance chart serves only as a guide (please refer to the water resistance chart on the next page). Actual water resistance may vary depending on a number of factors including water temperature, water salinity and use under water. The water resistance of your timepiece may eventually be compromised over time with general wear and tear and use of your timepiece under adverse conditions.

Note that you should **NEVER** wear your watch in a jacuzzi, hot shower or steam room where steam may enter the case despite the watertight seals used to protect your watch. This may cause condensation inside your watch, which may affect and damage the inner workings of your watch.

WATER RESISTANCE CHART	50M/ 5ATM
SPLASH/ SHOWERING	
SWIMMING/ BATHING	
BRIEF SWIMMING/ WATER SPORTS	
PROLONGED SWIMMING/ FREE DIVING	
SCUBA DIVING	
PROFESSIONAL DEEP SEA DIVING	

Represented By:

Authorised Rep Compliance Ltd.,
Ground Floor, 71 Lower Baggot Street,
Dublin, D02 P593, Ireland.

