

Professional **TRADE** Low Sheen

WM2043



**Description**

Wallmaster Professional Trade Low Sheen is a hard wearing and scuff-resistant interior wall finish with excellent washability. The product glides on evenly then levels to an ultra-smooth finish with an elegant look. It provides a tough, long lasting finish which bonds extremely well to the surface and meets the A.P.A.S. low VOC targets. The soft touch technology provides a silky-smooth surface that is soft to the touch, yet with a solid feel. It incorporates mould and bacteria resistant technology, making it ideal for the whole home, including kitchens and bathrooms.

**Principal Uses**

Interior, paper faced boards, plaster, fibrous plaster, cement sheet, masonry and brick. Do not use this product for any other purpose than as specified in our literature.

**Features**

**Hard Wearing-With Good Washability**

WALLMASTER Professional Trade Low Sheen is a tough, hard wearing and long-lasting finish for any interior wall. It provides a smooth and very non-abrasive finish that is easy to clean and wipe free of most household stains.

**Excellent Flow & Levelling**

The product is very smooth and even to apply with brush or roller and has excellent surface grip during application. Brush and roller marks flow and level out evenly resulting in smooth and uniform cover.

**Excellent For Same Colour Recoats**

WALLMASTER Professional Trade Low Sheen incorporates moderate levels of opacifying pigments and when tinted to the final wall colour gives good opacity versus cost benefit. It is the ideal product for use where lower cost is required in areas that are regularly repainted in the same colour such as flats and rental units.

**Low VOC-Low Odour**

Meets the Australian Paint Approval Scheme low VOC targets.

**Asthma & Allergy Friendly**

The formulation is free of known desensitizers, formaldehyde generators and or odour masking agents.

**Australian Made and Owned**

Astec Paints are an Australian owned and operated company that has been manufacturing premium finishes for the building and home restoration industries since 1978. For over four decades we have produced our entire product range in our South Australian plant. We are proud of what we make and that our products can carry the Australian Made and Owned Logo.



**Technical Data**

Clean-up	Water
Coverage	Up to 12 m <sup>2</sup> /litre, surface dependant. Spread rate will be lower on rough and or absorbent surfaces.
Volume Solids.	28.00%
Recoat Time	Touch dry 30 minutes      Recoat 4 hours
Gloss Level	5.8 @ 60 degrees
V.O.C	<14.85 gL

## Application Data

### Application

Stir well before use with a flat paddle or with a metal paint wacker using an up and down scooping action. Apply two coat WALLMASTER Professional Low Sheen. For best results use a new, unused 10 to 12 mm synthetic roller cover and a high-quality synthetic brush. Remember, worn roller covers will produce a poor result. NOTE: the number of coats required to achieve full cover will depend on application technique and/or the underlying substrate colour. Do not apply to surfaces that have had wax or silicone-based materials previously applied. Do not apply when ambient temperature is below 10°C, above 35°C or when humidity is very high.

## Surface Preparation

### New Interior Unpainted Paper Faced Wallboards

Lightly sand any joints where NECESSARY and brush down the surface to remove any dust. Apply one coat Wallmaster Acrylic Primer Undercoat.

### New Interior Unpainted Plaster and Fibrous Plaster

Brush down the surface to remove any dust. Apply one coat Wallmaster Multi-Block Primer Acrylic Undercoat to the entire surface.

### New Interior Unpainted Fibro Cement Sheet

Brush down the surface to remove any dust. Apply one coat Wallmaster Acrylic Primer Undercoat to the entire surface.

### New Interior Unpainted Masonry and Brick

Brush down the surface to remove any dust. Apply one coat Wallmaster Acrylic Primer Undercoat or Wallmaster Multi-Block Primer Sealer Undercoat to the entire surface.

### New Interior MDF

Lightly sand, remove all dust & apply one coat Wallmaster Acrylic Primer Undercoat or Wallmaster Multi-Block Primer Sealer Undercoat to the entire surface.

### New Interior Timber

Lightly sand, remove all dust & apply one coat Wallmaster Multi-Block Primer Sealer Undercoat to the entire surface.

### Water Stained Timber and Paper Faced Wallboards

Brush down the surface to remove any dust. Apply one coat Wallmaster Multi-Block Primer Sealer Undercoat to the entire surface.

### Mould Infested Areas

Wash down using a stiff brush with a household bleach and water to remove the mould. Rinse off well with water and allow to dry. Apply one coat Wallmaster Multi-Block Primer Sealer Undercoat to the entire surface.

## Paint Disposal

Do not pour left over paint down the drain. Brush any leftover paint onto newspaper and allow to dry in a well-ventilated area. Dispose of the dry paint via domestic waste disposal. Empty cans should be left open and allowed to dry then disposed of in accordance with your local recycling legislations.

## Safety Direction

Keep out of reach of children, provide adequate ventilation during use and do not dispose of left-over paint in any drainage systems.

## First Aid

### Eye Contact

Irrigate continuously with water for fifteen minutes holding eyelids open. Seek Medical advice.

### Swallowed

Contact a doctor or Poisons Information Centre immediately. Do not induce vomiting. Give a glass of water. If vomiting does occur, place victim's face downwards at low level to prevent vomit entering lungs. Contact Astec for the relevant Material Safety Data Sheet.