


### LARGE TRIANGLE




### **ASSEMBLY PARTS**






Video assembly here! Scan to watch.







- 1. Take the Short sidewall (1.2).
- 2.Put the round head screw (2.2) into the hole with the metal washer (see pic.1.1) and screw it into the long nog (1.3).
- 3. Screw 5 flat head screw (2.1; see pic.1.2) to the long nogs (1.3).



- 1. Take the Long Sidewall (1.1), Long nog (1.3), Left connector (1.4), and Right connector (1.5).
- 2. Fasten parts 1.4 and 1.5 with screws 2.1. Letters on the Connectors 1.4 and 1.5 inward should hok (see pic.2.3), as shown in the picture (see pic.2.1). Do not tighten the screws 2.1 on the connectors(see pic.2.2).
- 3. Fasten the rest of the 1.3 using thescrews 2.1 (see pic.2.3).








# **LARGE ARCH**




ASSEMBLY PARTS





Video assembly here! Scan to watch.





Screw two parts 1.1(p.1) to parts 1.2(p.1)


with screws 2.1(p.1) using a wrench 2.2(p.1) (see picture)



## LARGE RAMP




### **ASSEMBLY PARTS**





Video assembly here! Scan to watch.





Screw the hooks (1.2) to the Ramp (1.1) with the confirmat Screws (2.1). Tighten with the 3mm hex key (2.2).