



STANDARD TRIANGLE ASSEMBLED




ASSEMBLY PARTS







- 1.Take the Short sidewall (1.2). There are 7 holes in the Short sidewall.
- 2.Put the round head screw (2.2) into the hole with the metal washer (see pic.1.1) and screw it into the long nog (1.3).
- 3.Screw 5 flat head screws (2.1; see pic.1.2) into the long nogs(1.3) through the short sidewall.



- 1. Take the Long Sidewall (1.1), Long nog (1.3), Left connector (1.4), and Right connector (1.5).
- 2. Fasten parts 1.4 and 1.5 with screws 2.1. Letters on the Connectors 1.4 and 1.5 inward should hok (see pic.2.3), as shown in the picture (see pic.2.1). Do not tighten the screws 2.1 on the connectors(see pic.2.2).
- 3. Fasten the rest of the 1.3 using thescrews 2.1 (see pic.2.3).








STANDARD ARCH ASSEMBLED




Video assembly here!



ASSEMBLY PARTS







Screw two parts 1.1(p.1) to parts 1.2(p.1) with screws 2.1(p.1) using a Hex key 2.2(p.1)




STANDARD RAMP ASSEMBLED




Video assembly here!



ASSEMBLY PARTS







Screw the hooks (1.2) to the Ramp (1.1) with the confirmat screws (2.1). Tighten with the 3mm hex key (2.2).