

Goldair™

select



Operating Instructions

GTRM & GTRL Series Towel Warmers



GTRM*



GTRL*

* Available in either stainless steel or white

For Models: GTRMC, GTRMW, GTRLC, GTRLW

Safety Information

YOUR SAFETY IS IMPORTANT TO US.

PLEASE ENSURE YOU TAKE NOTE OF THE INSTRUCTIONS AND WARNINGS OUTLINED IN THIS MANUAL.

When using any electrical appliance, basic safety precautions should always be observed.

PLEASE READ THESE INSTRUCTIONS CAREFULLY




- This appliance is intended to warm and dry towels and therefore is hot to the touch. When used by or near young children or infirm persons, close supervision is necessary.
- Young children should be supervised to ensure that they do not play with the appliance.
- Any rise in ambient temperature is directly reflected in the appliance, and as a result of this, the appliance will feel hotter to the touch during warmer periods. Also the insulation effect of towels will cause the operating temperature to increase slightly.
- The towel rail is to be installed so that switches and other controls cannot be touched by a person in the bath or shower.
- To avoid a hazard this heated towel rail **MUST NOT** be used to carry towels or any other articles that have been in contact with oil, petroleum based products or dry cleaning fluids.
- Use this appliance only with the voltage specified on the rating label, or elsewhere in these instructions.
- Regulations require that electrical work be carried out only by authorised persons. For your own safety and that of others ensure this is done.
- **DO NOT** immerse in any liquid.
- For service contact your nearest Authorised Service Agent.
- **WARNING:** In order to avoid a hazard for young children, this appliance must be installed so that the bottom rail is at least 600mm above the floor.
- **DO NOT** use this appliance for any purpose other than its intended use.

Specifications




DIMENSIONS		
Model:	GTRM*	GTRL*
Height:	630mm	605mm
Width:	560mm	730mm
Depth:	85mm	85mm
ELECTRICAL		
GTRMW	50W	220-240VAC 50Hz
GTRMC	40W	220-240VAC 50Hz
GTRLC	60W	230-240VAC 50Hz
GTRLW	60W	230-240VAC 50Hz
International Protection Rating: IP55		

Dimensions

GTRMC



GTRLC



Components




3 x Leg Brackets



6 x Screws



3 x M5 Long Screw



6 x Wall Plugs



6 x Screw Hole caps

Installation

WARNING: Installation must be completed by a registered electrician.

Always choose a safe location for the Towel Rail, keeping in mind the safety precautions outlined. Ensure all packaging has been removed from the unit before use.




Figure 1 – Wall Mounted Towel Rail

Installation cont.

This appliance **MUST** be installed in accordance with the relevant wiring rules and regulations and in particular those regulations which cover installation of appliances and accessories in damp situations such as bathrooms, showers, laundries and other areas with fixed water containers. It is to be fitted in accordance with applicable Australian/New Zealand standards (AS/NZS).

In accordance with New Zealand's wiring regulations this appliance is required to be connected to a power supply that includes an earth circuit. This appliance cannot be connected to a two wire (lighting) power circuit.

WARNING

- In order to avoid a hazard for young children, this appliance must be installed so that the bottom rail is at least 600 mm above the floor.
- Special purpose tools are required for the replacement of the power supply cord and element. Contact an Authorised Service Agent for service.
- Please note that if mounting your Heated Towel Rail yourself contact your local hardware professional for advice on the best mounting hardware for your walls, as this may vary.

NOTE: Attempting to fix into plasterboard or cement sheeting alone is not recommended. Plasterboard in particular will not hold long term.

WALL PREPARATION

- Goldair Heated Towel Rails may be fixed to any type of timber stud, steel stud or masonry (solid or cavity) wall.
- Walls made from timber or steel require studs at the correct position for all rails. If the precise position can't be determined early in the job, consider sheets of 18mm construction ply, covering a larger area.
- This rail has a small footprint against the wall. The wire holes and mounting holes must be drilled neatly and accurately.
- For drilling through hard materials such as porcelain tiles, marble, granite etc. an appropriate drill bit must be used.
- No responsibility will be taken by Goldair for instances where installers drill incorrectly.

Electrical installation

WALL MOUNTED MODELS: GTRM AND GTRL

- Choose a suitable position on the wall to mount the Heated Towel Rail. The flex entry can be either on the left or right hand side but it must be horizontal and at the bottom of the frame.
- Fit the leg brackets and straps loosely to the frame, in the positions shown in figure 1.
- Place the Heated Towel Rail on a flat surface, check that all the leg brackets are sitting parallel and then tighten the screws, enough to hold the brackets firmly against the frame, without over tightening.
- Level up the top rail of the Heated Towel Rail and fasten to the wall with either the screws provided or with suitable toggle bolts.
- Fit the screw caps to cover the screw holes in each of the leg brackets.

PRE WIRING

NOTE: Only drill holes when you are 100% sure of your measurements.

A means for disconnection must be incorporated in the fixed wiring in accordance with the wiring guidelines AS/NZS 3000:2007.

WALL MOUNTED TOWEL RAILS ARE ONLY TO BE MOUNTED ON HEAT RESISTANT WALLS THAT COMPLY WITH CURRENT AS/NZS SPECIFICATIONS & BUILDING REGULATIONS

Operating your Towel Rail

ELECTRICIAN INFORMATION

A copy of this User Manual should be left with the consumer for future reference.

A means for disconnection must be incorporated in the fixed wiring in accordance with the wiring guidelines AS/NZS 3000:2007.

HEAT CONTROL

These towel rails run at a single temperature. Be aware they do get very hot to the touch.

CAUTION: The Towel Rail generates heat during use. Proper precautions must be taken to prevent the risk of burns, scalds, fires or other damage to persons

Do not attempt to dismantle the Towel Rail. There are no user serviceable parts. For service or repair, contact an authorised electrical service technician.

CARE AND CLEANING

The Towel Rail requires regular cleaning to ensure longevity of the product.

Turn off the isolating switch before cleaning. For additional protection, turn the mains supply off before cleaning.

Ensure that the towel rail has been allowed to cool down completely before cleaning.

Use a damp cloth (not wet) to wipe the exterior of the towel rail to remove dust and dirt.

Never use solutions such as benzene, thinners or polishing agents.

Never use abrasive materials like steel wool / scourers to scrub the towel rail.

Ensure the Towel Rail is dry before switching back on the mains supply and isolating switch.

RUST

Surface rust can occur on stainless steel over time. To avoid this the Heated Towel Rail is best wiped down from time to time with a damp cloth and a stainless-steel cleaner. Fine scratching can be removed using a metal polish such as 'Autosol' or 'Brasso' Paste which are available from most supermarkets and car care shops.

PROOF OF PURCHASE

To receive warranty, retain receipt as proof of purchase.

Goldair[™]

SUPPORT AND TECHNICAL ADVICE

Goldair – New Zealand

Monday – Friday 8am-5pm

Phone +64 (0)9 917 4000

Phone 0800 232 633

info@cdb.co.nz

Goldair – Australia

Monday – Friday 8am-5pm

Phone +61 (0)3 9336 4423

Phone 1300 465 324

info@cdbgoldair.com.au



Two Year Warranty

Thank you for purchasing this Goldair product. Your product is warranted against faults and manufacture when used in normal domestic use for a period of **two years**. In non-domestic use Goldair limits the voluntary warranty to **three months**.

Goldair undertake to repair or replace this product at no charge if found to be defective due to a manufacturing fault during the warranty period.

This warranty excludes damage caused by misuse, neglect, shipping accident, incorrect installation, or work carried out by anyone other than a qualified electrical service technician.

PLEASE KEEP YOUR RECEIPT AS THIS WILL HELP VERIFY YOUR WARRANTY.

The benefits given to you by this warranty are in addition to other rights and remedies available to you under law in relation to the goods or services to which this warranty relates.

In Australia, our goods come with guarantees that cannot be excluded under the Australian Consumer Law. You are entitled to a replacement or refund for a major failure and compensation for any other reasonably foreseeable loss or damage. You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and the failure does not amount to a major failure.

In New Zealand this warranty is additional to the conditions and guarantees of the Consumers Guarantee Act (1993).

Goldair – New Zealand

CDB Goldair
PO Box 100-707
N.S.M.C
Auckland

Phone +64 (0)9 917 4000
Phone 0800 232 633
www.goldair.co.nz

Goldair – Australia

CDB Goldair Australia Pty
PO Box 574
South Morang
Victoria, 3752

Phone +61 (0)3 9365 5100
Phone 1300 GOLDAIR (1300 465 324)
www.goldair.com.au

Goldair Two Year Warranty (IMPORTANT: Please complete and retain this warranty card)

Name _____

Address _____

Place Of Purchase _____

Date Of Purchase _____

Name Of Product _____

Model Number _____

Attach a copy of the purchase receipt to this warranty card

Goldair™

select



CDB  **Goldair™**

New Zealand
PO Box 100707,
North Shore Mail Centre,
Auckland, 0745
www.goldair.co.nz

Australia
PO Box 574,
South Morang,
Victoria, 3752
www.goldair.com.au