

Realplate with Tacx Neo

1.  Place the Neo onto the Realplate using the 4 circles to place the feet in, this ensures your Neo is central.
2.  Using the supplied Velcro, secure the arms of your Neo tightly.
3.  Once you are happy, position the supplied air bladders & adjust the air in the 2 bladders. Get on the bike to ensure you and the set up is level, then keep adding air until you feel the response is correct for you.
4.  Add the velcro dots to the feet of the Neo's riser and the front of the Realplate where suited
5. Ride.....

Important information regarding the air bladders

Your Rocker Plate is delivered with just enough air in the bladders for transport so please follow these simple instructions before use:

set up the bike and trainer so the centre of the bottom bracket is along the centre line of the Rocker Plate

Add a little air in each bladder - you may need to add a little more in the left bladder to compensate for the additional weight of the trainer's flywheel. One you have added air get on the bike and see how the rocking motion feels.

Repeat the step above until you have the right feel and you and the bike are level. Over time you may need to add a little air as its released under training

Remember, the idea is to have a full rocking motion so don't be tempted to add too much air. You want the Rocker Plate to move as much as possible. This WILL take some getting used to but please bear with it, soon you will love the feel.

Also, please do not worry about PSI and pressure gauges, the bladders will inflate to over 6PSI but if you are getting anywhere close to that pressure, the Rocker Plate will be almost static and have little or no movement.

