

LUNA Pendant Installation Guide

- Suspended mounted only.
- Certified electrician recommended for electrical installation.
- Minimum 3 people recommended for installation.
- Terminal Block not included. Installation may require advice from a qualified person.
- Junction box rated for minimum of 100lbs or structural blocking required to support fixture.
- Structural blocking required at monopoint locations, adequate drywall plugs may be substituted.
- For all LED fixtures, use only with class 2 power unit.
- The light source contained in this luminaire shall only be replaced by the manufacturer or his service agent or a similar qualified person. Contact manufacturer for service.

*** IMPORTANT: Please provide email confirmation that your order and its related components have been received in their entirety and in good condition. Failure to do so within 7 days of delivery will waive all product warranties.**



e: info@GabrielScott.com

t: (646) 783-3770

GABRIEL SCOTT
EST 2012



Provided Supplies:


- Luna pendant
- Universal T-bar
- Installation screws
- LED Driver

Required Tools & Hardware:

- Screwdriver
- Drywall anchor suitable for 25lbs for mono points
- 4x 2-pole wiring terminals, screw or screwless, 12-18AWG (1.0-2.5mm²), rated for 600V, 15A -ex: WAGO 222-412
- Requires LED driver; Input: Local line voltage, output 24Vdc SELV, 5A, max 60 Watt, Class 2 LED driver.


STEP
1

Carefully slide the glass beads over the Luna tubes.



STEP
2

Place the canopy over the threaded nipple and secure it in place with the provided nut.



STEP
3

Using wire terminals, connect the LED driver to the Luna fixture. On Gabriel Scott fixtures, the black wire (+) is positive, and the white wire is the negative (-). Next, again using wire terminals, connect the LED driver to the power supply. Finally, attach the universal T-bar and screw the canopy with the provided screws.

