

INSULIN PUMP PATCH

KTTM TAPE

PRO EXTREME[®] WATER RESISTANT ADHESIVE



1 BEFORE YOU APPLY

Follow all directions and use the following tips for best results and enhanced water resistance.



APPLY BEFORE ACTIVITIES

Apply one hour before exercising or exposing to water.



CLEAN SKIN

Use rubbing alcohol to ensure skin is clean and free from oils or lotion. Allow to dry.






TRIM HAIR

Trim hair for best adhesion.



CAUTION: If you have skin sensitivities, cancer, or are pregnant, consult your doctor before use. Improper application or applying on areas of sensitive skin may result in skin irritation. Stays secure and can be worn up to 7 days.

2 HOW TO APPLY



AVOID TOUCHING ADHESIVE

Avoid touching the adhesive side of the patch to prolong adhesion.

VIDEO INSTRUCTIONS



3 AFTER YOU APPLY

Follow these care tips to ensure best results.



TRIM LIFTING EDGES


Trim with scissors any frayed or lifted edges.



DO NOT DRY WITH HEAT

When the patch is wet, gently pat dry with a towel.

4 HOW TO REMOVE



1 For easier removal, apply baby oil to patch 5 minutes before removing.

2 Peel the patch up at the edge.

3 If leaving the device on, place finger on device to hold in place while removing patch.

4 Gently and slowly pull tape back – not up.