


# INSTRUCTION MANUAL

## Discover The World Around!

Your National Geographic 4x30 binoculars are the perfect companion for countless outdoor adventures. With these sturdy binoculars, you can investigate amazing species and sights. Take them on a nature walk to get a detailed look at birds and other wildlife without disturbing them. Take them on a hike to navigate your path and view distant landmarks. Most of all, keep them close by for on-the-go exploration.



## Determining Eye Distance

The distance between one's eyes varies from person to person, so it is essential that you adjust your binoculars before you use them. Take the binoculars in both hands (Fig. 1) and hold them to your eyes. Fold them so that you see a single circle when looking through them (Fig. 2).

## Adjusting The Focus

To adjust the focus, simply turn the center focus wheel (Fig. 3).




Fig. 1




Fig. 2




Fig. 3

## Did You Know?

Two numbers are usually used to describe binoculars — such as 4x30. The first number indicates magnifying power, which determines how much closer an object will appear, and the second is the aperture of the objective lens, which determines how much light can enter the device.

## Cleaning Instructions

To clean the eyepieces and/or objective lenses, only use a soft, lint-free cloth like a microfiber cloth. Do not apply excess pressure to the cloth to avoid scratching the lenses. To remove more stubborn dirt, moisten the cleaning cloth with an eyeglass-cleaning solution and wipe the lenses gently being careful to avoid excess pressure. Protect this device from dust and moisture. When using in high humidity conditions, let the device acclimatize for a short period of time before storing so that residual moisture can dissipate.

## SAFETY WARNINGS

### Read and follow the instructions, safety rules, and first aid information.

- Respect privacy: When using this device, respect the privacy of other people. For example, do not use them to look into people's homes.
- Risk of fire: Do not place device, particularly the lenses, in direct sunlight. The concentration of light rays could cause a fire.
- Choking hazard: Children should only use device under adult supervision. Keep packaging materials like plastic bags and rubber bands out of the reach of children as these materials pose a choking hazard.
- Do not disassemble this device. In the event of a defect, please contact your dealer. The dealer will contact the Customer Service Department and can send the device in to be repaired if necessary.
- Risk of blindness: Never use this device to look directly at the Sun or in the direct proximity of the Sun. Doing so may result in a permanent loss of vision.
- Do not subject the device to temperatures exceeding 60° C [140° F].



- Disposal: Keep packaging materials, like plastic bags and rubber bands, away from children as they pose a risk of suffocation. Dispose of packaging materials as legally required. Consult the local authority on the matter if necessary and recycle materials when possible.

## CONTENTS



**WARNING**  
CHOKING HAZARD – Small parts. Not for children under 3 years.

3

©2018 National Geographic Partners LLC. All rights reserved.  
NATIONAL GEOGRAPHIC and Yellow Border Design are trademarks of the  
National Geographic Society, used under license.

©2018 Explore Scientific, LLC.  
1010 S. 48th Street, Springdale AR 72762  
All rights reserved. [explorescientificusa.com](http://explorescientificusa.com) | [exploreone.com](http://exploreone.com) | 866.252.3811  
Made in China

CONFORMS TO THE SAFETY REQUIREMENTS OF ASTM F963



AGES  
8+

## CONTENTS

## INSTRUCTION MANUAL

**WARNING:**  
SUN HAZARD – Never look directly at the sun  
with this device.

**WARNING:**  
CHOKING HAZARD – Small parts.  
Not for children under 3 years.



- 01 Central Focusing Wheel
- 02 Eyepiece Lens
- 03 Objective Lens
- 04 Optical Tube
- 05 Carrying Case
- 06 Cleaning Cloth

**4X30 BINOCULARS**  
OUTDOOR EXPLORATION GEAR

2