

3



10x25 Monoculars

Instruction Manual

80-01025



1. Rubber eyecup
2. Eyepiece adjustment
3. Carrying bag



2

1



WARNING:
SUN HAZARD – Never look directly at the sun
with this device.



WARNING:
CHOKING HAZARD – Small parts.
Not for children under 3 years.

Adjusting the focus:

You can use the eyepiece adjustment (2) to change the focus of your monocular. To focus, look at an object approximately 100 metres away through the monocular and turn the eyepiece adjustment (2) until the object comes into focus.

Reversing the rubber eyecup:

Those who wear spectacles should reverse the rubber eyecup (1) to look through the monocular while wearing spectacles. The monocular's maximum field of view can thus be used.

Cleaning your monocular:

1. Remove coarse dust with a brush.
2. Use a soft, lint-free cloth for further cleaning.
3. Should there still be residue on the lens, dampen the cloth with standard cleaning fluid for optical glass cleaner (available from photography shops). Do not press hard when cleaning.



SUN WARNING

WARNING: NEVER ATTEMPT TO OBSERVE THE SUN WITH THIS DEVICE! OBSERVING THE SUN – EVEN FOR A MOMENT – WILL CAUSE INSTANT AND IRREVERSIBLE DAMAGE TO YOUR EYE OR EVEN BLINDNESS. Eye damage is often painless, so there is no warning to the observer that the damage has occurred until it is too late. Do not point the device at or near the Sun. Do not look through the device as it is moving. Children should always have adult supervision while observing.

SAFETY WARNINGS

Read and follow the instructions, safety rules, and first aid information.

- Respect privacy: When using this device, respect the privacy of other people. For example, do not use them to look into people's homes.
- Choking hazard: Children should only use device under adult supervision. Keep packaging materials like plastic bags and rubber bands out of the reach of children as these materials pose a choking hazard.
- Risk of blindness: Never use this device to look directly at the Sun or in the direct proximity of the Sun. Doing so may result in a permanent loss of vision.
- Risk of fire: Do not place device, particularly the lenses, in direct sunlight. The concentration of light rays could cause a fire.
- Do not disassemble this device. In the event of a defect, please contact your dealer. The dealer will contact the Customer Service Department and can send the device in to be repaired if necessary.
- Do not subject the device to temperatures exceeding 60° C [140° F].



- Disposal: Keep packaging materials, like plastic bags and rubber bands, away from children as they pose a risk of suffocation. Dispose of packaging materials as legally required. Consult the local authority on the matter if necessary and recycle materials when possible.