



How to use your EMERGENCY BLEED KIT


Before you ride: fill your emergency bleed kit with brake fluid - check with the manufacturer of your brakes to confirm what fluid you require. We recommend filling until the brake fluid is just touching the threaded section of your bleed kit to reduce the risk of overspill.




Unscrew the bleed plug from your brake lever bleed port, ensuring you remove the o-ring with the plug.




Remove the small end cap from your emergency bleed kit.




Screw the bleed kit into your brake lever until you feel the o-ring start to compress.



Holding the bleed kit body steady, unscrew the large end cap.



Squeeze your lever, watching for any air that bubbles into the bleed kit body. Release the lever, then squeeze again - repeat until no more air comes through.



6

Repeat the above steps in reverse order to remove the bleed kit from your brake lever.

Pro tip: wrap a rag or paper towel around the bleed kit before unscrewing from the brake lever to soak up any excess brake fluid that may escape.

OPTIONAL:

The night before bleeding your brakes, secure your brake levers in the "squeezed" position using a tie strap, shoe laces, or by leaning your brake lever up against something solid - this will help draw any trapped air up to the bleed port, making for an easier and more effective bleed.